

LLM.LSP — Length Lister & Measurement Toolkit for AutoCAD

Version 1.79 — August 04, 2025

Author: Timmay!

PURPOSE

Measures the total length of selected AutoCAD entities and displays results in flexible, user-defined units (feet, inches, meters, etc.). Offers rounding, clipboard support with toggle, locale formatting, expanded breakdowns for mode 8, and more.

SUPPORTED OBJECTS

LINE, ARC, CIRCLE, LWPOLYLINE, POLYLINE, SPLINE, ELLIPSE

INSTALLATION

1. Open AutoCAD
2. Load LLM.lsp using the APPLOAD command
3. Use the commands below

PRIMARY COMMANDS

- **LLM:** Repeats interactive length measurements. Displays "LLM Repeat Measure + Clipboard Copy" if clipboard copy is enabled, or "LLM Repeat Measure" if disabled. Shows results in an alert box or command line.
- **LLM-S:**  Opens an interactive settings menu to configure units, rounding, clipboard options, and display settings.
- **LLM-R:**  Resets all parameters to factory defaults with a confirmation prompt.
- **LLM-?:**  Displays a help summary and current configuration.

SESSION PARAMETERS (Global Variables)

Variable	Description	Default
llm-copy-label	Copy result label to clipboard	NIL
llm-copy-unit	Copy unit label to clipboard	T

Variable	Description	Default
llm-clipboard-copy	 Enable/disable copying results to clipboard	T
llm-locale	Decimal format: "US" (dot) or "EU" (comma)	"US"
llm-alert-enabled	Use popup alert box for results	T
llm-output-mode	Unit display mode (e.g., "4", "P1", "8")	"P8"
llm-rounding-mode	"UP"=Up, "DOWN"=Down, "NEAREST"=Nearest	"UP"
llm-foot-symbol	Display unit symbol as "ft" or ""	"ft"
llm-space-enabled	Add space between number and unit	NIL
llm-length-value	Manual length to add to computed total	0.0
llm-length-unit	Unit of manual length value	"ft"
llm-expanded-display	Show expanded breakdown (geom + manual) for mode 8	NIL

To change any of these, use LLM-S.

UNIT OUTPUT MODES

- **1:** Inches
- **2:** Centimeters
- **3:** Feet (decimal)
- **4:** Feet-Inches
- **5:** Meters
- **6:** Yards
- **7:** Kilometers
- **8:** All Units (1–7); if *llm-expanded-display* is T, shows a tabular breakdown with object geometry, add-on length, and total

PREDEFINED COMBO MODES

- **P1:** Feet-Inches + [Meters]
- **P2:** [Feet / Meters]

- **P3:** [Feet : Meters]
- **P4:** Feet / Meters (default)
- **P5:** Feet : Meters
- **P6:** [Meters / Feet]
- **P7:** [Meters : Feet]
- **P8:** Meters / Feet
- **P9:** Meters : Feet

ROUNDING MODES

- **UP:** Round Up
- **DOWN:** Round Down
- **NEAREST:** Round to Nearest

LOCALE FORMATTING

- **US:** 1,234.56 (decimal point)
- **EU:** 1.234,56 (decimal comma)

LLM-S OPTIONS

- **Units (1–8):** Select output mode (e.g., "4" for Feet-Inches, "8" for all units).
- **Predefined Formats (P1–P9):** Select combo modes or enter multiple (e.g., "1,4,7").
- **Toggles:**
 - **R:**  Toggle Rounding Mode (Up/Down/Nearest)
 - **C:**  Toggle Clipboard Data Copy (ON/OFF)
 - **L:**  Cycle Clipboard Label States (Label ON/OFF, Unit ON/OFF)
 - **F:**  Toggle Locale Format (US/EU)
 - **A:**  Toggle Alert Box (ON/OFF)
 - **S:**  Toggle Space Between Unit and Result
 - **':**  Toggle Foot Unit Symbol ("ft" or "'")

- **X:**  Toggle Expanded Result Report for Mode 8
- **Length Settings:**
 - **E:**  Enter Length Value to add to computed total
 - **T:**  Select Length Unit Type (1–7)
- **Exit:**  Press **Enter** or type **ESCAPE**

EXAMPLE WORKFLOW

1. Run LLM-S:
 - Set output to P1, rounding to NEAREST, enable clipboard copy (C), enable alerts (A).
2. Run LLM:
 - Verify prompt: LLM Repeat Measure + Clipboard Copy
 - Select objects.
3. View results in alert box or command line and paste with Ctrl+V.
4. Run LLM-R to reset settings if needed, confirming with Yes.
5. Run LLM-? to view current settings and help.

TIP

Use LLM-? to view the help summary and current settings at any time.
