

BLDC

Motor Driver

SV0 -- RED
HU -- GREEN
HV -- WHITE
HW -- YELLOW
COM -- BLACK

MOTOR

W -- BROWN
V -- GRAY
U -- ORANGE

DRIVER

Motor Phase Cable

MA(U)
MB(V)
MC(W)

Power Supply

VCC
GND

Control Board BLDC

Left side 5 screw connector

Motor Phase

MA
MB
MC
VCC
GND

Pin out bottom middle

G: GND
S: SC speed pulse output interface
V: 5V, reserved interface Tach (Future)
P: Signal Input External PWM signal input, Amplitude: 2.5-5v, Freq 50Hz-20KHz(best)
G: GND

Connector XH White, bottom right (HAL sensor)

GND, HC, HB, HA, 5v

Left side Screw Connector

5V -----| External Pot
0-5V -----|
GND -----|
DIR ----- GND
BRAKE ---- 5v Brake is active High level
STOP ----- GND (can be used as enable
(DIR and STOP active when low level)

