



Relay energized only when
`local_arm_request AND EN AND OK` is true.

Loss of any input or local interlock power removes permission through hardware.