CODE	COMPONENT
1	Driving school unit
2	Battery isolating switch
3	Tachograph
4	RH door lock switch
5	LH door lock switch
6	AC fan electronic module
7	Module control resistor unit
8	Line pressure sensor (automatic
	transmission)
9	Torque limiter solenoid valve
10	First gear switch
11	Differential lock switch
12	Dipped running lights earth relay
13	Warning cancellationswitch
14	Rear doors locking switch
15	Rear doors locking warning light
16	Injection pump advance solenoid valve (KSB) relay
17	Injection pump advance solenoid
	valve (KSB) temperature switch
18	Blown air temperature sensor
19	Electronic thermostat
20	Front ashtray light
21	Alarm display diode
22	Tailgate gas strut
23	Door and boot decoding relay
24	Transverse acceleration sensor
25	RH door opening motor
26	LH door opening motor
27	Cooling fans cut-off relay
28	RH door lock relay
29	LH door lock relay
30	Door/boot warning diode
31	Front fog lights diode
32	Canister diode
33	Fuel gauge computer timer relay
34	Roof light
35	Suspension height sensor
36	Self levelling suspension
37	Control accessory unit
38	Central accessory unit Retracting headlights computer
39	RH retracting headlight motor
40	LH retracting headlight motor
41	Self levelling suspension
	computer
42	EGR solenoid valve control
	computer
43	Cold start warning light
44	Heated seats warning light
45	Cold start computer
46	Cold start solenoid valve (diesel
	fuel inlet)
47	Oil level computer
48	RH main beam headlight
49	LH main beam headlight
50	RH dipped headlight
51	LH dipped headlight
52	Alarm electronic key (jack)
53	Cooling fan diode
54	Windscreen wiper motor filter
	(radio interference suppressor)
55	Retracting headlights relay
56	Accessory lights rheostat switch
57	Fan relay via central accessory
1	
58	unit Travel limit switch

CODE	COMPONENT
CODE	COMPONENT
59 60	Air distribution switch
62	De-icing motor EGR post-heat microswitch. 1
63	EGR post-heat microswitch. 2
64	Injection cut-off
	110°/115°temperature switch
65	Air recirculation solenoid valve
66	Sunroof relay
67	Passenger compartment
	ventilation control power supply
68	relay Passenger compartment
00	ventilation 4th speed relay
69	Surface temperature sensor
70	Water in diesel fuel sensor unit
71	Hinged door electric lock
72	Sliding door electric lock
73	Engine immobiliser LED
74	Courtesy light relay
75	C.D. loader
76	Control connector
77	Diesel injection main relay
78 79	High pressure solenoid valve Oxygen sensor balance relay
80	Cold start relay
81	Cold start button
82	Petrol/gas switch
83	Heated windscreen switch
84	Tipper pump assembly
85	Tipper remote control
86	Tipper switch relay
87	Tipper lowering solenoid valve
88	Tipper raise warning pressostat
89	Tipper raise motor
90 91	AC passenger evaporator fan AC condenser fan
92	AC info 1 condenser relay
93	AC info 2 evaporator relay
94	Hazard lights authorisation relay 1
95	Hazard lights authorisation relay 2
96	Rear doors electric locking
97	Passenger courtesy light
98	Operating light
99	Operating lights relay
1A	Dimmed operating lights relay
2A 3A	Heater control unit cut-off relay Self-contained heater cooling relay
0.7	n°1
4A	Self-contained heater cooling relay
	n°2
5A	Battery isolation relay
6A	Battery isolation timer relay
7A	Electrical solenoid relay
8A 101	Battery cut-off reset switch Cigar lighter
102	Distributor
103	Alternator
104	Anti-theft
105	Main electromagnetic horn
106	Electro-pneumatic horn
107	Battery
108	Ignition coil
109	ADAC computer
110	ABS Brake pressure control unit
111	Ignition assistance unit
112 113	Rear screen wiper timer Windscreen wiper timer
114	Dim/dip unit
	pini/dip driit

CODE	COMPONENT
115	Electric pump regulator unit
116 117	Headlight washer timer unit Lights on reminder buzzer/driving
	school alarm
118	ABS computer
119	Automatic transmission computer
120	Injection computer
121 122	Rear fog light switch Front fog light switch
123	Central door locking switch
124	Heater switch
125	Hazard warning lights switch
126	Cold air blower switch
127	Rear screen wiper switch
128 129	Heated rear window switch ECO/PERF switch
130	RH rear window winder switch
131	LH rear window winder switch
132	Driver's window winder switch
133	Passenger's window winder
	switch
134	Electric rear view mirror switch
135	Rear window winder locking switch
136	Choke control
137	Flasher unit
138	RH rear door electric lock
139	LH rear door electric lock
140	Driver's door electric lock
141 142	Passenger door electric lock Boot lid electric lock
143	Washer liquid minimum level
0	sensor
144	Coolant minimum level sensor
145	Wash/wipe combination switch
146	Pinking sensor 1
147 148	Atmospheric pressure sensor Oil pressure sensor
149	TDC sensor
150	RH rear wheel sensor
151	LH rear wheel sensor
152	RH front wheel sensor
153	LH front wheel sensor
154 155	Boot lid switch Reversing lights switch
156	Handbrake switch
157	Brake pedal switch
158	Full load switch
159	No load switch
160 161	Stop light switch Glove compartment switch
162	Flow sensor
163	Starter
164	Cold air blower
165	Boot light
166	RH number plate light
167 168	LH number plate light Glove compartment light
169	EGR solenoid valve
170	Power steering solenoid valve
171	Air conditioning control
172	RH rear light
173	LH rear light
174 175	RH rear fog light LH rear fog light
176	RH front fog light
177	LH front fog light
178	RH rear door switch

CODE	COMPONENT
179	LH rear door switch
180	Driver's door switch
181	Passenger door switch
182	RH reversing light
183	LH reversing light
184	RH side light
185	LH side light
186	Power steering pump assembly
187	Heater blower
188	Cooling fan unit
189 190	RH rear speaker LH rear speaker
191	RH front door speaker
192	LH front door speaker
193	Injector 1
194	Injector 2
195	Injector 3
196	Injector 4
197	Injector 5
198	Injector 6
199	Fuel tank sender unit
200	Heated rear screen
201	RH rear window winder LH rear window winder
202	Driver's window winder
204	Passenger window winder
205	Pressure switch
206	Air conditioning three-function
	pressure switch
207	Brake fluid level sensor
208	Lighting power module
209	Horn & lights switch
210	Analogue or digital clock
211	Rear screen wiper motor
212 213	Windscreen wiper motor
214	Front courtesy light RH rear courtesy light
215	LH rear courtesy light
216	RH front brake pad
217	LH front brake pad
218	Fuel pump
219	Headlight washer pump
220	Rear screen washer pump
221	Windscreen washer pump
222	Throttle potentiometer
223 224	Idle speed potentiometer Power assisted steering pressure
224	switch
225	Diagnostic socket
226	RH headlight
227	LH headlight
228	Idle speed regulator
229	Horn relay
230	Rear fog light relay
231	Front fog light relay
232	Starter relay
233 234	Cold air blower relay Fan assembly relay
235	Heated rear window relay
236	Fuel pump relay
237	Twin headlights relay
238	Injection locking relay
239	Electric mirror, driver's side
240	Electric mirror, passenger side
241	Lights rheostat
242	Downstream oxygen sensor
243	Oil level sensor

CODE	COMPONENT
244	
244	Injection coolant temperature sensor
245	Exterior temperature sensor
246	Electrical solenoid valve
247	Instrument panel
248	Fan temperature switch
249	Infrared transmitter
250 251	Vehicle speed sensor
251	Coolant dual function temperature switch
252	Mobile phone filter
253	RH front speaker
254	LH front speaker
255	RH front indicator light
256	LH front indicator light
257	Preheating unit
258	Heater plugs Temperature switch
259 260	Passenger compartment fuse box
200	and relay
261	Radio
262	Cooling and AC fan unit
263	Rear screen wash/wipe switch
264	Central door locking timer
265	Map reading/courtesy light
	console
266 267	Full load/no load switch
268	RH repeater LH repeater
269	Idling cut-off
270	8° temperature switch
271	Thermistor
272	Injection air temperature sensor
273	Engine speed sensor
274	Air conditioning solenoid valve
275	Additional fuel pump timer
276	"One touch" electric window control unit
277	Bulb monitor
278	Pinking sensor 2
279	Anti-percolation relay
280	AEI cut-off relay
281	Dipped headlights relay
282	Fuel filler flap electric lock switch
283	Additional fuel pump
284 285	RH headlight wiper motor LH headlight wiper motor
286	Rear screen washer switch
287	Ballast coil relay
288	Running lights main relay
289	Running lights side lights relay
290	Running lights dipped headlights
204	relay Carburattor calcacid valva
291 292	Carburettor solenoid valve Lights rheostat relay
293	Main power supply
294	Heated rear screen timer
295	Warning light unit
296	Fog lights shunt relay
297	Front fog light shunt
298	Heater
299	Relay plate
300	Rear cross member courtesy light
301 302	ABS electric pump relay Variable power steering relay
303	Automatic transmission selector
	light
304	Sunroof

0005	COMPONENT
CODE	COMPONENT
305	Advance correction solenoid valve
306	Advance correction temperature switch
307	Relay plate earth shunt
308	Degassing timer unit
309	Multifunction buzzer
310 311	Injection power module 1 Courtesy light timer
312	Accessory cut-off relay
313	Speed control relay
314	Headlight wiper relay
315	Windscreen wiper 2nd speed relay
316	Ignition 4° relay
317	Sunroof switch
318	Carburettor base heater
319	Air conditioning control panel
320 321	Basic/AC fan unit Air conditioning fan unit resistor
322	Power steering/air conditioning
	diode
323	Power steering/air conditioning
	solenoid valve diode
324	Speed relay
325	Radio satellite control
326 327	Speed warning buzzer
328	Fuel gauge computer LH front courtesy light
329	RH front courtesy light
330	Rear cigar lighter
331	Cruise control switch
332	"One touch" switch
333	Driver's seat belt switch
334	Thermal circuit breaker
335 336	Fan speed 1 relay Fan speed 2 relay
337	Fan speed 3 relay
338	Turbo pressure regulator
339	Cold start injector
340	Timed temperature switch
341	Idle speed regulation valve
342	Turbo safety pressostat
343 344	Oil temperature sensor Cruise control pump
345	Cruise control safety valve
346	Cruise control pump solenoid
	valve
347	Radio power supply
348	"One touch" electric window
349	switch Distributor
350	LH rear brake pad
351	RH rear brake pad
352	LH front seat back motor 1
353	LH front seat back motor 2
354	LH front seat height motor
355	LH front seat cushion motor
356	RH front seat back motor 1
357 358	RH front seat back motor 2 RH front seat height motor
359	RH front seat cushion motor
360	Voice synthesiser switch
361	ABS hydraulic unit
362	Battery + terminal plate
363	Voice synthesiser unit
364	Voice synthesiser speaker
365	RH tweeter

CODE	COMPONENT
366	LH tweeter
367	RH bonnet switch
368	LH bonnet switch
369	Turbo bearing coolant pump
370	Dim/dip resistor
371	Fuel vapour absorber
372	Boot open/close unit
373	Cruise control unit
374	LH front seat back adjustment
375	control RH front seat back adjustment
	control
376	LH front seat adjustment control
377 378	RH front seat adjustment control
3/0	LH front seat height adjustment control
379	Fast idle relay
380	ADAC computer conversion unit
381	Carburettor
382	Inlet manifold relay
383	Inlet manifold temperature switch
384	Manifold heater
385	Driver's heated seat
386	Passenger's heated seat
387	Oil pressure sensor
388	4x4 warning light switch
389	Central speaker
390	Rear fog light shunt
391	Rear screen wiper timer
392	ADAC sequence control
393	Power steering/air conditioning solenoid valve
394	Electric aerial
395	A4 automatic transmission stop light switch
396	Full load switch
397	Anti-percolation fan unit
398	Exhaust gas recirculation (EGR) solenoid valve
399	Anti-pollution relay
400	Lighting power module advance
	adjustment diode
401	Anti-pollution solenoid valve
402	Oil temperature switch
403	Secondary electromagnetic horn
404	Advance solenoid valve (KSB cold start device)
405	Load lever switch
406	Pre-heater temperature switch
407	Air recirculation flap control
408	Evaporator sensor
409	Power assisted steering pump
440	assembly relay
410	Idling cut-off relay
411	Air conditioning pressostat
412 413	Fast idle solenoid valve Heated seat identifier unit
414	Water in fuel sensor
415	Headlight wiper solenoid valve
416	Idling cut-off capacitor
417	AC recirculation relay
418	Passenger compartment
4.0	temperature sensor fan
419	AC monitoring unit
420	Mixing flap
420	
420	4x4 ABS clutch switch
	4x4 ABS clutch switch Cruise control steering column

CODE	COMPONENT
	COMPONENT
423	Cruise control steering column switch 2
424	Cruise control overspeed relay
425	ABS connection plate
426	Turbo opening solenoid valve
427	Alarm unit
428	ABS main relay (Bosch)
429	ABS auxiliary relay (Bosch)
430	ABS diode unit (Bosch)
431	Instrument panel initialisation
432	switch ABS main solenoid valve
433	Alarm ultrasound sensor
434	ABS cut-off pressostat
435	ABS solenoid valve unit
436	Turbo pressure solenoid valve
437	Throttle body heater
438	Bonnet switch
439	ABS computer relay
440 441	Heated seat switch
441 442	Automatic transmission Self-driven alarm siren
442	Automatic transmission control
- -	solenoid valve
444	Front map reading light
445	Fuel pump ballast resistor
446	Headlight adjustment control light
447	Rear fog light inhibitor relay
448	After ignition contact plate
449	Diesel fuel heater resistor
450 451	Diesel fuel heater relay Diesel fuel heater temperature
431	switch
452	Perimetric sensor unit
453	Volumetric sensor unit
454	Volumetric transmitter/receiver
455	Emission control solenoid valve
456	diode Fuel pump ballast relay
457	RH rear door first position switch
458	Rear fog and reversing light
459	Rear screen wiper timer
460	Rear axle switch
461	ABS overload protection relay
462	Tailgate/central number plate light
463	Quarter panel light
464	Courtesy light switch
465 466	Turbo bearing coolant pump timer Shunt box
466 467	Dipped/side lights relay
468	Driving school dipped headlight
	diode
469	Instructor's control unit
470	Driving school windscreen wiper
4=-	high speed relay
471	Electric window winder control
472	relay Radio cut-off relay
473	Voice synthesiser test switch
474	AC compressor control relay
475	Recirculation motor
476	Quadra transmission unit
477	Diesel heater accelerator pump
478	4x4 differential lock
479	Heater accelerator temperature
490	Switch Hot air extractor sensor
480 481	Hot air extractor sensor Hot air extractor fan
701	I IOLUII OMIUOIOI IUII

CODE	COMPONENT
482 483	Differential lock solenoid valve Acceleration sensor
484	4x4 transmission solenoid valve
485	Multifunction switch
486	Passenger seat belt switch
487	Choke solenoid valve
488 489	Choke temperature switch LH rear first position switch
490	RH front first position switch
491	LH front first position switch
492	Mobile phone unit
493	LH rear seat
494 495	RH rear seat RH front seat
496	LH front seat
497	ABS 4x4 accelerometer
498	Vertical accelerometer
499	Longitudinal accelerometer
500	Transverse accelerometer
501	Seat and rear view mirror memory unit
502	Variable power steering computer
503	Decoder unit
504	RH rear reading light
505	LH rear reading light
506 507	Accessories socket Front & rear fog and hazard
307	warning lights switch
508	RH boot light
509	LH boot light
510	Memory seat sensor
511 512	Courtesy light switch Map reading light switch
513	Seat inflation memory switch
514	Seat inflation pump memory
515	Seat memory unit
516	Seat memory unit
517	Seat memory programme and control keypad
518	Pulse generator
519	LH front door edge light
520	RH front door edge light
521	RH rear door edge light
522 523	LH rear door edge light Driver's door light
524	Passenger door light
525	RH rear door light
526	LH rear door light
527	Driver's switch for rear window
528	winder Driver's switch for rear window
320	winder
529	Central courtesy light
530	Cruise control stop switch
531 532	Cruise control clutch switch Driver's switch for front passenger
J32	window winder
533	Self levelling suspension switch
534	Variable shock absorber switch
535	ECO/PERF indicator light
536	Headphone jack socket
537 538	LH headlight adjustment motor RH headlight adjustment motor
539	Engine compartment light switch
540	Variable power steering motor
541	Courtesy mirror light
542	Self levelling suspension
	computer

CODE	COMPONENT
543	Variable shock absorber computer
544	Self levelling suspension pump
F 4 F	relay
545	Self levelling suspension safety relay
546	Self levelling suspension pump
547	unit LH rear shock absorber solenoid
	valve
548	RH rear shock absorber solenoid valve
549	LH front shock absorber solenoid valve
550	RH front shock absorber solenoid
551	valve RH front vehicle level sensor
552	LH front vehicle level sensor
553	RH rear vehicle level sensor
554	LH rear vehicle level sensor
555	Self levelling suspension solenoid
	valve
556	Tailgate position switch
557	Tailgate closing assistance motor
558	Tailgate closing switch
559	Tailgate closing assistance
	computer
560	Tailgate opening switch
561	Horn compressor
562	Headlight adjustment control
563	Oil cooler relay
564	Oil cooler fan unit
565	Throttle body
566	Anti-percolation timer temperature
300	switch
567	Electric coolant pump
568	Electric coolant pump timer
569	4-speed automatic transmission kick-down switch
570	Power steering 1st stage solenoid
	valve relay
571	Power steering 2nd stage solenoid valve relay
572	Power steering diode
573	Electric coolant pump relay
574	Electric coolant pump diode
575	E5F engine adjustment terminal
576	Anti-percolation authorisation relay
577	Mobile phone computer
578	Pierburb emission control solenoid
579	valve
2/9	Exhaust gas recirculation solenoid valve switch
580	Turbo bearing coolant pump authorisation relay
581	AC/coolant pump separator diode
582	Coolant pump temperature switch
583	Steering wheel angle sensor
584	AC compressor clutch relay
585	Pneumatic pressure sensor
586	Hazard warning lights switch
587	ABS longitudinal accelerometer
	Driver's courtesy mirror light
588 589	
	Injection pump
590	Alarm switch
591	Catalytic converter temperature sensor
592	Catalytic converter temperature
1	processor

CODE	COMPONENT
593	Variable power steering safety
393	relay
594	Catalytic converter temperature
EOE	warning light diode
595 597	Electric pump authorisation relay Engine fuse box and relay
598	Torque reducer solenoid valve
599	Coolant pump locking relay
600	Heater fan motor
601	Heater fan coolant temperature switch
602	Reversing lights relay
603	Memory steering column
	adjustment control
604 605	Memory steering column motor Carburettor base heater
003	authorisation relay
606	Carburettor base heater relay
607	Carburettor base heater
	temperature switch
608	Anti-percolation fan sensor
609 610	Coolant temperature computer ABS diagnostic switch
611	LH heated windscreen
612	LH heated windscreen relay
613	Heated windscreen switch
614	"One touch" electric window
615	control unit Driver's heated seat switch
616	Passenger's heated seat switch
617	Attenuation resistor
618	Transponder code entry button
619	Door and boot receiver switch
620	Twin throttle potentiometer
621	Coolant temperature switch shunt relay
622	Anti-percolation timer
623	Degassing (valve) solenoid valve
624	RH rear seat back adjustment
625	RH left seat back adjustment
626	Automatic transmission selector light unit
627	Cruise control switch
628	Variable power steering speed
	sensor
629	RH heated windscreen relay
630 631	RH heated windscreen Exterior temperature module
632	Heater plugs 1 and 3
633	Heater plugs 2 and 4
634	Clutch sensor
635	AC compressor blocking timer
636	Stop light separation diode
637 638	Stop light/clutch separation diode Driving school warning
000	light/buzzer relay
639	Centre stop light
640	Injection locking relay assistance
C44	relay
641 642	Cooling/timer separator diode
042	AC/diesel pre-heating separator diode
643	Anti-percolation resistor
644	Managed suspension computer
645	Passenger compartment
C40	computer
646 647	Heated windscreen relay Heated windscreen
648	Injection diode
0-10	Infootion aloue

CODE	COMPONENT
649	Stepping motor
650	Heated seats warning light
651	LCD panel
652	Air conditioning control relay
653	Combined clock/ext. temp./mobile
654	phone display unit
655	Alarm key and equipment lock key Halex/Halmo sensor
658	Cruise control solenoid valve and
	pneumatic control unit
659	AC/cooling separator diode
660	Air conditioning cut-off
204	temperature switch
661	Air conditioning cut-off timer control relay
662	Navigation aid computer
663	Dual ignition coil 1
664	Dual ignition coil 2
665	Dual ignition coil 3
666	Dual ignition coil 4
667	Brake pedal travel sensor
668	LH front vertical accelerometer RH front vertical accelerometer
669 670	LH rear vertical accelerometer
671	RH rear vertical accelerometer
672	Resistor unit
673	Rear window winder safety
	override switch
674	Rear fog light/heated rear screen
675	double switch Clutch pedal switch
676	Accelerator pedal switch
677	Two-way washer pump, front and
	rear
678	EGR solenoid valve temperature
070	switch
679 680	Radio interference suppressor Pre-heater plug 1
681	Pre-heater plug 2
682	Pre-heater plug 3
683	Pre-heater plug 4
684	Compact disc player
685	Cruise control solenoid valve
686	Power steering solenoid valve relay
687	Diode unit
688	Oil level and temperature sensor
689	Cruise control and airbag switch
690	Electronic thermostat relay
691	Navigation aid screen
692 693	Mobile phone handset Mobile phone speaker
694	LH heater jet
695	RH heater jet
696	Shunt
697	After ignition/accessory diode
698	Accessory/after ignition diode
699	Automatic transmission cruise control shunt
700	Percolation fan low speed relay
701	Percolation pump locking relay
702	18 minute anti-percolation coolant
	pump timer
703	Electric window winder relay
704	Hood warning buzzer
705 706	Hood rear screen blower relay Hood switch
707	Hood cover switch

CODE	COMPONENT
708	Hood rear screen blower
709	- Power assisted steering and
	pump assembly anti-roll diode
710	Unit fuse
711	Diesel pump
712	Cooling unit
713	Caravan connection
714	F8Q emission control/AC
	separator diode
715	Mobile phone communication
	interface
716	RH front shock absorber
717	LH front shock absorber
718	RH rear shock absorber
719	LH rear shock absorber
720	AC cut-off relay
721	ABS and ABS hydraulic unit
	computer assembly
722	Heated windscreen/rear screen
	double switch
723	Automatic clutch diode
724	Automatic clutch pump unit
725	Automatic clutch solenoid valve
726	Gear engaged sensor
727	Clutch position sensor
728	Gear lever sensor
729	Accelerator position sensor
730	Automatic clutch computer
731	Heated windscreen timer
732	Overspeed switch
733	Overspeed/lights on reminder
	computer Driver's "one touch" electric
734	
705	window switch
735 736	Seat belt reminder buzzer
737	Magnetometer Vehicle speed info sensor (N7Q)
738	Injection needle lift sensor
739	Headlight washer liquid level
139	sensor
	0011001
740	Circuit + bat/+ accessory
1 .0	separator diode
741	Altimetric corrector
742	Advance retard solenoid valve
	(load independence solenoid
	valve)
743	- Altimetric corrector relay.
744	Pre-/post-heating timer/EGR
	computer feed relay
745	Diesel fuel heater switch relay
746	Camshaft sensor
747	LH rear seat switch
748	RH rear seat switch
749	LH front head restraint switch
750	Child safety relay
751	After ignition relay no. 1 (ap1)
752	After ignition relay no. 2 (ap2)
753	Headlight washer pump relay
754	Electric/hydraulic interface
755	Traction control switch
756	Airbag/pretensioner computer
757	Driver's pretensioner
758	Passenger's pretensioner
759	Boot lid 1st position switch
760	Heated windscreen/rear screen
761	Switch Alternator power cut-off relay
. /01	Internator power cut-off felay

CODE	COMPONENT
762	Automatic clutch pump unit relay
763	Automatic clutch warning buzzer
764	Air pump feed relay and air pump
705	solenoid valve
765	Air pump motor
766	Air pump solenoid valve
767	Automatic transmission computer relay
768	Variable inlet solenoid valve
769	Air conditioning cut-off oil
709	temperature switch
771	Door/boot open/seat belt warning
	module
772	Heater relay
773	Heater
774	Pretensioner supply
775	Automatic transmission (Volvo
113	aw)
776	Locking relay assistance relay
777	Power feed fuse rack
778	Ignition coil module
779	Automatic transmission
113	multifunction switch
780	Automatic transmission vehicle
700	speed sensor
781	Relative pressure sensor
701	(automatic transmission)
782	Automatic transmission engine
702	speed sensor
783	Power relay unit 2
784	Control relay unit 2
785	Variable distribution feed relay
786	Variable distribution solenoid valve
700	1
787	Variable distribution solenoid valve
101	2
788	Fuel reserve tank vent solenoid
	valve
789	Hands-free mobile phone micro
	unit
790	Variable air inlet solenoid valve 2
791	Ignition coil, cylinder 1
792	Ignition coil, cylinder 2
793	Ignition coil, cylinder 3
794	Ignition coil, cylinder 4
795	Ignition coil, cylinder 5
796	Ignition coil, cylinder 6
797	Lambda sensor
798	Dual mode solenoid valve
799	Injection air flow sensor
800	Blower control relay
801	
	Non-return charge circuit diode
	Non-return Charge circuit diode
802	Non-return N7U computer
802	Non-return N7U computer diode/fuel pump relay
	Non-return N7U computer diode/fuel pump relay Non-return N7U computer
802 803	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay
802 803 804	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay
802 803 804 805	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay
802 803 804	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger
802 803 804 805 806	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system
802 803 804 805 806 807	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve
802 803 804 805 806 807 808	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay
802 803 804 805 806 807 808 809	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay Passenger airbag
802 803 804 805 806 807 808 809 810	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay Passenger airbag RH rear heated quarter light
802 803 804 805 806 807 808 809 810 811	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay Passenger airbag RH rear heated quarter light LH rear heated quarter light
802 803 804 805 806 807 808 809 810 811 812	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay Passenger airbag RH rear heated quarter light LH rear heated quarter light Retracting mirrors computer
802 803 804 805 806 807 808 809 810 811 812 813	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay Passenger airbag RH rear heated quarter light LH rear heated quarter light Retracting mirrors computer Ignition power stage n° 1
802 803 804 805 806 807 808 809 810 811 812	Non-return N7U computer diode/fuel pump relay Non-return N7U computer diode/coolant pump relay Protective relay Heated windscreen relay Monobloc passenger compartment cooling system EGR timer solenoid valve AEI or power module feed relay Passenger airbag RH rear heated quarter light LH rear heated quarter light Retracting mirrors computer

CODE	COMPONENT
816	RH passenger airbag igniter
817	Heated windscreen relay unit 2
818	Heating accelerator coolant pump authorisation relay
819	Air flap solenoid valve
820	Central flasher unit + lights on
	and/or overspeed warning
821 822	Opening rear screen locking
823	Opening rear screen switch
824	RH speaker, 3rd line LH speaker, 3rd line
825	Traction control/ECO/PERF
	switch
826	k7 cassette player
827 828	Driver's distribution motor Passenger's distribution motor
829	Passenger air inlet motor
830	Passenger's mixer motor
831	Passenger's heater control panel
832	Passenger's air conditioning
000	control panel
833 834	Fuel pump and sender unit Self levelling suspension
	compressor computer
835	Automatic clutch pressure switch
836	Non-return starter coil diode
837	Charge warning light cut-off relay
838 839	Regulator current cut-off relay Injection computer/automatic
039	clutch computer/idle speed
	regulator motor one-way diode
840	Charge warning light cut-off relay
	timer
841	LH quarter light open/close electric motor
842	RH quarter light open/close
843	electric motor
844	Electric quarter light switch Fuel filler flap lock motor
845	No. 2 passenger airbag
846	Front passenger seat forward
	inclination motor
847	Front passenger seat backward inclination motor
848	Front driver's seat forward
	inclination motor
849	Front driver's seat backward
850	inclination motor
030	Electric power steering torque sensor
851	Tyre pressure computer
852	Electric window winder timer
853	+APC, +AVC relay
854	Electric window winder simultaneous switch
855	Fuel cut-off solenoid switch with
	immobiliser code
856	Rear window and tailgate control
857	unit Infrared transmitter relay
858	Lights rheostat
859	Rear window and tailgate control
	audible signal
860	Rotary switch
861 862	Passenger airbag Cruise control prohibition relay in
002	pn
863	Dual function aerial feed

CODE	COMPONENT
864	Carburettor flow slide valve and
004	temperature sensor
865	Advance actuator
866	Diesel injection computer
867	Rear fog light and RH reversing light
868	Rear fog light and LH reversing light
869	LH front door switch/self-levelling
870	suspension isolation diode RH front door switch/self-levelling
871	suspension isolation diode Rear door switch/self-levelling
	suspension isolation diode
872	RDS decoder
873 874	RH distribution motor LH distribution motor
875	RH air inlet motor
876	LH air inlet motor
877	RH mixer motor
878	LH mixer motor
879	LH rear window winder relay unit
880	RH rear window winder relay unit
881	Front passenger window winder relay unit
882	Hood cover unlocking switch
883	Hood cover lock
884	Optional road box module
885	Electric hood
886	Aerial amplifier
887 888	Upstream oxygen sensor Carminat radio data system unit
889	Magnetometer computer
890	Igniter solenoid valve relay
891	Igniter relay
892	Igniter solenoid valve
893	Igniter
894	Leak detection pump
895	Dual mode control exhaust computer
896	Bi-mode motoreductor
897	Front fog light resistor unit
898	Additional heater plug
899	Driver's airbag (x06)
900	Battery compartment fans
901	Insulation check computer
902	Battery compartment cover switch Electromagnetic switch
904	Traction motor
905	Traction motor fan unit
906	Minimum heater fuel switch
907	Vacuum pump
908	0.5 bar braking assistance failure switch
909	Heater metering pump
910	Battery compartment fan relay
911	Charging cut-off relay
912	Charging temperature switch
913	Battery compartment temperature sensor
914	Electromagnetic switches control relay
915	Battery compartment failure relay
916	Charging socket
917	AC/DC converter
918	Emergency stop switch
919	Forward/reverse switch
920	Braking potentiometer

0005	COMPONENT
CODE	COMPONENT
921	Accelerator potentiometer
922 923	Traction motor fan relay Heater switch
923	Heater warning light
925	Self-contained heater
926	Electrical test display
927	Impact sensor (inertia sensor)
928	Battery current sensor
929	Ventilated on-board charger
930	Static converter
931	Alarm speaker electrical test unit
932	Direction of travel control
933	potentiometer Vacuum pump control pressure
933	gauge
934	Passenger compartment fan low
	speed relay
935	Heater programming relay
936	Charging socket holder
937	Converter fan
938	Traction battery
939	Self-contained heater computer
940	Gauge interface unit
941 942	High voltage fuse High voltage fuse microswitch
943	Warning lights test relay
944	Traction motor temperature switch
946	Electric vehicle electrical test unit
947	Charge status warning light
948	Hood cover cylinder switch
949	5th bow cylinder switch
950	Main cylinder switch
951	Electric hood pump unit
952	Fuel cut-off solenoid and electric advance actuator solenoid
953	Wheel speed computer
954	Self-levelling suspension control
	module computer alarm
955	Self-levelling suspension overload
	detection pressure gauge
956	Self-levelling suspension purge solenoid valve
957	Transponder unit
958	Lights on warning buzzer/reset
330	rear fog lights relay diode
959	Lights on reminder
	buzzer/dashboard diode
960	Rear fog light reset relay
961	Battery isolation (x70)
962 963	Alternator safety relay Fan unit failure detector diode 1
964	Fan unit failure detector diode 1 Fan unit failure detector diode 2
965	Low-speed fan/1st threshold
	temperature switch one-way diode
966	Injection/anti-percolation relay
	one-way diode
967	Electromagnetic horn
968	Shift lock relay
969	3rd imposed shift lock electromagnet
970	Stalk
971	dp0 automatic transmission
	module
972	Carminat keypad
973	GPS unit
974	GPS aerial
975	CD-ROM drive
976	User interface manager

CODE	COMPONENT
977	Battery coolant pump
978	Charging socket flap electric lock
979	Oil vapour re-breathing pipe
980	heater Diesel plugs relay unit
981	Injector with sensor
982	Rear courtesy light switch relay
983	Diesel injection computer feed
	relay
984	Charge level computer (electric
	vehicle)
989 990	Discharge bulb computer RH front potentiometer position
990	sensor
991	RH rear potentiometer position
	sensor
992	Automatic transmission multi-
	selector
993	Alarm display LED (j66)
994	Volumetric exclusion switch (j66)
995 996	Electronic rev counter (j66) LPG injection simulator
997	LPG injection simulator LPG computer
998	LPG mechanism
999	LPG ignition adaptor
1001	LPG tank sender
1002	LPG tank solenoid valve
1003	LPG/petrol selector switch
1004	Oxygen sensor signal control relay
1005	LPG canister cut-off solenoid
4006	valve relay
1006 1007	LPG adaptor Charge box switch
1007	Fan switch
1009	Charge box motor
1010	Rear compartment fan motor
1011	Navigation aid interconnection unit
1012	Navigation aid speaker
1013	Variable camshaft
1014	Engine cooling fan unit low-speed
1015	resistor Anti-stall timer
1016	Passenger compartment fuse box
1017	Automatic transmission turbine
	speed sensor
1018	Feed-back relay (door/boot lock)
1019	Exchanger flow lock-up solenoid
1000	valve
1020 1021	Under drive switch
1021	Shift lock switch Key lock switch
1023	AC fan unit power module (j64)
1024	LPG fuel level indicator
1025	Engine speed signal amplifier
1026	Driver's lateral airbag
1027	Passenger's lateral airbag
1028	Driver's side satellite
1029	Passenger side satellite
1030	Resistor
1031	Disengageable high-pressure piston
1032	Fuel manifold pressure sensor
1033	Positive protected battery
1034	Running lights relay mounting
1035	LPG principal solenoid valve
1036	LPG safety and idling solenoid
	valve
1037	Engine speed signal amplifier

CODE	COMPONENT
1038	Programming shunt (G.P.L.
1039	calculator) Indicator and hazard lights relay
1040	Windscreen wiper relay
1041	Rear screen wiper relay
1042	Central door locking relay
1043	Central door unlocking relay
1044	"One-touch" electric window closer relay
1045	"One-touch" electric window opener relay
1046	Injection diode 2
1047	Injection relay
1048	Tailgate computer
1049	Heating element relay
1050	Clutch solenoid valve
1051 1052	Engaging 1 solenoid valve Engaging 2 solenoid valve
1052	Selecting 1 solenoid valve
1054	Selecting 2 solenoid valve
1055	Engaging position sensor
1056	Selecting position sensor
1057	Clutch position sensor
1058	Gear lever switch
1059	Automatic transmission pressure sensor
1060	Transmission input speed sensor
1061	Fuel tank sender relay
1062	Driver's door/computer diode
1063	AC power supply
1064	Autonomy prolonging device
1065	Autonomy prolonging device switch
1066	Fuel temperature sensor
1067	Additional heater relay 1
1068	Additional heater relay 2
1069 1070	Additional heater relay 3 Cruise control interface
1071	Turbocharging pressure sensor
1072	Additional heater plug relay 2
1073	Additional heater plug relay 3
1074	Additional heater plug relay 4
1075	Air swirl solenoid valve
1076	Mechanied throttle body
1077	Pencil-type coil cylinder 1
1078	Pencil-type coil cylinder 2
1079	Pencil-type coil cylinder 3
1080 1081	Pencil-type coil cylinder 4 Cruise control reverse gear limit
	switch
1082	Card reader, keyless vehicle
1083	RH front handle detector, keyless vehicle
1084	LH front handle detector, keyless vehicle
1085	RH rear handle detector, keyless vehicle
1086	LH rear handle detector, keyless vehicle
1087	Engine reverse gear pushbutton, keyless vehicle
1088	Electric steering column lock
1089	LPG injector
1090	LPG temperature and flow sensor
1091	Diagonal brake 1 pressure sensor
1092	Diagonal brake 2 pressure sensor
1093	Brake booster microswitch
1094	ABS/ESP computer

CODE	COMPONENT
1095	Driver's lap belt pretensioner
1096	Passenger's lap belt pretensioner
1097	LH rear pretensioner
1098	RH rear pretensioner
1099	LH rear lateral airbag
1100	RH rear lateral airbag
1101	Driver's head level lateral airbag
1102	Passenger's head level lateral
	airbag
1103	Driver's chest level lateral airbag
1104	Passenger's chest level lateral
	airbag
1105	Fuel flow actuator
1106	ESP reverse gear pushbutton
1107	Cluster sensor
1108	Child seat detector/passenger
1109	front Manual gearbox neutral/reversing
1109	lights sensor
1110	Tyre pressure monitoring display
1111	Sun detector
1112	Air toxicity sensor
1113	Additional passenger
	compartment heating
1114	Screen heater distribution motor
1115	Foot well distribution motor
1116	LESA computer
1117	LESA sensor
1118	Front passenger footwell light
1119	Driver footwell light
1120	RH rear passenger footwell light
1121	LH rear passenger footwell light
1122	Driver's door multiplex computer
1123	Passenger door multiplexing
	computer
1124	Rain sensor computer
1125	Central communications unit
1126	Telecom keypad Video display
1127 1128	GSM aerial
1129	Automatic transmission lever
1129	display
1130	Driver's seat position sensor
1131	Front passenger seat position
	sensor
1132	RH rear tweeter
1133	LH rear tweeter
1134	Camshaft row A sensor
1135	Camshaft row B sensor
1136	Camshaft row A shift
1137	Camshaft row B shift
1138	Downstream oxygen sensor row B
1139	Upstream oxygen sensor row A
1140	Transmission output speed
	sensor
1141	LH rear potentiometer position
11/12	sensor
1142 1143	Injector rail
1143	Emergency stop switch Battery disconnection module
1145	Ultra-fast heater evaporator water
	sensor
1146	Freon temperature sensor
1147	AC ultra-fast heating pressure
	gauge
1148	Freon inversion solenoid valve
1149	Freon by-pass solenoid valve
1150	Variable cylinder actuator

CODE	COMPONENT
1151	Tailgate catch
1152	Doors/boot locking status light
1153	Rear screen open switch
1154	Electric door unlocking
1155	Relay + accessories