APEREMOT E

INSTRUCTION MANUAL







Ape Labs ApeRemote

Assignment of a Group

Each Ape Labs lighting fixture can be assigned to a specific group (so certain fixtures can be controlled differently than others in the same room).

- Immediately after turning the Ape Labs fixture on, the current group setting of the fixture flashes on the remote control. (Factory setting is group 1.)
- While the group LED is flashing, tap the Group Button again to change groups. The selected group LED will change as you tap the Group Button

Note: The remote control switches to a power-save mode after a few minutes and will not detect the power-on event of the fixture. Press any key of remote control to stop the power-save mode.

Using the Remote Control

- > To select the group you'd like to control, tap the "Group" button until the group LED is lit up. To control all groups at once, press and hold the "Group" button until all four group LEDs light up.
- Programs, brightness, speed and sound active mode can be controlled by the corresponding keys (see figure).



List of Programs

Deutsch

NO	Program
1	White
2	Red
3	Orange
4	Amber
5	Lime
6	Green
7	Cyan
8	Cyan-Blue
9	Blue
10	Blue-Magenta
11	Magenta
12	Red Pastel
13	Green Pastel
14	Blue Pastel
15	Blue > Red
16	Magenta > White
17	White > Blue
18	Red Pastel > Green Pastel > Blue Pastel

No	Program
1	White
2	Red
3	Orange
4	Amber
19	Amber > Magenta > Blue
20	Rainbow

Hint: A long press on the left arrow will provide a static white color. A long press on the right arrow will provide a rainbow program. A long press on "Slow Down" stops a flash effect/color change.

Disabling of the Battery Status Indicator

The red/green glowing indicator of the battery level can be disabled.

- Step 1: Press and hold the power button on fixture until it flashes blue/white (This is also placing the fixture into Service Mode).
- Step 2: Remove the battery compartment out of the ApeRemote.

- Step 3: Slide the battery compartment back into the remote while pushing the "flashlight" symbol. (Remote will be flashing red on groups 1 & 4).
- > Step 4: Push the "Dim" button on the remote.
- Step 5: Press the power button on fixture one time.
- > Step 6: Press the "Power" button on the remote.

Enabling of the Battery Status Indicator

- Step 1: Press and hold the power button on fixture until it flashes blue/white (This is also placing the fixture into Service Mode).
- Step 2: Remove the battery compartment out of the ApeRemote.
- Step 3: Slide the battery compartment back into the remote while pushing the "flashlight" symbol. (Remote will be flashling red on groups 1 & 4).
- > Step 4: Push the "Bright" button on the remote.
- > Step 5: Press the power button on fixture one time.
- > Step 6: Press the "Power" button on the remote.

Pairing

Ape Labs lights and ApeRemotes can be paired permanently to one another so that they will no longer synchronize with other fixtures. Pair as many lights to one remote as you would like. This will allow users to create up to four groups on one remote and up to four

more groups on each additional remote that is being used at the same time.

Pairing an ApeRemote with a Fixture:

- Step 1: Remove battery from ApeRemote
- Step 2: While holding down flashlight button, insert battery into ApeRemote (if done correctly, group 1 and group 4 will flash on remote).
- Step 3: Turn on fixture with long press on power button (5 seconds – if done correctly, fixture will blink blue).
- Step 4: Press Right Arrow button to pair remote and light.
- Step 5: Turn light off then back on. It will now only be controlled with that specific remote.
- Step 6: To unpair, follow steps 1-3, then press Left Arrow button to unpair.

NOTE: In case you lose paired remote, any remote can be used to unpair fixtures.