

Model PD 490 TYPICAL SPECIFICATION

Four Manual Moving Drawknob Console

PEDAL		GREAT		SWELL
1 Open Wood	32	1 Double Diapason	16	1 Bourdon 16
2 Contra Bourdon	32	2 Gedeckt	16	2 Violoncello 16
3 Contra Violone	32	3 Principal I	8	3 Geigen Diapason 8
4 Open Diapason	16	4 Principal II	8	4 Lieblich Gedeckt 8
5 Bourdon	16	5 Claribel Flute	8	5 Viola di Gamba 8
6 Lieblich Gedeckt	16	6 Bourdon	8	6 Voix Celeste 8
7 Violone	16	7 Salicional	8	7 Unda Maris II 8
8 Octave	8	8 Octave	4	8 Principal 4
9 Bass Flute	8	9 Chimney Flute	4	9 Traverse Flute 4
10 Dulciana	8	10 Twelfth	2-2/3	10 Violina Celeste II 4
11 Choral Bass	4	11 Fifteenth	2	11 Nazard 2-2/3
12 Flute	4	12 Seventeenth	1-3/5	12 Fifteenth 2
13 Mixture	IV	13 Mixture	III	13 Flautino 2
14 Bombarde	32	14 Cymbel	III	14 Tierce 1-3/5
15 Trombone	16	15 Posaune	16	15 Plein Jeu IV
16 Fagotto	16	16 Tromba	8	16 Double Trumpet 16
17 Trumpet	8	17 Octave Tromba	4	17 Trumpet 8
18 Clarion	4	(i) Tremulant		18 Oboe 8
(i) Great to Peda	=	(ii) Swell to Great		19 Vox Humana 8
(ii) Swell to Pedal		(iii) Choir to Great		20 Clarion 4
(iii) Choir to Pedal		(iv) Solo to Great		(i) Tremulant
(iv) Solo to Pedal		(v) Great & Pedal on		(ii) Solo to Swell
(v) Auto Pedal		Choir Expression		(iii) MIDI to Swell
(vi) Great & Pedal Pistons		(vi) MIDI to Great		(44) 4.522 4 4 5 1.445
Coupled		(,)		CHOIR
(vii) MIDI to Peda	nl	SOLO		1 Principal 8
(11) 111121 00 1 000	••	1 Harmonic Flute	8	2 Bourdon 8
ACCESSORIES		2 Violoncello	8	3 Dolce Flute 8
Expression Pedal to the Swell organ		3 Cello Celeste	8	4 Flute Celeste 8
Expression Pedal to the Choir organ		4 Concert Flute	4	5 Gemshorn 8
Expression Pedal to the Solo organ		5 Harmonic Piccolo	2	6 Gemshorn Celeste 8
Crescendo Pedal Transposer +3/-3		6 Mounted Cornet	V	7 Prestant 4
Fine Tune		7 Corno di Bassetto	16	8 Koppelflote 4
Capture lock switch		8 French Horn	8	9 Quintflote 2-2/3
Pedal light		9 English Horn	8	10 Blockflote 2
TECHNICAL DATA		10 Orchestral Oboe	8	11 Terz 1-3/5
Manuals: 3x61 notes		11 Tuba	16	12 Larigot 1-1/3
Pedals: 32 note AGO		12 Tuba Mirabilis	8	13 Sifflote 1
Audio: 20 audio channe		13 Octave Tuba	4	14 Scharf III
	ifiers or euivalent	14 Trompette en Chamade	16	15 Cor Anglais 16
Total: 4,180 W a Input: 2 channel socke		15 Trompette en Chamade		16 Clarinet 8
Midi: In, Out, Thru		16 Trompette en Chamade		17 Krummhorn 8
Headphones socket		(i) Tremulant	·	18 Harmonic Trumpet 8
		(ii) MIDI to Solo		19 Chimes
		() = ====		(i) Tremulant
				(ii) Swell to Choir
				(iii) MIDI to Choir
				()

COMBINATION ACTION

- 8 Thumb pistons to the Swell organ
- 8 Thumb pistons to the Great organ
- 8 Thumb pistons to the Choir organ
- 6 Thumb pistons to the Solo organ
- 12 General thumb pistons
- 12 General toe pistons
- 8 Toe pistons to the Pedal
- 1 rev. thumb piston Swell to Great 1 rev. thumb piston Choir to Great
- 1 rev. thumb piston Swell to Pedal
- 1 rev. thumb piston Great to Pedal
- 1 rev. thumb piston Choir to Pedal
- 1 rev. thumb piston Swell to Choir
- 1 rev. thumb piston Solo to Great
- 1 rev. thumb piston Solo to Swell
- 1 rev. thumb piston Solo to Pedal
- 1 rev. thumb piston Solo to Choir 1 rev. thumb piston Sforzando

- 1 thumb piston General Cancel
- 1 thumb piston Set
- 1 rev. toe piston Swell to Great
- 1 rev. toe piston Choir to Great
- 1 rev. toe piston Solo to Great
- 1 rev. toe Piston Great to Pedal
- 1 rev. toe Piston Swell to Pedal
- 1 rev. toe piston Choir to Pedal
- 1 rev. toe piston Sforzando
- 1 rev. toe piston Zimbelstern