

VERSION HISTORY

Version	Date	Revision
1.0.0	April 30, 2026	Created

Module	Module Key	Group	Group ID	Description
Sentiface	0x1XXX	Timings	0x00	Defines parameters for measurements and transmission behavior
Sentiface	0x1XXX	Alarms and thresholds	0x01	Defines alarms and limit values, such as upper and lower temperature limits
Sentiface	0x1XXX	Settings for opening detection	0x02	Defines measurement thresholds for triggering the alarm for temperature and relative humidity
Sentiface	0x1XXX	Settings for tilt detection	0x03	Defines the behavior of the accelerometer

Tables for cross-product modules (Senticom/Sentivisor) can be found in the [Generic NFC and Downlink documentation](#).

For more information on configuring sensor communication, refer to the respective [mioty®](#) documentation depending on the version.

Instructions valid for versions:

ITEM CODE	IFM ARTICLE CODE	FEATURES
S-JUNO-IX-MIOTY-TH	ZJF 201	INDUSTRIAL JUNO IP67 TH Sensor, Temperature and Relative Humidity with Tilt Detection and Door Open Detection mioty

SENTIFACE: GROUP TIMINGS 0x00								
Resources	Resource ID	Description	Key (NFC/BLE)	Min	Max	Factory setting	Unit	Module key
MEASUREMENT PERIOD	0x00	Specifies the interval at which measurements are taken. 5 minutes means that the sensor takes a measurement every 5 minutes.	period	1	360	30	min	1111
REGULAR TRANSMISSION INTERVAL	0x01	Number of measurements performed prior to transmission.	every	1	64	6		1111

SENTIFACE: GROUP ALARM SETTINGS 0x01								
Resources	Resource ID	Description	Key (NFC/BLE)	Min	Max	Factory setting	Unit	Module key
ALARM ACTIVE	0x00	Indicates which alarms, whether for temperature or relative humidity, are active: 0: Both alarms deactivated 1: Temperature alarm active 2: Relative humidity alarm active 3: Both alarms active	aact	0	3	1		1111
TEMPERATURE DELTA	0x01	Specifies the absolute change in temperature compared to the last transmission that must occur to trigger an ALARM transmission. This transmission is performed independently of the normal transmission interval.	tdt	1	50	5	°C	1111
UPPER TEMPERATURE LIMIT	0x02	Specifies the upper absolute limit at which an alarm is triggered.	tht	0	85	40	°C	1111
TEMPERATURE BELOW LIMIT	0x03	Specifies the lower absolute limit at which an alarm is triggered.	tlt	-25	75	0	°C	1111
RELATIVE HUMIDITY DELTA	0x04	Specifies the absolute change in relative humidity compared to the last transmission that must occur in order to trigger an ALARM- transmission. This transmission is performed independently of the normal	hdt	1	80	20	%RH	1111

		transmission interval (for sample versions, 0x05 and higher were used here).						
RELATIVE HUMIDITY UPPER LIMIT	0x05	Specifies the upper absolute limit at which an alarm is triggered.	hht	5	100	80	%RH	1111
RELATIVE HUMIDITY BELOW THRESHOLD	0x06	Specifies the lower absolute limit at which an alarm is triggered.	hlt	0	95	20	%RH	1111
TEMPERATURE HYSTERESIS	0x07	Determines the absolute hysteresis in °C during state changes. If the temperature falls below or exceeds a threshold value minus the hysteresis, the system switches from a higher to a lower alarm state.	thy	2	0	10	°C	1111
HYSTERESIS REL. HUMIDITY	0x08	Determines the absolute hysteresis in %RH during state changes. If the relative humidity falls below or exceeds a threshold value minus the hysteresis, the system switches from a higher to a lower alarm state.	hhy	5	0	30	%RH	1111

SENTIFACE: OPENING DETECTION GROUP 0x02								
Property	Property ID	Description	Key (NFC/BLE)	Min	Max	Default	Unit	Module Key
OPENING COOLDOWN	0x00	Specifies a time period during which, after an opening has been triggered, another opening cannot be triggered (de-bounces the openings). The last counted opening.	acool	0	600	0	sec	1111
OPENING TIME ALARM	0x01	Specifies how long the lid must remain open before an alarm is triggered (0 = immediate alarm).	oaaf	0	2880	0	sec	1111
OPENING MODE	0x02	Describes which direction the sensor faces when it is closed and which angles are set for opening detection. "Face up" describes the state when the sensor is lying on the table and facing upward toward the ceiling. Settings from 0 to 7 with accelerometer, 8 and 9 with Hall sensor: • 0: off • 1: Ultra Low Power. Fixed threshold 50°. Closed when facing down (Face Down). • 2: Ultra Low Power. Fixed threshold 50°. Closed when facing up (Face Up). • 3: Ultra Low Power. Fixed threshold 50°. Closed when facing sideways.	opmo	0	8	1		1111

		• 4: Advanced tilt sensing. Adjustable threshold. Closed when facing down (Face Down). • 5: Advanced tilt sensing. Adjustable threshold. Closes when facing up (Face Up). • 6: Advanced tilt sensing. Adjustable threshold. Closes when facing sideways. • 7: Advanced tilt sensing. Adjustable threshold. Automatic calibration of the closed orientation. • 8: Container is closed when the magnet is in contact. • 9: Container is open when magnet is present.						
--	--	---	--	--	--	--	--	--

SENTIFACE: ADVANCED TILT SETTINGS GROUP 0x03								
Property	Property ID	Description	Key (NFC/BLE)	Min	Max	Default	Unit	Module Key
SAMPLING PERIOD	0x00	Specifies how often the accelerometer determines the angle. The higher the frequency, the higher the power consumption.	tspe	2	600	2	s	1111
TRIGGER LEVEL	0x01	Specifies the angle at which an opening is detected or an alarm is triggered.	ttle	5	180	20	°	1111
TRIGGER HYSTERESIS	0x02	Hysteresis value for the opening angle	tthy	1	90	4	°	1111

Example downlinks:

Setting	Downlink
period = 10	00 11 11 00 00 00 00 00 0A
every = 5	00 11 11 00 01 00 00 00 05
alarm_act = 0	00 11 11 01 00 00 00 00 00