

Pump room start-up

Close valve V-12 before entering the pump room.
Check that the pressure gauge reads below 2 bar.

- Start pump P-2 from the local panel.



Figure 1: Valve V-12, closed.

Torque table

Bolt	Torque	Unit
M8	25	N·m
M10		N·m

Torque with a calibrated wrench.