


Half of these resistors, i.e. the ones marked with 'DNI', can be removed. Only 16 resistors are needed in order to select the default boot mode. The button above is used to choose an optional SD card boot mode.

User LEDs


GND



Micro SD card slot



JTAG Header



Only connect EMU2, EMU3 and EMU4 if you plan to use advanced JTAG features (HS-RTDX, Core Trace, System Trace, etc) of higher end debuggers:

- http://processors.wiki.ti.com/index.php/JTAG_Connectors
- http://processors.wiki.ti.com/index.php/XDS_Target_Connection_Guide



	Octavo Sy	stems LLC.		
	OSD3358-SM-RED Platform			
	3/25/2019 4:25 PM			
	Sheet:	5/12	Rev 3	
7			Q	

