

1. Common Issues with USB Keyboard or Mouse

Issue	Possible Solution
1. Device is not detected	Disconnect and reconnect the USB device or try another USB port.
2. Keyboard/Mouse is not responding	Restart the laptop and check the device again.
3. USB driver problem	Update or reinstall the driver through Device Manager.
4. Mouse/Keyboard works intermittently	Try a different USB port and check the USB cable for damage.
5. Device is disabled	Open Device Manager and enable the keyboard/mouse device.

2. Bluetooth Headphones Not Connecting to Phone

Step-by-Step Troubleshooting

1. Check Bluetooth: Open phone Settings → Bluetooth and make sure Bluetooth is ON.
2. Check headphones: Make sure the headphones are powered ON and have enough battery.
3. Enable Pairing Mode: Put the headphones into Bluetooth pairing mode and check for a blinking indicator.
4. Check Available Devices: Look for the headphone name under available Bluetooth devices.
5. Forget Old Connection: If the headphones are already listed, select them and choose Forget/Unpair.
6. Pair Again: Search for the headphones and select their name to connect.
7. Check Distance: Keep the headphones close to the phone and remove possible interference.
8. Restart: Turn Bluetooth OFF and ON, then restart both the phone and headphones if necessary.
9. Test: Play audio and check whether the headphones are selected as the audio output.
10. Reset Headphones: If they still do not connect, reset the headphones according to their manufacturer's instructions.

3. External Webcam Not Detected in Zoom on Windows 10

1. Check USB Connection: Make sure the webcam is properly connected and try another USB port.
2. Check Device Manager: Open Device Manager → Cameras/Imaging Devices and check whether the webcam is detected. Update the driver if necessary.

3. Check Windows Privacy Settings: Go to Settings → Privacy → Camera and allow camera access.
4. Allow App Access: Make sure Allow apps to access your camera is enabled.
5. Check Zoom Camera Settings: Open Zoom → Settings → Video and select the correct external webcam.
6. Restart and Test: Close Zoom, restart the computer, reconnect the webcam, and test it using the Windows Camera app.

4. Printer Showing "Offline" – Windows Troubleshooter

Steps to Troubleshoot

1. Open Settings on the Windows PC.
2. Go to Devices → Printers & scanners.
3. Select the printer that is showing Offline.
4. Click Manage and check the printer status.
5. Run the available Printer Troubleshooter.
6. Follow the instructions shown by Windows.
7. The troubleshooter checks common problems such as printer connection, driver issues, printer status, and related settings.
8. Apply the recommended fixes.
9. Restart the printer and computer if required.
10. Print a test page to confirm that the problem has been fixed.

Information Provided by the Troubleshooter

The troubleshooter can identify and report problems such as:

- Printer not connected properly.
- Printer driver problems.
- Printer being offline or unavailable.
- Incorrect printer settings.
- Communication problems between the PC and printer.