

Upgrade of the Firewire driver for the camera

Contents

1.	Firewire driver version information	2
2.	Installation instructions	3
2.1.	Operating Systems.....	3
2.1.1.	Windows 98 Second Edition	3
2.1.2.	Windows ME.....	3
2.1.3.	Windows 2000.....	4
2.1.4.	Windows XP	4
3.	Troubleshooting	5
3.1.	Windows XP & 2000 Driver loading/unloading rights.....	5



Version 1.1

1. Firewire driver version information

Version 5.20.2600.911

12 March 2003

- Support multiple cameras on the same firewire bus.
- Support more video formats for A20 cameras.
- Fixed a crash when the camera was connected at PC-bootup.
- Fixed the image out of sync on some laptops.
- Fixed the constant flickering on some laptops.

2. Installation instructions

Make sure that the camera is connected to your computer, using firewire, before you start the upgrade!

2.1. Operating Systems

2.1.1. Windows 98 Second Edition

1. Select the "My Computer" icon on the desktop and right click on it and select "Properties".
2. Select the "Device Manager" sheet.
3. Select the "Imaging devices" node and open it by double click on it.
4. Select the "FLIR ThermoCAM" driver.
5. Press the "Properties" button.
6. Select the "Driver" sheet.
7. Start the "Update Device Driver Wizard" by pressing the "Update Driver" button.
8. Press the "Next" button.
9. Select "Display a list of all the drivers..."
10. Press the "Next" button.
11. Press the "Have Disk" button.
12. Press the "Browse" button and browse to the directory containing the driver file and press the "OK" button.
13. Press the "OK" button in the "Install from Disk" dialog.

2.1.2. Windows ME

1. Select the "My Computer" icon on the desktop and right click on it and select "Properties".
2. Select the "Device Manager" sheet.
3. Select the "Imaging devices" node and open it by double click on it.
4. Select the "FLIR ThermoCAM" driver.
5. Press the "Properties" button.
6. Select the "Driver" sheet.
7. Start the "Update Device Driver Wizard" by pressing the "Update Driver" button.
8. Select "Specify the location..."
9. Press the "Next" button.
10. Select "Display a list of all the drivers..."
11. Press the "Next" button.
12. Press the "Have Disk" button.
13. Press the "Browse" button and browse to the directory containing the driver file and press the "OK" button.
14. Press the "OK" button in the "Install from Disk" dialog.

2.1.3. Windows 2000

You need to log in as administrator (or as as user with administrator rights) to be able to install the driver.

1. Select the "My Computer" icon on the desktop and right click on it and select "Properties".
2. Select the "Hardware" sheet.
3. Press the "Device Manager..." button.
4. Select the "Imaging devices" node and open it by by double click on it.
5. Select the "FLIR ThermoCAM" driver.
6. Press the "Properties" button.
7. Select the "Driver" sheet.
8. Start the "Update Device Driver Wizard" by pressing the "Update Driver" button.
9. Press the "Next" button.
10. Select "Display a list of all the known drivers...".
11. Press the "Next" button.
12. Press the "Have Disk" button.
13. Press the "Browse" button and browse to the directory containing the driver file and press the "Open" button.
14. Press the "OK" button in the "Install from Disk" dialog.

2.1.4. Windows XP

You need to log in as administrator (or as as user with administrator rights) to be able to install the driver.

1. Open the Control Panel by selecting Start Menu -> Settings -> Control Panel.
2. Double click on "System"
3. Select the "Hardware sheet"
4. Press the "Device Manager" button.
5. Select the "Imaging devices" node and open it by by double click on it.
6. Select the "FLIR ThermoCAM" driver and right click on it and choose "Update Driver" to start the "Hardware Update Wizard"
7. Select "Install from a list or specific..."
8. Press the "Next" button
9. Select "Don't search. I will choose..."
10. Press the "Next" button.
11. Press the "Have Disk" button.."
12. Press the "Browse" button and browse to the directory containing the driver file and press the "Open" button.
13. Press the "OK" button in the "Install from Disk" dialog.

3. Troubleshooting

3.1. Windows XP & 2000 Driver loading/unloading rights

On Windows 2000/XP, only administrators and users with appropriate rights may load/unload device drivers. To enable users to connect to the camera, you should *either* give them Local Administrator Rights or change the Local Security Policy.

To give a user local administrator rights:

You need to be logged in as administrator (or as as user with administrator rights)

1. Open the Control Panel by selecting Start Menu -> Settings -> Control Panel.
2. Double click on "Administrative Tools".
3. Double click on "Computer Management".
4. Open "Local Users And Groups" by double clicking on it.
5. Select "Groups" and double-click on Administrators.
6. Add the relevant users, or the name of a group containing the right users.

To give a user rights to load/unload device drivers:

You need to be logged in as administrator (or as as user with administrator rights)

1. Open the Control Panel by selecting Start Menu -> Settings -> Control Panel.
2. Double click on "Administrative Tools".
3. Double click on "Local Security Policy".
4. Open "Local Policies" by double clicking on it.
5. Select "User Rights Assignment".
6. Find "Load and unload Device Drivers" and double-click on it.
7. Add the relevant users, or the name of a group containing the right users.