



GTC4Lusso USA - Checking the injection and ignition system pipes and connections - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.
Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.18 Checking the injection and ignition system pipes and connections

Checking injection and ignition system pipes and connections

- Remove the flat undertray sections ( E3.13).
- Remove the engine compartment cosmetic shields ( E3.14).
- Check the state of the connection pipes between the fuel tank and the high pressure pump, and of the fuel rail on the intake manifold.
- If any leakage is found, replace the pipes and check the system.
- Check the state of the cables and connectors for the ECUs and the coils.
- Replace the cables if any damaged cables or connectors are found.
- In the event of malfunction, check the spark plugs. Replace the spark plugs at the intervals indicated in the maintenance schedule.
- Refit the engine compartment cosmetic shields ( E3.14).
- Refit the flat undertray sections ( E3.13).