



GTC4Lusso USA - Checking exhaust emissions - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.20 Checking exhaust emissions

Exhaust gas analysis

- **TEST DRIVE (details of procedure):**
- Preferably test drive the vehicle after it has been left unused overnight. The difference between the engine temperature and ambient temperature on starting must be between 3°C and 37.5°C, and the fuel level must be between 15% and 85%.
- Self-adaptive parameters must be reset (simply cancel errors to reset).
- **TEST DRIVE procedure:**
- With the engine cold, start the engine and leave to idle for 4 minutes without accelerating.
- Drive the vehicle normally for approximately 6 Km at constant speed, in 3rd or 4th gear with an engine speed between 2,000 and 2,500 rpm, and without accelerating suddenly or changing gear too frequently.
- Accelerate gradually to 6,000 rpm, then slow to an engine speed of 2,000 rpm. Repeat eight times.
- Stop the vehicle, leave the engine idling for 5 minutes, then switch off the engine.
- Wait at least 15 minutes.
- Start the engine and drive the vehicle normally for at least 20 minutes with accelerating suddenly or changing gear too frequently.
- **EXHAUST GAS ANALYSIS (details of procedure)**
- Remove the engine compartment cosmetic shields ( E3.14).
-  Remove the cosmetic inspection shields.
- Connect the DEIS tester to the diagnostic socket ( F2.09).
-  Perform the cycle "**170 NCM Exhaust gas test**" with the DEIS Diagnostic Tester.



- Perform test at the outlet ports of the cylinder head in the following conditions: engine temperature above 90°C, engine at idle speed and A/C system ON.
- Check CO, HC, CO₂ and O₂ levels by connecting the tester to the unions on the connector pipes for the exhaust manifold, after removing the two nuts (1).
- If the values are not within the specified limits, see the most recent Technical Information relative to the "Engine Fault Check List".
- After completing the procedure, tighten the two nuts (1).

➤ Refit the engine compartment cosmetic shields (🔧 E3.14).