



GTC4Lusso USA - Checking service brake/parking brake function - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.22 Checking service brake/parking brake function

Checking service brake/parking brake function

➤ Remove the flat undertray sections ( E3.13).

 Remove the rear flat undertray section.

- Check the brake pedal travel and **STOP** light switch function.
- Road test the vehicle to check braking performance.
- Check electric parking brake operation and the state of the parking brake cables.

➤ Refit the flat undertray sections ( E3.13).

 Refit the rear flat undertray section.