



GTC4Lusso USA - Checking wheels and tyres - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.28 Checking wheels and tyres

Checking wheels and tyres



CAUTION

Tyre replacement is recommend after 4 years of normal use. Frequent use in maximum load conditions and at high temperatures may lead to premature deterioration.

- Remove the wheels from the vehicle, then check the state of the wheel rims and tyres.
- Check that the tyre pressure matches the value specified
- Check the location and fastening of the balancer weights on the inside of the wheel rims.
- In case of excessive tyre wear, check the wheel alignment data and perform static and dynamic wheel balancing