



GTC4Lusso USA - Inspecting the air conditioning and heating system - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.29 Inspecting the air conditioning and heating system

Inspecting the air conditioning and heating system

- Remove the engine compartment cosmetic shields ( E3.14).
- Remove the front bumper ( E3.03).
- Remove the flat undertray sections ( E3.13).
 -  Remove the central flat undertray section.
- Check the unions on the pipes leading to the condenser, the dehydrator filter, the evaporator and compressor for gas leakage.
- Check for gas leakages from the system hoses.
- Check for refrigerant leakages from the recirculation pump, the evaporator or the oil-water pump.
- Refit the flat undertray sections ( E3.13).
 -  Refit the front and central flat undertray sections.
- Refit the front bumper ( E3.03).
- Refit the engine compartment cosmetic shields ( E3.14).