



GTC4Lusso USA - Checking and lubricating hinges and adjusters - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

A3.32 Checking and lubricating hinges and adjusters

Checking and lubricating hinges and adjusters

- Check that the hinges of the doors, of the engine compartment lid and of luggage compartment are correctly secured, exhibit no free play and operate quietly.
- Check that the door locks and the locking mechanisms of the engine compartment lid and luggage compartment function correctly.
- Check the state of the engine compartment lid and fuel filler flap release cables.
- Check that the gas struts of the engine compartment and luggage compartment lids function correctly.
- Lubricate all friction surfaces with lithium based waterproof grease.