



GTC4Lusso USA - Draining the engine fuel system - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

B3.08 Draining the engine fuel system

Draining the engine fuel system



CAUTION

Fuel is highly flammable.
NEVER WORK ON A HOT ENGINE.

- To drain the fuel system, aspirate the fuel using an aspirator pump compliant with applicable **EEC regulations** and a suitable piece of flexible hose at least **2.5 metres** long and with a maximum diameter of **10 mm**.
- Connect pipe correctly to the aspirator pump.



Only use the funnel included, which releases the Capless automatic locking system correctly.

- Select the fuel filler funnel from the tool kit.
- Insert the funnel into the fuel filler neck.
- The funnel releases the capless automatic sealing system.

**CAUTION**

Collect the fuel in a suitable container.

- Feed the pipe through the funnel to reach the bottom of the fuel tank.
- Aspirate the fuel with the aspirator pump.
- Check the remaining fuel level from the instrument panel and repeat the procedure to aspirate any remaining fuel from the tank if necessary.