



GTC4Lusso USA - Steering wheel - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.
Copyright by Ferrari S.p.A. - P.IVA 00159560366

D5.06 Steering wheel

Removing the steering wheel

- Disconnect the battery (🔧 F2.01).
- Remove the driver side airbag module (🔧 F4.02).



- Detach the connector pin (1) from the relative seat.
- Disconnect the connector (1).
- Undo the indicated screw.

- Remove the steering wheel and secure the clock spring connector in place by fitting and tightening a cable tie.

Refitting the steering wheel

			
Tightening torque		Nm	Class
Fastening steering wheel to steering column	Screw	80 Nm	B

- Release the clock spring connector and fit the steering wheel.



- Refit the driver side airbag module (🔧 F4.02).
- Connect the battery (🔧 F2.01).

- Tighten the indicated screw.

Tightening torque	Nm	Class
Screw	80 Nm	B

- Connect the connector (1).
- Refit the connector (1) in the relative seat.