



GTC4Lusso USA - Tightening torques - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

E1.01 Tightening torques



Tightening torque		Nm	Class
Fastening engine compartment cosmetic shields	Screw	4 Nm	B
	Screw	4.5 Nm	B
Fastening flat undertray elements	Screw	7 Nm	B
	Screw / Nut	8 Nm	B
Fastening the drain pipes	Screw collar	4 Nm	B
Fastening front bumper	Screw	7 Nm	B
	Screw	6 Nm	B
Fastening front wheelhouse	Screw	7 Nm	B
Fastening rear wheelhouse	Screw	7 Nm	C
Fastening rear bumper	Screw	7 Nm	B
	Nut	7 Nm	B
	Screw	5 Nm	B
Fastening front removable subframe	Screw (pre-tightening)	20 Nm	B
	Screw	60 Nm	B
	Screw	110 Nm	B
Fastening the power steering fluid reservoir bracket	Screw	9 Nm	B
Fastening the front seats	Screw	40 Nm	B
Fastening door tie-rods	Screw	23 Nm	B
Fastening door tie-rods	Screw	23 Nm	B
Fastening door striker plates	Screw	0.8 Nm	B
	Screw	24 Nm	B
	Screw	30 Nm	B
Fastening the sill trim panel	Screw	7 Nm	B
Fastening the footrest mat	Screw	9 Nm	B



Tightening torque		Nm	Class
Fastening the engine compartment cross-member	Screw	30 Nm	B
	Screw	65 Nm	B
Fastening the tilting central backrest	Screw	25 Nm	B
	Nut	25 Nm	B
	Screw	30 Nm	B
Fastening rear seats	Screw	25 Nm	B
Fastening the centre console trim panel	Nut	4 Nm	B
	Screw	4 Nm	B
	Screw	5 Nm	B
	Screw	8 Nm	B
	Screw	9 Nm	B
Fastening lower central instrument panel	Screw	3 Nm	B
Fastening complete glove compartment	Screw	3 Nm	B
	Nut	3 Nm	B
Fastening lower right dashboard trim panel	Screw	4 Nm	B
Fastening Body computer trim	Screw	4 Nm	B
Fastening underdashboard trim panels	Screw	3 Nm	B
Fastening lower left dashboard trim panel	Screw	3 Nm	B
Fastening lateral front passenger compartment trim panels	Screw	4 Nm	B
Fastening lower brackets for front seat belts	Screw	40 Nm	B
Fastening lateral rear passenger compartment trim panel	Screw	4 Nm	B
Fastening rear seat striker trim	Screw	4 Nm	B
Fastening centre panel of lateral rear passenger compartment trim	Screw	4 Nm	B
Fastening upper left dashboard trim panel	Screw	3 Nm	B
Fastening luggage rear compartment pillar trim	Screw	4 Nm	B
Fastening lateral rear luggage compartment trim	Screw	4 Nm	B
	Screw	9 Nm	B
	Screw	5 Nm	B
Fastening seat handles on lateral rear trim panels of luggage compartment	Screw	4 Nm	B
Fastening inner luggage compartment sill protector hooks	Screw	10 Nm	B
Fastening lower luggage compartment trim panel	Screw	4 Nm	B
Fastening upper luggage compartment trim panel	Screw	4 Nm	B
Fastening luggage compartment luggage shelf trim hooks	Screw	10 Nm	B
Fastening upper headliner trim	Screw	4 Nm	B



Tightening torque		Nm	Class
Fastening front ceiling cross member trim panel	Screw	4 Nm	B
Fastening fixed sun visor mount	Screw	2.6 Nm	B
Fastening A-pillar trim	Screw	4 Nm	B
Fastening rear headliner trim	Screw	4 Nm	B
	Nut	4 Nm	B
Fastening rear ceiling handle	Screw	9 Nm	B
Fastening sun visor	Screw	2.6 Nm	B
Fastening underwindscreen cosmetic shields	Screw	4 Nm	B
Fastening door panel	Screw	5 Nm	B
	Screw	5 Nm	B
	Screw	6 Nm	B
Fastening inner trim to door panel	Screw	3 Nm	B
Fastening internal door release handle to door panel	Screw	9 Nm	B
Fastening door pull to door panel	Screw	8 Nm	B
Fastening upper right dashboard trim panel	Screw	4 Nm	B
	Screw	3 Nm	B
Fastening door lock	Screw	9.5 Nm	B
Fastening upper front bumper cross member	Screw	30 Nm	B
Fastening dashboard	Screw	40 Nm	B
	Screw	4 Nm	B
	Screw	9 Nm	B
	Screw	34 Nm	B
	Screw	9 Nm	B
	Screw (pre-tightening)	25 Nm	B
Fastening air ducts on centre tunnel console	Screw	4 Nm	B
	Nut	4 Nm	B
Fastening accelerator pedal plate	Screw	8 Nm	B
Fastening passenger compartment air intake	Screw	4 Nm	B
Fastening the inertia switch shield	Screw	5 Nm	B
Fastening driver side footrest	Screw	8 Nm	B
Fastening windscreen washer/headlight washer fluid tank	Screw	7 Nm	B
Fastening parking sensor buzzer	Screw	4 Nm	B
Fastening the engine compartment diagonal braces	Screw	34 Nm	B
Fastening the door windows	Screw	9 Nm	B
Fastening the power window units	Nut	9 Nm	B
	Nut	9.5 Nm	B
Fastening door lock Bowden cable mounting brackets	Nut	4 Nm	B



Tightening torque		Nm	Class
Fastening door lock latch	Nut	2 Nm	B
Fastening internal body of external door handle	Nut	5 Nm	B
Fastening buffer on inner body of external door handle	Buffer	5 Nm	B
Fastening external body of external door handle	Screw	3.5 Nm	B
Fastening external window scraper seal	Screw	2 Nm	B
Fastening the dashboard substructure trim panel	Screw	4 Nm	B
Fastening upper dashboard trim panel	Screw	3 Nm	B
Fastening fuel filler flap hinge	Screw	4 Nm	C
Fastening the passenger compartment air intake	Screw	4.5 Nm	B
Fastening speakers	Screw	4 Nm	A
Fastening amplifier	Screw	9 Nm	B
Fastening the amplifier (Hi-Fi version)	Screw	4 Nm	A
Fastening tweeters	Screw	4 Nm	B
Fastening gearbox control panel	Screw	5 Nm	B
Fastening instrument panel	Screw	3 Nm	B
Fastening DVD player and TV node mounting bracket	Screw	4 Nm	B
Fastening TV node	Nut	4 Nm	B
Fastening AM/FM amplifier	Screw	4 Nm	B
Fastening TV amplifier	Screw	4 Nm	B
Fastening shift paddle assembly	Screw	4 Nm	A
Fastening ignition switch	Screw	7 Nm	B
Fastening external rear view mirror	Screw	9 Nm	B
Fastening NIT to bracket	Screw	4 Nm	B
Fastening bracket complete with NIT to upper left hand dashboard trim	Screw	3 Nm	B
	Screw	4 Nm	B
Fastening luggage compartment lid lock	Screw	8 Nm	B
Fastening engine compartment lid lock	Nut	9 Nm	B
Fastening luggage compartment lid striker plate	Screw (pretightening)	0.4 Nm	B
	Screw	8 Nm	B
Fastening twiddlers	Screw	4 Nm	B
Fastening inertia switch to bodyshell	Screw	5 Nm	B
Fastening main shell	Screw	1.08 Nm	0
Fastening NVO circuit board	Screw	0.32 Nm	0
Fastening Manettino toggle	Dowel	0.74 Nm	0
Fastening Manettino selector dial	Screw	0.32 Nm	0
Fastening main base	Screw	0.27 Nm	0
Fastening high beam - windscreen wiper switch	Screw	0.27 Nm	0
Fastening turn indicator switch	Screw	0.75 Nm	0
Fastening Manettino selector dial screw ring	Ring nut	1.48 Nm	0

			
Tightening torque		Nm	Class
Fastening gear motor	Screw	4.5 Nm	B