



GTC4Lusso USA - Seat controls - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

E5.11 Seat controls

Seat adjustment controls



Never adjust the seat position while driving, as this may cause loss of control of the vehicle.



Do not operate the electric seat adjustment controls while the backrest is tipped.

After opening one of the doors with the vehicle in KEY OFF state, the seat may still be adjusted within a limited period of time (approximately 15 seconds).

The seat may be adjusted again for a brief period each time one of the doors is opened or both of the doors are closed with the vehicle in KEY OFF state.

- Adjusting the backward/forward position, height and tilt angle of the seat cushion

Push the control **(A)** forwards or backwards, as indicated by the arrows on the control itself, to adjust the forward/backward position of the seat.

Push the control **(A)** downwards or upwards, as indicated by the arrows on the control itself, to adjust the height or tilt angle of the seat.

- Adjusting backrest inclination

Turn the control **(B)** forwards or backwards, as indicated by the arrows on the control itself, to adjust the inclination of the seat backrest.

- Lumbar support adjustment

Push the control **(C)** forwards, backwards, upwards or downwards, as indicated by the arrows on the control itself, to adjust the backrest lumbar support.

- Pneumatic side bolster width adjustment

Push the control **(D)** as indicated by the arrows on the control itself, to adjust the width of the lateral backrest and cushion sides.

- Heating

Press **(E)** to activate the seat heating function.

Use the control or the virtual buttons in the **COMFORT** screen to select the heating function level from the 3 levels available.

Driving positions



Use the three buttons **(F)** as described as follows to memorise or recall up to three different driving positions (function only enabled in key-on state):

- to memorise a driving position setting, adjust the seat, steering wheel and external rear view mirrors as desired using the respective controls, then press and hold any one of the three buttons **(F)** (each button corresponds to one memorisable position) for at least three seconds, until a double beep sounds to confirm that the setting has been saved. Adding a new driving position setting to the memory automatically replaces the setting assigned previously with the same button.
- to recall a memorised driving position, press the relative button **(F)** and release within three seconds.

Driving position selection may not be recalled while the vehicle is in motion.

The movements begin once one of the buttons **(F)** is released.

After releasing one of the buttons (**F**), if the vehicle starts to move before the seat, steering wheel and external rear view mirrors have reached their respective memory positions, they will continue moving until the selected positions are reached.

Pressing any of the seat adjustment control buttons or memory buttons immediately arrests the automatic function in progress (e.g. memory recall, driver seat easy entry/exit function or rear seat easy entry function).

- Ventilation (Full Electric option)

The seat ventilation function is selectable from the **COMFORT** screen of the Infotainment System.

- Tipping the backrest



Do not operate the electric seat adjustment controls while the backrest is tipped.

Pull the handle (**G**) while pushing the backrest forwards to tip the seat backrest forwards. When the backrest is tilted, the front seat automatically lowers and moves forward fully. The seat returns to its original position when the backrest is tipped back again.