



GTC4Lusso USA - Tightening torques - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

F1.01 Tightening torques

			
Tightening torque		Nm	Class
Fastening high pressure fuel pump	Screw (pretightening)	5 Nm	B
	Screw	10 Nm	B
Fastening the high pressure GDI fuel pipes	Union	23 +1 Nm -1	0
Fastening low pressure fuel pipe to high pressure fuel pumps	Union	20 +2 Nm -0	0
Fastening the rubber-lined bracket holding the high pressure GDI fuel pipe	Screw	8 Nm	A
Fastening ECUs	Screw	9 Nm	B
Fastening ionising ECUs	Screw	9 Nm	B
Fastening TPMS ECU	Nut	3 Nm	B
Fastening the power steering ECU	Nut	4 Nm	B
Fastening the shock absorber control ECU	Screw	3 Nm	B
Fastening engine services cable to battery terminal block	Nut	11 Nm	B
Fastening alternator bushings to engine	Bushing	10 Nm	B
Fastening alternator - engine	Screw (pre-tightening)	5 Nm	B
	Screw	49 Nm	B
Fastening heat shield - starter motor	Screw	10 Nm	B
	Nut	10 Nm	B
Fastening starter motor to transmission housing	Screw	25 Nm	A
Fastening starter motor mounting bracket	Screw	10 Nm	B
	Screw	25 Nm	B



Tightening torque		Nm	Class
Fastening horn mounting bracket	Screw	12 Nm	B
Fastening windscreen wiper linkage	Screw	9 Nm	B
Fastening taillight	Nut	5 Nm	B
Fastening headlight	Screw	8 Nm	B
Fastening battery bracket to tie-rods	Nut	6 Nm	B
Fastening bracket to terminal block	Screw	1.2 Nm	B
Fastening positive terminal clamp	Nut	4.5 Nm	C
Fastening windscreen wiper arms	Nut	25 Nm	B
	Nut	9 Nm	B
Fastening engine services cable	Nut	14 Nm	A
	Nut	11 Nm	C
	Nut	7.9 ÷ 11.8 Nm	0
Fastening gearbox ECU	Screw	5 Nm	B
Fastening lift system ECU	Screw	4 Nm	A
Fastening door node ECUs	Screw	4 Nm	A
Fastening fuel pump control ECUs	Screw	4 Nm	A
Fastening EPB ECU	Nut	7.5 Nm	B
Fastening EPB Bowden cable and heat shield	Screw	6 Nm	B
Fastening the PTU ECU	Screw	5 Nm	B
Fastening the adaptive headlight ECU bracket	Screw	5 Nm	B
Fastening the parking sensor ECU	Screw	4 Nm	B
Fastening third stop light	Screw	2 Nm	B
Fastening Body computer	Screw	8 Nm	B
Fastening Magneride accelerometers	Accelerometer	16 Nm	B
Fastening battery sensor	Nut	6 Nm	B
Fastening satellite alarm system ECU	Nut	4 Nm	B
Fastening parking camera ECU	Screw	4 Nm	B
Fastening airbag ECU	Nut	10 Nm	B
Fastening the rear screen wiper ECU	Nut	5 Nm	B
Fastening the luggage compartment lid power assistance system ECU	Nut	4 Nm	B
Fastening GDI injection pump soundproofing cover	Screw	10 Nm	B
Fastening the active carbon filter	Screw	9 Nm	B
Fastening the active carbon filter cover	Screw	9 Nm	B
Fastening the fuel vapour separator mounting bracket	Screw	9 Nm	B
Fastening fuel pipes to chassis	Screw / Nut	9 Nm	B
Fastening fuel pipe retainer brackets	Screw / Nut	5 Nm	B
Fastening GDI injection pump soundproofing cover	Screw	10 Nm	B



Tightening torque		Nm	Class
Fastening RPM sensor	Sensor	8 Nm	A
Fastening engine oil pressure sensor	Sensor	36 Nm	B
Fastening the GDI rail pipes	Screw (pretightening)	5 Nm	B
	Screw	10 Nm	B
Fastening the GDI rail pipe connector bracket	Screw	10 Nm	B
Fastening the timing sensors	Screw	8 Nm	A
Fastening variable timing adjuster solenoid valve	Screw	6 Nm	B
Fastening accelerator pedal	Nut	9 Nm	B
Fastening volumetric sensor	Nut	4 Nm	B
Fastening anti-lift sensor	Screw	4 Nm	B
Fastening anti-theft siren	Nut	8 Nm	B
Fastening the front seat belts	Screw	40 Nm	A
Fastening the rear seat belts	Screw	40 Nm	A
	Nut	40 Nm	A
Fastening the passenger side airbag mounting bracket	Screw	4 Nm	B
	Screw	8 Nm	B
Fastening the passenger side airbag	Nut	8 Nm	B
Fastening the side airbag	Screw	4 Nm	B
	Screw	8 Nm	B
Fastening the side airbag mounting bracket	Screw	9 Nm	B
	Nut	9 Nm	B
Fastening the front seat belt extenders	Screw	4 Nm	B
Fastening AC pipe union.	Nut	8 Nm	B
Fastening AC compressor to engine	Screw	25 Nm	B
Fastening pipes to AC compressor	Screw	24 Nm	B
Fastening Freon pipes	Nut	16 Nm	B
	Screw	9 Nm	B
	Nut	24 Nm	B
	Screw	5 Nm	B
Fastening TGK solenoid valve mounting bracket	Screw	9 Nm	B
Fastening condenser	Screw	5 Nm	B
Fastening AC unit	Nut	9 Nm	B
	Screw	8 Nm	B
Fastening AC unit air ducts	Screw	4 Nm	B
	Nut	4 Nm	B
	Screw	2 Nm	B
Fastening the front axle shafts	Screw	30 Nm	A
	Nut	275 Nm	A
Fastening the power steering pump	Screw	24 Nm	A



Tightening torque		Nm	Class
Fastening front secondary air accumulator tank to chassis	Screw	9 Nm	B
Fastening rear secondary air accumulator tank to chassis	Nut	4 Nm	B
Fastening secondary air pump bracket to chassis	Screw	9 Nm	B
Fastening rear solenoid valves to chassis	Screw	4 Nm	B