



GTC4Lusso USA - Electrical system absorption test - Latest Update: 2021-01-26

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by Ferrari S.p.A. Ferrari S.p.A. does not guarantee or accept any liability with respect to the correctness of information in this document.

Copyright by Ferrari S.p.A. - P.IVA 00159560366

F2.13 Electrical system absorption test

Measuring no-load current absorption

The current absorbed by the vehicle system may be measured with a digital multimeter or with an amperometric clamp meter.

Use only amperometric clamp meters with mA scales.

The unit of measurement used for testing must be Amperes (A).


- Ensure that the doors and the luggage compartment lid are correctly closed.
- Open the engine compartment lid.

- Remove the engine compartment cosmetic shields (🔧 E3.14).

🔧 Remove the right hand cosmetic inspection shield.

PROCEDURE WITH DIGITAL MULTIMETER

- Disconnect the battery (🔧 F2.01).



If possible, use cables with terminal clamps for the following procedures.

- Connect the wire **(A)** to the tester socket marked Ground.
- Connect the wire **(B)** (usually red) to the tester socket marked with the unit of measurement A (Amperes).



- Attach the lead clamp **(D)** onto the quick release terminal clamp connected to ground on the chassis.



-  Do not start the engine or turn the ignition key-on, as this may blow the instrument fuse.

- Attach the black lead clamp **(C)** (common ground) onto the false pole connected to the negative battery pole.

- To prevent the reading from being affected by devices that are still active, wait at least **15 minutes** for the network to enter **"Sleep Mode"**.
- Read the absorption values measured.
- The values read for zero-load current absorption must be close to **25 to 35 mA** and **MUST NOT** exceed **45 mA**.
- Remove the lead clamps.
- Connect the battery ( **F2.01**).

PROCEDURE WITH AMPEROMETRIC CLAMP METER

- Disable the EPB electric parking brake Autohold function ( **D3.06**).
- Close the driver side door ensuring that it closes correctly.



The instrument used must have a current scale precision in mA.

- Place the clamp meter unit around the ground cable leading from the negative battery pole.
- The direction of the current measured is indicated on the clamp.
-  As in this case the current originates from the battery and discharges on the chassis, the arrow indicates a direction leading away from the battery toward the earthing point on the chassis.
- To prevent the reading from being affected by devices that are still active, wait at least **6 minutes** for the network to enter "**Sleep Mode**".
- The values read for zero-load current absorption must be close to **25 to 35 mA** and **MUST NOT** exceed **45 mA**.
- Refit the engine compartment cosmetic shields ( E3.14).

Possible causes of excessive absorption

- If the value read in the vehicle is higher than in the specifications, the battery will tend to discharge rapidly.
- The cause of this is probably one or more devices failing to switch off.
- To identify the cause of excessive absorption, disconnect the networked ECUs one by one while observing the absorption value. This will drop when the active ECU is disconnected.
- Another possible cause for excessive current absorption may be a short circuit to ground at some point in the wiring harness.