


BIGTREE TECH

KRAKEN V1.0

User Manual



Revision Log

Version	Date	Revisions
v1.00	22nd December 2023	Initial Version
V1.01	March 6, 2024	Add max31865 description

CONTENT

Revision Log	2
Product Profile	5
Features Highlights	5
Specifications	6
Firmware Support	7
Dimensions	8
Interface Diagram	8
Pin Description	9
Interface Introduction	9
USB Power Supply	9
Stepper Motor Drivers	10
Onboard TMC2160 in SPI mode	10
PWM Fan Voltage Selection	10
MicroProbe V2.0 Wiring	11
Auto Power Off (Relay V1.2) Wiring	11
EXP1+EXP2 and MINI12864 V2.0 Display Wiring	12
RGB Wiring	12
Servo Wiring	13
I²C Wiring (Temperature and Humidity Sensor)	13
2-pin Fan Connection	14
Proximity Switch Connection	15
4-pin PWM Fan and Water Cooling Connection (12V example)	16
Raspberry Pi Connection	16
Marlin	17
Install Compiling Environment	17
Download Marlin Firmware	17
Configure Firmware	17

Open Marlin Project	17
Compiling Environment	17
Configure Motherboard and Serial Port	17
Configure Stepper Driver Kraken has 8 TMC2160 drivers onboard	18
Sensorless Homing	20
100K NTC	21
Max31865	21
BLTouch	22
Auto Power Off (Relay V1.2)	24
RGB	25
Filament Sensor	26
Compile Firmware	28
Klipper	29
Compiling the Firmware	29
Configuring Klipper	30
Firmware Updates	32
Updating via microSD	32
Updating Klipper via DFU	32
Precautions	33

Product Profile

BIGTREETECH Kraken V1.0 is a 32-bit motherboard for large printers. It comes with onboard high-voltage, high-current stepper motor drivers, significantly simplifying the connection between the motherboard and high-voltage drivers and saving space in the chassis. The board uses silkscreened ID design with an ID-design heat sink for aesthetics and practical cooling.

Features Highlights

- Utilizes a 32-bit ARM Cortex-M7 series STM32H723ZGT6 MCU with a main frequency of 550 MHz.
- TPS5450-5A power chip, supporting DC12/24V power input. This chip provides an output current of up to 5A, peaking at 6A, perfectly supporting Raspberry Pi power supply.
- The motherboard has a reserved BOOT button, allowing users to update the bootloader via DFU mode.
- The thermistor circuit is protected to prevent MCU damage from shorted heated bed and heater cartridge connections;
- Selectable voltage (24V, 12V, 5V) for PWM fan, eliminating the need for external voltage conversion modules, thereby reducing the likelihood of motherboard damage.
- Onboard two MAX31865 modules, supporting dual PT thermocouples and compatible with two or four-wire PT100/PT1000, facilitating DIY usage for customers.
- Firmware can be upgraded via MicroSD card or through the Klipper's `make flash` command via DFU.
- Onboard 8 TMC2160 drivers in SPI mode with DIAG function pins; simply plug and unplug jumpers for easy use.
- Reserved interfaces for Filament Detection, Auto Power-Off, Probe, RGB, I²C, Servo, EXP1+EXP2, CAN, UART (SBC), and USB A power output.
- High-performance MOSFETs to reduce heat generation.
- Replaceable fuses for easy replacement.
- 2x 4-pin fan interfaces with selectable voltages of 24V, 12V, and 5V, also suitable for water cooling setups.
- Onboard proximity switch port, supports NPN and PNP types, 24V, 12V, 5V voltage selectable;

- Reserved SPI interface for connecting an accelerometer for Klipper resonance compensation.
- External DC12V powers the MOSFET control power for TMC2160, reducing driver output impedance and chip heat generation.

Specifications


MCU	ARM Cortex-M7 STM32H723ZGT6 550MHz
Driver Input Voltage	HV (24-60V)
Motherboard Input Voltage	DCIN = DC12V or DC24V
Heated Bed Input Voltage	BED IN = DC12V or DC24V
Logic Voltage	DC3.3V
Heating Interface	Heating Interface: Heated Bed (HB), Heater Cartridge (HE0, HE1, HE2, HE3)
Max Heated Bed Output Current	10A, peak 11A
Max Heater Cartridge Output Current	6A, peak 6.5A
Fan Interfaces	6x 2-pin PWM Fans (FAN0, FAN1, FAN2, FAN3, FAN4, FAN5), 2x 4-pin PWM Fans (FAN6, FAN7), 5x Always-On Fan, PWM Fans Voltage (5V, 12V, 24V) Selectable
Max Fan Output Current	1A, peak 1.5A
Total Current for Heater Cartridge + Fans	Less than 14A
Motherboard Max 5V Output Current	5A (peak 6A)
Motherboard Max 12V Output Current	5A (peak 6A)
Expansion Interfaces	Probe (Servos, Probe), Servo, Filament Sensor, PS-ON, I ² C, RGBx2, SPI, SBC (UART), EXP1+EXP2, CANx2, PT100/PT1000x2, USB-A 5V Power, Endstop

	Portx8, etc.
	Onboard TMC2160, support 24-60V, Max 8A driving current for S1-S4(Rsense=22mR),
Motor Drivers	Max 3A for S5-S8(Rsense=75mR)
Driver Modes	SPI
Motor Interfaces	S1, S2, S3, S4, S5, S6, S7, S8
Temp Sensor Interfaces	5x 100K NTC, 2x MAX31865
Display	LCD
PC Communication	Type-C
Supported Kinematics	Cartesian, Delta, Kossel, Ultimaker, CoreXY
Recommended Slicer/Console	Cura, Simplify3D, Pronterface, Repetier-host, Makerware
Dimensions	200 x 113mm
Mounting Dimensions	for details please refer to BIGTREETECH Kraken V1.0-SIZE.png

Firmware Support


Compatible with Klipper, Marlin, RRF(RepRapFirmware)

Dimensions




Peripheral Interface

Interface Diagram



Pin Description




Kraken v1.0-Pin

Interface Introduction

USB Power Supply

When Kraken is powered on, the power indicator light turns red, indicating normal power supply. VUSB is the power select pin which needs to be shorted with a jumper only when supplying power to the board via USB.



Stepper Motor Drivers

Onboard TMC2160 in SPI mode


No jumper is needed to select the mode; directly use the SPI mode. When using Sensorless Homing, plug in the jumper; if not, leave it unplugged. DIAG connection as follows:




PWM Fan Voltage Selection

Set the output voltage to 5V, 12V, or 24V via a jumper. The fan interface output current is 1A.


Be sure to confirm the supported voltage of the fan before selection to avoid damage for which our company is not responsible.




MicroProbe V2.0 Wiring




Auto Power Off (Relay V1.2) Wiring




EXP1+EXP2 and MINI12864 V2.0 Display Wiring




RGB Wiring




Servo Wiring



I²C Wiring (Temperature and Humidity Sensor)



2-pin Fan Connection




Proximity Switch Connection


Normally open (NPN type), no jumper is required, as shown in the 24V example.




Normally closed (PNP type), a jumper is needed, as shown in the 24V example.



4-pin PWM Fan and Water Cooling Connection (12V example)



Raspberry Pi Connection



Marlin

Install Compiling Environment

<https://github.com/bigtreeetech/Document/blob/master/How%20to%20install%20VScode%2BPlatformio.md>

https://marlinfw.org/docs/basics/install_platformio_vscode.html

Download Marlin Firmware

Get pre-configured firmware source code from our GitHub:

<https://github.com/bigtreeetech/BIGTREETECH-Kraken>

Configure Firmware


Open Marlin Project

You can open Marlin in VS Code in one of several ways:

- Drag the downloaded Marlin Firmware folder onto the VScode application icon;
- Use the **Open...** command in the VSCode **File** menu;
- Open the PIO Home tab and click the **Open Project** button.

Compiling Environment

Open **platformio.ini** file and change **default_envs** to **STM32H723ZG_btt**.



Configure Motherboard and Serial Port


Set **MOTHERBOARD** as **BOARD_BTT_KRAKEN_V1_0**

#define MOTHERBOARD BOARD_BTT_KRAKEN_V1_0

```
#define SERIAL_PORT 3 (Enable SBC serial port)
#define BAUDRATE 115200 (Set baudrate to the same as the communication device)
```

#define SERIAL_PORT_2 -1 (Enable USB serial port)


The above settings can be enabled as needed.



```
EXPLORER ... C Configuration.h M X
Marlin > C Configuration.h > E MOTHERBOARD
69 // Choose the name from boards.h that matches your setup
70 #ifndef MOTHERBOARD
71 #define MOTHERBOARD BOARD_BTT_KRAKEN_V1_0
72 #endif
73
74 /**
75 * Select the serial port on the board to use for communication with the host.
76 * This allows the connection of wireless adapters (for instance) to non-default port pins.
77 * Serial port -1 is the USB emulated serial port, if available.
78 * Note: The first serial port (-1 or 0) will always be used by the Arduino bootloader.
79 *
80 * :[-1, 0, 1, 2, 3, 4, 5, 6, 7]
81 */
82 #define SERIAL_PORT 3
83
84 /**
85 * Serial Port Baud Rate
86 * This is the default communication speed for all serial ports.
87 * Set the baud rate defaults for additional serial ports below.
88 *
89 * 250000 works in most cases, but you might try a lower speed if
90 * you commonly experience drop-outs during host printing.
91 * You may try up to 1000000 to speed up SD file transfer.
92 *
93 * :[2400, 9600, 19200, 38400, 57600, 115200, 250000, 500000, 1000000]
94 */
95 #define BAUDRATE 115200
96
97 //##define BAUD_RATE_GCODE // Enable G-code M575 to set the baud rate
98
99 /**
100 * Select a secondary serial port on the board to use for communication with the host.
101 * Currently Ethernet (-2) is only supported on Teensy 4.1 boards.
102 * :[-2, -1, 0, 1, 2, 3, 4, 5, 6, 7]
103 */
104 #define SERIAL_PORT_2 -1
105 //##define BAUDRATE_2 250000 // :[2400, 9600, 19200, 38400, 57600, 115200, 250000, 500000, 1000000]
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142 #define X_DRIVER_TYPE TMC2160
143 #define Y_DRIVER_TYPE TMC2160
144 #define Z_DRIVER_TYPE TMC2160
145 //##define X2_DRIVER_TYPE A4988
146 //##define Y2_DRIVER_TYPE A4988
147 //##define Z2_DRIVER_TYPE A4988
148 //##define Z3_DRIVER_TYPE A4988
149 //##define Z4_DRIVER_TYPE A4988
150 //##define I_DRIVER_TYPE A4988
151 //##define J_DRIVER_TYPE A4988
152 //##define K_DRIVER_TYPE A4988
153 //##define U_DRIVER_TYPE A4988
154 //##define V_DRIVER_TYPE A4988
155 //##define W_DRIVER_TYPE A4988
156 #define E0_DRIVER_TYPE TMC2160
157 //##define E1_DRIVER_TYPE A4988
158 //##define E2_DRIVER_TYPE A4988
159 //##define E3_DRIVER_TYPE A4988
160 //##define E4_DRIVER_TYPE A4988
161 //##define E5_DRIVER_TYPE A4988
162 //##define E6_DRIVER_TYPE A4988
163 //##define E7_DRIVER_TYPE A4988
```

Configure Stepper Driver


Kraken has 8 TMC2160 drivers onboard



```
EXPLORER ... C Configuration.h M X
Marlin > C Configuration.h > E E0_DRIVER_TYPE
142 #define X_DRIVER_TYPE TMC2160
143 #define Y_DRIVER_TYPE TMC2160
144 #define Z_DRIVER_TYPE TMC2160
145 //##define X2_DRIVER_TYPE A4988
146 //##define Y2_DRIVER_TYPE A4988
147 //##define Z2_DRIVER_TYPE A4988
148 //##define Z3_DRIVER_TYPE A4988
149 //##define Z4_DRIVER_TYPE A4988
150 //##define I_DRIVER_TYPE A4988
151 //##define J_DRIVER_TYPE A4988
152 //##define K_DRIVER_TYPE A4988
153 //##define U_DRIVER_TYPE A4988
154 //##define V_DRIVER_TYPE A4988
155 //##define W_DRIVER_TYPE A4988
156 #define E0_DRIVER_TYPE TMC2160
157 //##define E1_DRIVER_TYPE A4988
158 //##define E2_DRIVER_TYPE A4988
159 //##define E3_DRIVER_TYPE A4988
160 //##define E4_DRIVER_TYPE A4988
161 //##define E5_DRIVER_TYPE A4988
162 //##define E6_DRIVER_TYPE A4988
163 //##define E7_DRIVER_TYPE A4988
```

We need to enable [TMC_USE_SW_SPI](#) in Configuration_adv.h


```
#define TMC_USE_SW_SPI
```



```
EXPLORER ... Configuration.h M Configuration_adv.h X
BTT_MARLIN_PRI Marlin > Configuration_adv.h ...
.github 2901 /**
>.pio 2902 * Software option for SPI driven drivers (TMC2130, TMC2160, TMC2660, TMC5130 and TMC5160).
>.vscode 2903 * The default SW SPI pins are defined the respective pins files,
>buildroot 2904 * but you can override or define them here.
>config 2905 */
>docker 2906 #define TMC_USE_SW_SPI
>docs 2907 // #define TMC_SW_MOSI -1
>ini 2908 // #define TMC_SW_MISO -1
>Marlin 2909 // #define TMC_SW_SCK -1
2910
2911
```

The Rsense of S1-S4 is $22\text{m}\Omega$, so the firmware needs to be set to 0.022.

The Rsense of S5-S8 is $75\text{m}\Omega$, so the firmware needs to be set to 0.075.



```
EXPLORER ... Configuration.h M Configuration_adv.h M
MARLIN Marlin > Configuration_adv.h ...
.devcontainer 2950 #if AXIS_IS_TMC_CONFIG(X)
.github 2951 #define X_CURRENT 800 // (mA) RMS current. Multiply by 1.414 for peak current.
>.pio 2952 #define X_CURRENT_HOME X_CURRENT // (mA) RMS current for sensorless homing
>.vscode 2953 #define X_MICROSTEPS 16 // 0..256
>buildroot 2954 #define X_RSENSE 0.022 // Multiplied x1000 for TMC26X
>config 2955 #define X_CHAIN_POS -1 // -1..0: Not chained. 1: MCU MOSI connected. 2: Next in chain, ...
>docker 2956 // #define X_INTERPOLATE true // Enable to override 'INTERPOLATE' for the X axis
>docs 2957 // #define X_HOLD_MULTIPLIER 0.5 // Enable to override 'HOLD_MULTIPLIER' for the X axis
>ini 2958 #endif
>Marlin 2959
>lib 2960
>src 2961
config.ini 2962
Configuration_adv.h M 2963
Configuration.h M 2964
Makefile 2965
Marlin.ino 2966
Version.h 2967
.editorconfig 2968
.gitattributes 2969
.gitignore 2970
LICENSE 2971
Makefile 2972
2973 #define Y_CURRENT 800
2974 #define Y_CURRENT_HOME Y_CURRENT
2975 #define Y_MICROSTEPS 16
2976 #define Y_RSENSE 0.022
#define Y_CHAIN_POS -1
// #define Y_INTERPOLATE true
2977
2978
2979
2980
2981
2982
2983
2984
2985
2986
2987
2988
2989
2990
2991
2992
2993
2994
2995
2996
2997
2998
2999
2999
```

Sensorless Homing

```

EXPLORER          Configuration.h M   Configuration_adv.h M X
BTT_MARLIN_PRI
  .github
  .pio
  .vscode
  buildroot
  config
  docker
  docs
  ini
  Marlin
    lib
    src
  Configuration_adv.h M
  Configuration.h M
  Makefile
  Marlin.ino
  Version.h
  .editorconfig
  .gitattributes
  .gitignore
  docker-compose.yml
  get_test_targets.py
  LICENSE
  Makefile
  platformio.ini
  process-palette.json
  README.md

Marlin > Configuration_adv.h > ...
3047 /**
3048 * Use StallGuard to home / probe X, Y, Z.
3049 *
3050 * TMC2130, TMC2160, TMC2209, TMC2660, TMC5130, and TMC5160 only
3051 * Connect the stepper driver's DIAG1 pin to the X/Y endstop pin.
3052 * X, Y, and Z homing will always be done in spreadCycle mode.
3053 *
3054 * X/Y/Z_STALL_SENSITIVITY is the default stall threshold.
3055 * Use M914 X Y Z to set the stall threshold at runtime:
3056 *
3057 * Sensitivity TMC2209 Others
3058 * HIGHEST      255     -64  (Too sensitive => False positive)
3059 * LOWEST       0       63  (Too insensitive => No trigger)
3060 *
3061 * It is recommended to set HOMING_BUMP_MM to { 0, 0, 0 }.
3062 *
3063 * SPI_ENDSTOPS *** Beta feature! *** TMC2130/TMC5160 Only ***
3064 * Poll the driver through SPI to determine load when homing.
3065 * Removes the need for a wire from DIAG1 to an endstop pin.
3066 *
3067 * IMPROVE_HOMING_RELIABILITY tunes acceleration and jerk when
3068 * homing and adds a guard period for endstop triggering.
3069 *
3070 * Comment *_STALL_SENSITIVITY to disable sensorless homing for that axis.
3071 */
3072 #define SENSORLESS_HOMING // StallGuard capable drivers only
3073
3074 #if EITHER(SENSORLESS_HOMING, SENSORLESS_PROBING)
3075     // TMC2209: 0...255, TMC2130: -64...63
3076     #define X_STALL_SENSITIVITY 8
3077     #define X2_STALL_SENSITIVITY X_STALL_SENSITIVITY
3078     #define Y_STALL_SENSITIVITY 8
3079     #define Y2_STALL_SENSITIVITY Y_STALL_SENSITIVITY
3080     //#define Z_STALL_SENSITIVITY 8
3081     //#define Z2_STALL_SENSITIVITY Z_STALL_SENSITIVITY
3082     //#define Z3_STALL_SENSITIVITY Z_STALL_SENSITIVITY
3083     //#define Z4_STALL_SENSITIVITY Z_STALL_SENSITIVITY
3084     //#define I_STALL_SENSITIVITY 8
3085     //#define J_STALL_SENSITIVITY 8
3086     //#define K_STALL_SENSITIVITY 8
3087     //#define SPI_ENDSTOPS // TMC2130 only
3088     #define IMPROVE_HOMING_RELIABILITY
3089 #endif


```

#define SENSORLESS_HOMING // enable sensorless homing
#define xx_STALL_SENSITIVITY 8 // sensitivity setting, TMC2209 range from 0 to 255, higher number results in more sensitive trigger threshold, sensitivity too high will cause endpoint to trigger before gantry actually moves to the end, lower number results in less sensitive trigger threshold, too low of sensitivity will cause endpoint to not trigger and gantrying continue. Other drivers range from 63 to -64, lower numbers result in a more sensitive trigger threshold.
#define IMPROVE_HOMING_RELIABILITY // can be used to set independent motor current for homing moves(xx_CURRENT_HOME) to improve homing reliability.

100K NTC

The standard TH ports only support NTC 100K thermistor. In Marlin firmware, "1" represents a 100K NTC with a 4.7K pull-up resistor.

```
#define TEMP_SENSOR_0 1
#define TEMP_SENSOR_1 1
#define TEMP_SENSOR_BED 1
```



The screenshot shows the VS Code interface with the 'Configuration.h' file open. The code defines three temperature sensors:


```
#define TEMP_SENSOR_0 1
#define TEMP_SENSOR_1 1
#define TEMP_SENSOR_BED 1
```

Max31865

To understand how to wire your sensor, look at the pin diagram and use the dip switch settings that correspond to your connection scheme. Apply the following firmware settings based on your connection scheme and dip switch settings.

In Marlin (klipper) firmware, "-5" represents max31865, the sensor resistance (rtd_nominal_r) and calibration (rtd_reference_r) resistance of PT100 are 100 and 430, while PT1000 are 1000 and 4300.

```
#define TEMP_SENSOR_0 -5
#define TEMP_SENSOR_1 -5
```




The screenshot shows the VS Code interface with the 'Configuration.h' file open. The code defines two temperature sensors as Max31865 and sets their resistances:

```
#define TEMP_SENSOR_0 -5
#define TEMP_SENSOR_1 -5
```

It also defines MAX31865_SENSOR_OHMS_0 and MAX31865_CALIBRATION_OHMS_0 with values 1000 and 4300 respectively, and MAX31865_SENSOR_OHMS_1 and MAX31865_CALIBRATION_OHMS_1 with values 100 and 430.

BLTouch



```

EXPLORER    ... C Configuration.h M X C Configuration_adv.h M
BTT_MARLIN_PRI
> .github
> .pio
> .vscode
> buildroot
> config
> docker
> docs
> ini

Marlin > C Configuration.h > ...
1033 /**
1034  * Enable this option for a probe connected to the Z-MIN pin.
1035  * The probe replaces the Z-MIN endstop and is used for Z homing.
1036  * (Automatically enables USE_PROBE_FOR_Z_HOMING.)
1037 */
1038 //##define Z_MIN_PROBE_USES_Z_MIN_ENDSTOP_PIN
1039 // Force the use of the probe for Z-axis homing
1040 //##define USE_PROBE_FOR_Z_HOMING

```

//##define Z_MIN_PROBE_USES_Z_MIN_ENDSTOP_PIN // Do not remap the Z_PROBE_PIN to the Z_MIN port.




```

EXPLORER    ... C Configuration.h M X C Configuration_adv.h M
BTT_MARLIN_PRI
> .github
> .pio
> .vscode
> buildroot
> config
> docker
> docs
> ini

Marlin > C Configuration.h > ...
1092 /**
1093  * The BLTouch probe uses a Hall effect sensor and emulates a servo.
1094 */
1095 #define BLTOUCH
1096

```

#define BLTOUCH // Enable BLTouch



```


EXPLORER    ... C Configuration.h M X C Configuration_adv.h M
BTT_MARLIN_PRI
> .github
> .pio
> .vscode
> buildroot
> config
> docker
> docs
> ini
> Marlin
> lib
> src
C Configuration_adv.h M
C Configuration.h M
M Makefile
C Marlin.ino
C Version.h
.editorconfig
.gitattributes
.gitignore
.docker-compose.yml
.get_test_targets.py
LICENSE
M Makefile
platformio.ini
process-palette.json
README.md

Marlin > C Configuration.h > ...
1182 * Some examples:
1183 * #define NOZZLE_TO_PROBE_OFFSET { 10, 10, -1 } // Example "1"
1184 * #define NOZZLE_TO_PROBE_OFFSET {-10, 5, -1 } // Example "2"
1185 * #define NOZZLE_TO_PROBE_OFFSET { 5, -5, -1 } // Example "3"
1186 * #define NOZZLE_TO_PROBE_OFFSET {-15,-10, -1 } // Example "4"
1187 *
1188 * +-- BACK ---+
1189 * | [+] |
1190 * | L | 1 | R <-- Example "1" (right+, back+)
1191 * | E | 2 | I <-- Example "2" (left-, back+)
1192 * | F | [-] N [+] | G <-- Nozzle
1193 * | T | 3 | H <-- Example "3" (right+, front-)
1194 * | 4 | T <-- Example "4" (left-, front-)
1195 * | [-] |
1196 * 0-- FRONT --+
1197 */
1198 #define NOZZLE_TO_PROBE_OFFSET { -40, -10, -2.85 }
1199
1200 // Most probes should stay away from the edges of the bed, but
1201 // with NOZZLE_AS_PROBE this can be negative for a wider probing area.
1202 #define PROBING_MARGIN 10
1203
1204 // X and Y axis travel speed (mm/min) between probes
1205 #define XY_PROBE_FEEDRATE (133*60)
1206
1207 // Feedrate (mm/min) for the first approach when double-probing (MULTIPLE_PROBING == 2)
1208 #define Z_PROBE_FEEDRATE_FAST (4*60)
1209
1210 // Feedrate (mm/min) for the "accurate" probe of each point
1211 #define Z_PROBE_FEEDRATE_SLOW (Z_PROBE_FEEDRATE_FAST / 2)
1212

```

#define NOZZLE_TO_PROBE_OFFSET { -40, -10, -2.85 } // set BLTouch probe offset

#define PROBING_MARGIN 10 // set distance between probe area and print area perimeter




```

EXPLORER ... Configuration.h M Configuration_adv.h M
Marlin > Configuration.h > ...
1562 // #define AUTO_BED_LEVELING_3POINT
1563 // #define AUTO_BED_LEVELING_LINEAR
1564 #define AUTO_BED_LEVELING_BILINEAR
1565 // #define AUTO_BED_LEVELING_UBL
1566 // #define MESH_BED_LEVELING
1567 /**
1568 * Normally G28 leaves leveling disabled on completion. Enable one of
1569 * these options to restore the prior leveling state or to always enable
1570 * leveling immediately after G28.
1571 */
1572 // #define RESTORE_LEVELING_AFTER_G28
1573 // #define ENABLE_LEVELING_AFTER_G28
1574 #define ENABLE_LEVELING_AFTER_G28
1575 /**
1576 */

```

#define AUTO_BED_LEVELING_BILINEAR // set probe pattern
#define RESTORE_LEVELING_AFTER_G28 // apply leveling after G28 homing command




```

EXPLORER ... Configuration.h M Configuration_adv.h M
Marlin > Configuration.h > ...
1628 #if EITHER(AUTO_BED_LEVELING_LINEAR, AUTO_BED_LEVELING_BILINEAR)
1629
1630 // Set the number of grid points per dimension.
1631 #define GRID_MAX_POINTS_X 5
1632 #define GRID_MAX_POINTS_Y GRID_MAX_POINTS_X
1633
1634 // Probe along the Y axis, advancing X after each column
1635 // #define PROBE_Y_FIRST
1636
1637 #if ENABLED(AUTO_BED_LEVELING_BILINEAR)
1638
1639 // Beyond the probed grid, continue the implied tilt?
1640 // Default is to maintain the height of the nearest edge.
1641 // #define EXTRAPOLATE_BEYOND_GRID
1642

```

#define GRID_MAX_POINTS_X 5 // set number of probe points for X axis,
usually 5 point is sufficient
#define GRID_MAX_POINTS_Y GRID_MAX_POINTS_X // set the number of
probe points for Y axis to the same as X axis.

If BLTouch also functions as your Z homing sensor, no wiring change is needed,
just set it in the firmware.




```

EXPLORER ... Configuration.h M Configuration_adv.h M
Marlin > Configuration.h > ...
1033 /**
1034 * Enable this option for a probe connected to the Z-MIN pin.
1035 * The probe replaces the Z-MIN endstop and is used for Z homing.
1036 * (Automatically enables USE_PROBE_FOR_Z_HOMING.)
1037 */
1038 // #define Z_MIN_PROBE_USES_Z_MIN_ENDSTOP_PIN
1039
1040 // Force the use of the probe for Z-axis homing
1041 #define USE_PROBE_FOR_Z_HOMING
1042

```

#define USE_PROBE_FOR_Z_HOMING // use Z Probe(BLTouch) for Z homing




```

EXPLORER ... C Configuration.h M X C Configuration_adv.h M
Marlin > C Configuration.h > ...
1758 /**
1759 * Use "Z Safe Homing" to avoid homing with a Z probe outside the bed area.
1760 *
1761 * - Moves the Z probe (or nozzle) to a defined XY point before Z homing.
1762 * - Allows Z homing only when XY positions are known and trusted.
1763 * - If stepper drivers sleep, XY homing may be required again before Z homing.
1764 */
1765 #define Z_SAFE_HOMING
1766
1767 #if ENABLED(Z_SAFE_HOMING)
1768 #define Z_SAFE_HOMING_X_POINT X_CENTER // X point for Z homing
1769 #define Z_SAFE_HOMING_Y_POINT Y_CENTER // Y point for Z homing
1770#endif

```

`#define Z_SAFE_HOMING // home Z at the center of print bed to prevent probing outside of the print bed.`

Auto Power Off (Relay V1.2)



```


EXPLORER ... C Configuration.h M X C Configuration_adv.h M
Marlin > C Configuration.h > ...
359 /**
360 * Power Supply Control
361 *
362 * Enable and connect the power supply to the PS_ON_PIN.
363 * Specify whether the power supply is active HIGH or active LOW.
364 */
365 #define PSU_CONTROL
366 #define PSU_NAME "Power Supply"
367
368 #if ENABLED(PSU_CONTROL)
369 // #define MKS_PWC // Using the MKS PWC add-on
370 // #define PS_OFF_CONFIRM // Confirm dialog when power off
371 // #define PS_OFF_SOUND // Beep is when power off
372 #define PSU_ACTIVE_STATE HIGH // Set 'LOW' for ATX, 'HIGH' for X-Box
373
374 // #define PSU_DEFAULT_OFF // Keep power off until enabled directly with M80
375 // #define PSU_POWERUP_DELAY 250 // (ms) Delay for the PSU to warm up to full power
376
377 // #define POWER_OFF_TIMER // Enable M80 D<seconds> to power off after a delay
378 // #define POWER_OFF_WAIT_FOR_COOLDOWN // Enable M81 S to power off only after cooldown

```

`#define PSU_CONTROL // enable PSU control to turn on and off using M80 and M81`

`#define PSU_ACTIVE_STATE HIGH // set turn on level, Relay V1.2 is turned on with high level and turned off with low level, so this setting needs to be HIGH.`

RGB



```

EXPLORER      C Configuration.h M  C Configuration_adv.h M
BTT_MARLIN_PRI Marlin > C Configuration.h > ...
> .github
> .pio
> .vscode
> buildroot
> config
> docker
> docs
> ini
Marlin
> lib
> src
C Configuration_adv.h M
C Configuration.h M
Marlin > C Configuration.h ...
2926 // Support for Adafruit NeoPixel LED driver
2927 #define NEOPIXEL_LED
2928 #if ENABLED(NEOPIXEL_LED)
2929 #define NEOPIXEL_TYPE NEO_GRB // NEO_GRBW / NEO_GRB - four/three channel driver type (defined in Adafruit_NeoPixel.h)
2930 //#define NEOPIXEL_PIN 4 // LED driving pin
2931 //#define NEOPIXEL2_TYPE NEOPIXEL_TYPE
2932 //#define NEOPIXEL2_PIN 5
2933 #define NEOPIXEL_PIXELS 30 // Number of LEDs in the strip. (Longest strip when NEOPIXEL2_SEPARATE is disabled.)
2934 #define NEOPIXEL_IS_SEQUENTIAL // Sequential display for temperature change - LED by LED. Disable to change all LEDs at once.
2935 #define NEOPIXEL_BRIGHTNESS 255 // Initial brightness (0-255)
2936 #define NEOPIXEL_STARTUP_TEST // Cycle through colors at startup
2937
2938 // Support for second Adafruit NeoPixel LED driver controlled with M150 S1 ...
2939 //#define NEOPIXEL2_SEPARATE
2940 #if ENABLED(NEOPIXEL2_SEPARATE)
2941 #define NEOPIXEL2_PIXELS 15 // Number of LEDs in the second strip
2942 #define NEOPIXEL2_BRIGHTNESS 127 // Initial brightness (0-255)
2943 #define NEOPIXEL2_STARTUP_TEST // Cycle through colors at startup
2944 #else
2945 //#define NEOPIXEL2_INSERIES // Default behavior is NeoPixel 2 in parallel
2946 #endif
2947
2948 // Use some of the NeoPixel LEDs for static (background) lighting
2949 //#define NEOPIXEL_BKGD_INDEX_FIRST 0 // Index of the first background LED
2950 //#define NEOPIXEL_BKGD_INDEX_LAST 5 // Index of the last background LED
2951 //#define NEOPIXEL_BKGD_COLOR { 255, 255, 255, 0 } // R, G, B, W
2952 //#define NEOPIXEL_BKGD_ALWAYS_ON // Keep the backlight on when other NeoPixels are off
2953 #endiff


```

```

#define NEOPIXEL_LED // enable Neopixel
#define NEOPIXEL_TYPE NEO_GRB // set Neopixel type
//#define NEOPIXEL_PIN 4 // disable PIN setting, use the correct signal pin in
the pin file of the motherboard
#define NEOPIXEL_PIXELS 30 // number of LEDs
#define NEOPIXEL_STARTUP_TEST // the light will show red green and blue
sequentially to self-test

```

If you are using displays like LCD2004, 12864, mini12864, etc., you can also control RGB from your display directly.



```


EXPLORER      C Configuration.h M  C Configuration_adv.h M
BTT_MARLIN_PRI Marlin > C Configuration.h > ...
> .github
> .pio
> .vscode
> buildroot
> config
> docker
> docs
> ini
Marlin
> lib
> src
C Configuration_adv.h M
C Configuration.h M
Marlin > C Configuration.h ...
1326 /**
1327 * LED Control Menu
1328 * Add LED Control to the LCD menu
1329 */
1330 #define LED_CONTROL_MENU
1331 #if ENABLED(LED_CONTROL_MENU)
1332 #define LED_COLOR_PRESETS // Enable the Preset Color menu option
1333 //#define NEO2_COLOR_PRESETS // Enable a second NeoPixel Preset Color menu option
1334 #if ENABLED(LED_COLOR_PRESETS)
1335 #define LED_USER_PRESET_RED 255 // User defined RED value
1336 #define LED_USER_PRESET_GREEN 128 // User defined GREEN value
1337 #define LED_USER_PRESET_BLUE 0 // User defined BLUE value
1338 #define LED_USER_PRESET_WHITE 255 // User defined WHITE value
1339 #define LED_USER_PRESET_BRIGHTNESS 255 // User defined intensity
1340 //#define LED_USER_PRESET_STARTUP // Have the printer display the user preset color on startup
1341 #endiff
1342 #if ENABLED(NEO2_COLOR_PRESETS)
1343 #define NEO2_USER_PRESET_RED 255 // User defined RED value
1344 #define NEO2_USER_PRESET_GREEN 128 // User defined GREEN value
1345 #define NEO2_USER_PRESET_BLUE 0 // User defined BLUE value
1346 #define NEO2_USER_PRESET_WHITE 255 // User defined WHITE value
1347 #define NEO2_USER_PRESET_BRIGHTNESS 255 // User defined intensity
1348 //#define NEO2_USER_PRESET_STARTUP // Have the printer display the user preset color on startup for the second strip
1349 #endiff

```

```
#define LED_CONTROL_MENU // add LED control to your menu.
```

Filament Sensor

Standard filament run out sensors are usually comprised of a microswitch which signals the mainboard of filament status with High or Low level signal.



```

EXPLORER          C Configuration.h M X C Configuration_adv.h M
Marlin > C Configuration.h > ...
1462 #define FILAMENT_RUNOUT_SENSOR
1463 #if ENABLED(FILAMENT_RUNOUT_SENSOR)
1464 #define FIL_RUNOUT_ENABLED_DEFAULT true // Enable the sensor on startup. Override with M412 followed by M500.
1465 #define NUM_RUNOUT_SENSORS 1 // Number of sensors, up to one per extruder. Define a FIL_RUNOUT#_PIN for each.
1466
1467 #define FIL_RUNOUT_STATE LOW // Pin state indicating that filament is NOT present.
1468 #define FIL_RUNOUT_PULLUP // Use internal pullup for filament runout pins.
1469 // #define FIL_RUNOUT_PULLDOWN // Use internal pulldown for filament runout pins.
1470 // #define WATCH_ALL_RUNOUT_SENSORS // Execute runout script on any triggering sensor, not only for the active extruder.
1471 // This is automatically enabled for MIXING_EXTRUDERS.

```

```

#define FILAMENT_RUNOUT_SENSOR // enable filament run out sensor
#define FIL_RUNOUT_ENABLED_DEFAULT true // true default to filament run
out sensor enabled

```


```

#define NUM_RUNOUT_SENSORS 1 // number of filament run out sensor
#define FIL_RUNOUT_STATE LOW // voltage level of the filament runout
sensor trigger signal. Set according to the actual situation of the module. If the
module sends a low level when the filament is abnormal, set it to LOW.

```

Smart Filament Sensor (SFS V1.0)

The smart filament sensor works by continuously sending signal to the mainboard to communicate filament status.



```

EXPLORER          C Configuration.h M X C Configuration_adv.h M
Marlin > C Configuration.h > ...
1462 #define FILAMENT_RUNOUT_SENSOR
1463 #if ENABLED(FILAMENT_RUNOUT_SENSOR)
1464 #define FIL_RUNOUT_ENABLED_DEFAULT true // Enable the sensor on startup. Override with M412 followed by M500.
1465 #define NUM_RUNOUT_SENSORS 1 // Number of sensors, up to one per extruder. Define a FIL_RUNOUT#_PIN for each.
1466
1467 #define FIL_RUNOUT_STATE LOW // Pin state indicating that filament is NOT present.
1468 #define FIL_RUNOUT_PULLUP // Use internal pullup for filament runout pins...
1469 // Override individually if the runout sensors vary ...
1470
1471 // #define FIL_RUNOUT2_STATE LOW...
1472
1473 // #define FIL_RUNOUT3_STATE LOW...
1474
1475 // #define FIL_RUNOUT4_STATE LOW...
1476
1477 // #define FIL_RUNOUT5_STATE LOW...
1478
1479 // #define FIL_RUNOUT6_STATE LOW...
1480
1481 // #define FIL_RUNOUT7_STATE LOW...
1482
1483 // #define FIL_RUNOUT8_STATE LOW...
1484
1485 // Commands to execute on filament runout.
1486 // With multiple runout sensors use the %c placeholder for the current tool in commands (e.g., "M600 T%c")
1487 // NOTE: After 'M412 H' the host handles filament runout and this script does not apply.
1488 #define FILAMENT_RUNOUT_SCRIPT "M600"
1489
1490 // After a runout is detected, continue printing this length of filament
1491 // before executing the runout script. Useful for a sensor at the end of
1492 // a feed tube. Requires 4 bytes SRAM per sensor, plus 4 bytes overhead.
1493 #define FILAMENT_RUNOUT_DISTANCE_MM 3
1494
1495 // Enable this option to use an encoder disc that toggles the runout pin
1496 // as the filament moves. (Be sure to set FILAMENT_RUNOUT_DISTANCE_MM
1497 // large enough to avoid false positives.)
1498
1499 #define FILAMENT_MOTION_SENSOR
1500
1501 #endif
1502
1503 #endif
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522


```

```

#define FILAMENT_MOTION_SENSOR // set encoder type
#define FILAMENT_RUNOUT_DISTANCE_MM 7 // set sensitivity, SFS V1.0
nominal setting should be 7mm, which means if no signal of filament movement is
detected after 7mm of filament travel command, filament error will be triggered.

```


The settings below also need to be set to instruct the printer to park the nozzle after filament error is detected.



```

EXPLORER ... C Configuration.h M C Configuration_adv.h M
Marlin > C Configuration.h > ...
1907 #define NOZZLE_PARK_FEATURE
1908
1909 #if ENABLED(NOZZLE_PARK_FEATURE)
1910     // Specify a park position as { X, Y, Z raise }
1911     #define NOZZLE_PARK_POINT { (X_MIN_POS + 10), (Y_MAX_POS - 10), 20 }
1912     // #define NOZZLE_PARK_X_ONLY           // X move only is required to park
1913     // #define NOZZLE_PARK_Y_ONLY           // Y move only is required to park
1914     #define NOZZLE_PARK_Z_RAISE_MIN    2 // (mm) Always raise Z by at least this distance
1915     #define NOZZLE_PARK_XY_FEEDRATE   100 // (mm/s) X and Y axes feedrate (also used for delta Z axis)
1916     #define NOZZLE_PARK_Z_FEEDRATE    5 // (mm/s) Z axis feedrate (not used for delta printers)
1917 #endif

```



```


EXPLORER ... C Configuration.h M C Configuration_adv.h M
Marlin > C Configuration.h > ...
1907 #define NOZZLE_PARK_FEATURE
1908
1909 #if ENABLED(NOZZLE_PARK_FEATURE)
1910     // Specify a park position as { X, Y, Z raise }
1911     #define NOZZLE_PARK_POINT { (X_MIN_POS + 10), (Y_MAX_POS - 10), 20 }
1912     // #define NOZZLE_PARK_X_ONLY           // X move only is required to park
1913     // #define NOZZLE_PARK_Y_ONLY           // Y move only is required to park
1914     #define NOZZLE_PARK_Z_RAISE_MIN    2 // (mm) Always raise Z by at least this distance
1915     #define NOZZLE_PARK_XY_FEEDRATE   100 // (mm/s) X and Y axes feedrate (also used for delta Z axis)
1916     #define NOZZLE_PARK_Z_FEEDRATE    5 // (mm/s) Z axis feedrate (not used for delta printers)
1917 #endif

```

```

#define NOZZLE_PARK_FEATURE // park nozzle
#define NOZZLE_PARK_POINT { (X_MIN_POS + 10), (Y_MAX_POS - 10), 20 }
// set the X, Y and Z offset coordinate of the nozzle

```



```

EXPLORER ... C Configuration.h M C Configuration_adv.h M
Marlin > C Configuration_adv.h > ...
2488 * Requirements:
2489 * - For Filament Change parking enable and configure NOZZLE_PARK_FEATURE.
2490 * - For user interaction enable an LCD display, HOST_PROMPT_SUPPORT, or EMERGENCY_PARSER.
2491 *
2492 * Enable PARK_HEAD_ON_PAUSE to add the G-code M125 Pause and Park.
2493 */
2494 #define ADVANCED_PAUSE_FEATURE
2495 #if ENABLED(ADVANCED_PAUSE_FEATURE)

```

```

#define ADVANCED_PAUSE_FEATURE // retraction setting of nozzle park
movement and filament purge distance after the print is resumed.

```

Compile Firmware

1. Click "√" to compile firmware.



2. Copy the compiled "firmware.bin" to SD card and insert to motherboard to update firmware.


```
PROBLEMS 1 OUTPUT DEBUG CONSOLE TERMINAL
> ▾ TERMINAL
⌚ Compiling .pio\build\STM32H723Zx_btt\FrameworkArduino\wiring_time.c.o
⌚ Archiving .pio\build\STM32H723Zx_btt\libFrameworkArduino.a
⌚ Linking .pio\build\STM32H723Zx_btt\firmware.elf
⌚ Checking size .pio\build\STM32H723Zx_btt\firmware.elf
⌚ Advanced Memory Usage is available via "PlatformIO Home > Project Inspect"
⌚ RAM: [ ] 3.0% (used 17472 bytes from 577536 bytes)
⌚ Flash: [====] 37.4% (used 195880 bytes from 524288 bytes)
⌚ Building .pio\build\STM32H723Zx_btt\firmware.bin
===== [SUCCESS] Took 88.43 seconds =====
Environment      Status      Duration
-----  
STM32H723Zx_btt  SUCCESS  00:01:28.432
===== 1 succeeded in 00:01:28.432 =====
```

A screenshot of the PlatformIO IDE TERMINAL tab. It shows the build process for a STM32H723Zx_btt project. The terminal output includes compilation of source files, archiving of libraries, linking of the executable, memory usage analysis, and finally the successful building of the firmware binary. The status line at the bottom shows "1 succeeded in 00:01:28.432".


Klipper

Compiling the Firmware

1. Use the following configuration to compile the firmware (if these options are not available, please update the Klipper firmware source code to the latest version):



2. Press **q** to exit, and **Yes** when asked to save the configuration.
3. Run **make** to compile firmware, "klipper.bin" file will be generated in **home/pi/klipper/out** folder when **make** is finished, download it onto your computer using the SSH application.



4. Rename **klipper.bin** to "**firmware.bin**", copy to SD card to update firmware.


5. Enter: `ls /dev/serial/by-id/` in command line to check motherboard ID to confirm whether firmware is updated successfully, as shown below.

```
pi@fluiddp:~/klipper $ ls /dev/serial/by-id/
usb-Klipper_stm32h723xx 41003D001751303232383230-if00
pi@fluiddp:~/klipper $
```


copy and save this ID, it is needed when modifying klipper config.

Configuring Klipper

- Enter the Raspberry Pi's IP in a browser to access it. Download the motherboard's reference configuration in the path shown in the image below. If you cannot find this file, update the Klipper firmware source code to the latest version or download from GitHub: <https://github.com/bigtreech/BIGTREETECH-Kraken>



2. Upload the motherboard's configuration file to **Configuration Files** and include this configuration file in the **printer.cfg** file.



[include generic-bigtreetech-kraken.cfg]

```

printer.cfg

1 [include mainsail.cfg]
2
3 [include generic-bigtreetech-kraken.cfg]
4

```

3. Insert the correct motherboard ID.

```

generic-bigtreetech-kraken.cfg

7 [mcu]
8 serial: /dev/serial/by-id/usb-Klipper_stm32h723xx_kraken-if00

```

4. Refer to <https://www.klipper3d.org/Overview.html> for detailed configuration guide according to your machine type.

Firmware Updates

Updating via microSD

1. Ensure the microSD card is formatted as FAT32.
2. Rename the compiled firmware or the firmware downloaded from GitHub to "firmware.bin" (**note:** make sure the computer system's extension settings are clear, as some users hide the extension, and "firmware.bin" actually displays as "firmware").
3. Copy "firmware.bin" to the root directory of the microSD card.
4. Insert the microSD card into the motherboard's slot, power on the motherboard, and the bootloader will automatically update the firmware.
5. The status LED will blink during update.
6. When it stops and the file is renamed "FIRMWARE.CUR", the update is complete.

Updating Klipper via DFU

1. Run `ls /dev/serial/by-id/` to get the board ID. If Klipper is running, it will return a klipper ID.

```
pi@fluddpi:~/klipper $ ls /dev/serial/by-id/
usb-Klipper_stm32h723xx_41003D001751303232383230-if00
pi@fluddpi:~/klipper $
```

2. If `ls /dev/serial/by-id/` is able to find the MCU's klipper device ID, you can directly input: `cd ~klipper`
`make flash FLASH_DEVICE=/dev/serial/by-id/usb-Klipper_stm32h723xx_41003D001751303232383230-if00`
to write firmware (Note: Replace `/dev/serial/by-id/xxx` with the actual ID queried in the previous step)

```
bingu@urakura:~/Klipper$ make flash FLASH_DEVICE=/dev/serial/by-id/usb-Klipper_stm32g0b1xx_190028000050415833323520-if00
Building hid-flash
/bin/sh: 1: pkconfig: not found
hid-ash: /bin/sh: hid-ash: command not found; please install with:
sudo apt-get install libusb1.0
Flashing out/klipper.bin to /dev/serial/by-id/usb-Klipper_stm32g0b1xx_190028000050415833323520-if00
Entering bootloader on /dev/serial/by-id/usb-Klipper_stm32g0b1xx_190028000050415833323520-if00
Device reconnect on /sys/devices/platform/soc/S200000.usb/usb1/1-1/1-1.1:1.1:1
sudo dfu-util -p 1-1.1 -R -a 0 -s 0x8002000:leave -D out/klipper.bin
dfu-util 0.9

Copyright 2005-2009 Weston Schmidt, Harald Welte and OpenMoko Inc.
Copyright 2010-2016 Tormod Volden and Stefan Schmidt
This program is Free Software and has ABSOLUTELY NO WARRANTY
Please report bugs to http://sourceforge.net/p/dfu-util/tickets/

dfu-util: Invalid DFU suffix signature
dfu-util: A valid DFU suffix will be required in a future dfu-util release!!!
Opening DFU Capable USB device...
ID 0483:df11
Run-time device DFU version 011a
Claiming USB DFU Interface...
Setting Alternative setting #0 ...
Detected DFU device status: state = dfuIDLE, status = 0
dfuIDLE, continuing
DFU mode device DFU version 011a
Device returned transfer size 1024
DfuSe interface name: "Internal Flash"
Download pending to address = 0x08002000, size = 25264
Download [=====] 100% 25264 bytes
Download done.
File downloaded successfully
dfu-util: Error during download get_status

Failed to flash to /dev/serial/by-id/usb-Klipper_stm32g0b1xx_190028000050415833323520-if00: Error running dfu-util
If the device is already in bootloader mode it can be flashed with the
following command:
make flash FLASH_DEVICE=0483:df11
OR
make flash FLASH_DEVICE=1209:beba
If attempting to flash via 3.3V serial, then use:
make serialflash FLASH_DEVICE=/dev/serial/by-id/usb-Klipper_stm32g0b1xx_190028000050415833323520-if00
```

After writing completes, there may be an error message **dfu-util: Error during download get_status**, just ignore it.

Precautions

1. Forbidden to switch driver voltage when stepper motors are in motion;
2. When switching stepper motor driver voltage, ensure no control signals are being output from the MCU to the driver chips;
3. When driver current exceeds 7A, it is recommended to add a cooling fan for the driver for heat dissipation.

If you need further resources for this product, you can find them at [GitHub](<https://github.com/bigtreeetech/>). If you cannot find what you need, you may contact our after-sales support(service005@biqu3d.com).

If you encounter any other problems during use or have suggestions or feedback, please contact us. Thank you for choosing BIGTREETECH products.