240VAC UPS SUPPLY
FROM F16-DB-201
2000-F16-TLD-EL-10057

240VAC
1
240VAC
3
F16RIO100P1-L
F16RIO100P1-N
240VAC
2
240VAC
4

Q006
10A
0060

Q007
10A
0076

F16RIO100-PS1
PHOENIX
QUINT4-PS/1AC/24DC/20
240VAC/24VDC, 20A POWER SUPPLY

F16RIO100-PS2
PHOENIX
QUINT4-PS/1AC/24DC/20
240VAC/24VDC, 20A POWER SUPPLY

DC OK
13
14
F16RIO100PS1+24VDC
F16RIO100PS1
POWER SUPPLY 1
24VDC HEALTHY
TO 2000-F16-TER-IC-10012

DC OK
13
14
F16RIO100PS2+24VDC
F16RIO100PS2
POWER SUPPLY 2
24VDC HEALTHY
TO 2000-F16-TER-IC-10012

(+24VDC)
(0VDC)
0131
0137
0130
0138

F16RIO100-RM
PHOENIX
QUINT-ORING/24DC/2x20/1x40
REDUNDANCY MODULE

(+24VDC)
(0VDC)
Q022
20A

0220
0205

Q025
6A
0250
S025
DOOR
0255
WH
0VDC
1
PANEL LIGHT

Q028
2A
0280
F16SR001-LCS
2000-F16-TER-EL-10201
0VDC
2
F16SR001-LCS
SWITCHROOM
EMERGENCY SHUTDOWN
24VDC POWER SUPPLY

FIELD CONTROL UNIT
Q032
6A
0320
POWER SUPPLY 1
POWER SUPPLY 2
0VDC
3
F16-FCS-414
FIELD CONTROL UNIT
24VDC POWER SUPPLIES

Q034
6A
0VDC
4
SPARE
24VDC POWER SUPPLY

Q036
2A
0VDC
5
SPARE
24VDC POWER SUPPLY

Q038
2A
0VDC
6
SPARE
24VDC POWER SUPPLY

0220
24VDC SUPPLY
CONT'D ON LINE 51
0205

(+24VDC)
(0VDC)
0220
24VDC SUPPLY
CONT'D FROM LINE 048
0205

Q053
10A
0530
Q054
10A
0540
POWER SUPPLY 1
POWER SUPPLY 2
NODE INTERFACE UNIT
F16FCS408-NU18
0VDC
7
0VDC
8
YOKOGAWA - NIU
NETWORK I/O NODE
A2NN3D-440001102

Q060
10A
0600
24VDC FIELD POWER
2000-F16-TER-IC-10012
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-01
DIGITAL INPUT
TM
0VDC
9
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

Q065
10A
0650
24VDC FIELD POWER
2000-F16-TER-IC-10013
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-02
DIGITAL INPUT
TM
0VDC
10
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

Q070
10A
0700
24VDC FIELD POWER
2000-F16-TER-IC-10014
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-03
DIGITAL OUTPUT
TM
0VDC
11
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

Q075
10A
0750
24VDC FIELD POWER
2000-F16-TER-IC-10015
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-04
ANALOGUE INPUT
TM
0VDC
12
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

NOTES

1. TERMINALS ON TERMINAL STRIPS ABOVE 50VAC SHALL HAVE A SEPARATE PERSPEX SHROUD AND SHALL BE LABELLED "DANGER xxxVAC".
2. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. F16RIO100-xxxx.
3. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.
4. FOR NETWORK CONNECTION & BUS CABLING DETAILS REFER TO RIO PANEL COMMUNICATIONS TERMINATION DIAGRAMS.
5. INSTRUMENT EARTH BAR TO BE BONDED TO MAIN EARTH BAR WITH SOLID COPPER LINK.

LEGEND

- FIELD TERMINAL
- DCS OR I/O TERMINAL
- 0VDC TERMINAL FOR 24VDC (2)
- DEVICE TERMINAL
- EARTH BAR
- INSTRUMENT EARTH BAR

NIO BASEPLATE

F16FCS408NU18-01
- NETWORKED INPUT/OUTPUT (N-IO) BASEPLATE
- NODE INTERFACE UNIT (N-IU)
- FIELD CONTROL UNIT

2000-F16-SCM-IC-10011_Rev2

F16-SR-001 - F16-RIO-100 11kV SWITCHROOM
N-IO PANEL - SCHEMATIC DIAGRAM