240VAC UPS SUPPLY
FROM F16-DB-201
2000-F16-TLD-EL-10057

240VAC
240VAC
F16RIO100P1-L
F16RIO100P1-N
240VAC
240VAC

Q006
10A
0060

Q007
10A
0076

F16RIO100-PS1
PHOENIX
QUINT4-PS/1AC/24DC/20
240VAC/24VDC, 20A POWER SUPPLY

F16RIO100-PS2
PHOENIX
QUINT4-PS/1AC/24DC/20
240VAC/24VDC, 20A POWER SUPPLY

DC OK
13
14
F16RIO100PS1+24VDC
F16RIO100PS1
POWER SUPPLY 1
24VDC HEALTHY
TO 2000-F16-TER-IC-10012

DC OK
13
14
F16RIO100PS2+24VDC
F16RIO100PS2
POWER SUPPLY 2
24VDC HEALTHY
TO 2000-F16-TER-IC-10012

(+24VDC)
(0VDC)
0131
0137
0130
0138

F16RIO100-RM
PHOENIX
QUINT-ORING/24DC/2x20/1x40
REDUNDANCY MODULE

(+24VDC)
(0VDC)
Q022
20A

0220
0205

Q025
6A
0250
S025
DOOR
0255
WH
0VDC
1
PANEL LIGHT

Q028
2A
0280
F16SR001-LCS
2000-F16-TER-EL-10201
F16SR001-LCS
SWITCHROOM
EMERGENCY SHUTDOWN
24VDC POWER SUPPLY

FIELD CONTROL UNIT
POWER SUPPLY 1
POWER SUPPLY 2
Q032
6A
0320
F16-FCS-414
FIELD CONTROL UNIT
24VDC POWER SUPPLIES

Q034
6A
SPARE
24VDC POWER SUPPLY

Q036
2A
SPARE
24VDC POWER SUPPLY

Q038
2A
SPARE
24VDC POWER SUPPLY

0220
24VDC SUPPLY
CONT'D ON LINE 51
0205

(+24VDC)
(0VDC)
0220
24VDC SUPPLY
CONT'D FROM LINE 048
0205

Q053
10A
0530
Q054
10A
0540
POWER SUPPLY 1
POWER SUPPLY 2
NODE INTERFACE UNIT
F16FCS408-NU18
YOKOGAWA - NIU
NETWORK I/O NODE
A2NN3D-440001102

Q060
10A
0600
24VDC FIELD POWER
2000-F16-TER-IC-10012
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-01
DIGITAL INPUT
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

Q065
10A
0650
24VDC FIELD POWER
2000-F16-TER-IC-10013
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-02
DIGITAL INPUT
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

Q070
10A
0700
24VDC FIELD POWER
2000-F16-TER-IC-10014
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-03
DIGITAL OUTPUT
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

Q075
10A
0750
24VDC FIELD POWER
2000-F16-TER-IC-10015
FIELD POWER - I/O BASE PLATE
16 CHANNEL I/O MODULE
F16FCS408NU18-04
ANALOGUE INPUT
16 CHANNEL NIO
BASEPLATE
A2BN3D-01020/L

NOTES

1. TERMINALS ON TERMINAL STRIPS ABOVE 50VAC SHALL HAVE A SEPARATE PERSPEX SHROUD AND SHALL BE LABELLED "DANGER xxxVAC".
2. WIRE NUMBER FERRULES ON TERMINAL STRIP SHALL BE PREFIXED WITH EQUIPMENT NUMBER e.g. F16RIO100-xxxx.
3. EACH WIRE SHALL BE IDENTIFIED AT BOTH ENDS WITH FERRULES.
4. FOR NETWORK CONNECTION & BUS CABLING DETAILS REFER TO RIO PANEL COMMUNICATIONS TERMINATION DIAGRAMS.
5. INSTRUMENT EARTH BAR TO BE BONDED TO MAIN EARTH BAR WITH SOLID COPPER LINK.

LEGEND

- FIELD TERMINAL
- DCS OR I/O TERMINAL
- 0VDC TERMINAL FOR 24VDC
- DEVICE TERMINAL
- EARTH BAR
- INSTRUMENT EARTH BAR

NIO BASEPLATE

F16FCS408NU18-01

- NETWORKED INPUT/OUTPUT (N-IO) BASEPLATE
- NODE INTERFACE UNIT (N-IU)
- FIELD CONTROL UNIT

2000-F16-SCM-IC-10011_Rev2

F16-SR-001 - F16-RIO-100 11kV SWITCHROOM
N-IO PANEL - SCHEMATIC DIAGRAM

O:\CAD PROJECTS\235 NORTHERN STAR RESOURCES LTD\23517 KCGM GROWTH PROJECT\03 DELIVERABLES\IC\F16 - ROUGHER & SCAVENGER FLOTATION\2000-F16-SCM-IC-10011.DWG 14-JUL-25 10:24 AM ANTONY.DECAPRIO