

SCHEME WATER DISTRIBUTION
2000-F24-PID-PR-10006
SCHEME WATER

RAW WATER BOOSTER PUMP
2000-F24-PID-PR-10020
RAW WATER
RAW WATER BOOSTER PUMP
2000-F24-PID-PR-10020
RAW WATER

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-1602-PSW-PE16-32
100VBFEL2
F12-11071

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

12-0001-BW-PE16-110
12-0995-BW-PE16-32

12-1735-IA-MSG3-25
PRIMARY CRUSHER 2
AIR RECEIVER
2000-F12-PID-PR-10012
PLANT AIR
25VB03S1
F12-10016
LO

PRIMARY CRUSHER 2 DISCHARGE
2000-F12-PID-PR-10001
DUST
DUCT
SLIDE GATE

PRIMARY CRUSHER 2 DISCHARGE
CONVEYOR FEED CHUTE
2000-F12-PID-PR-10001
COARSE ORE

PRIMARY CRUSHER 2 DISCHARGE
APRON FEEDER DRIBBLE CHUTE
2000-F12-PID-PR-10001
COARSE ORE

YA 12505A START

YA 12505A

YA 12559A

PRIMARY CRUSHER 2
DISCHARGE APRON FEEDER VSD
2000-F12-PID-PR-10001
SIGNAL

PRIMARY CRUSHER 2
DISCHARGE APRON FEEDER VSD
2000-F12-PID-PR-10001
SIGNAL

PRIMARY CRUSHER 2
DISCHARGE APRON FEEDER VSD
2000-F12-PID-PR-10001
SIGNAL

PRIMARY CRUSHER 2
DISCHARGE APRON FEEDER VSD
2000-F12-PID-PR-10001
SIGNAL

NOTES:

1. PART OF PRIMARY CRUSHER 2 VENDOR PACKAGE.

2.

3.

4.

5.

6.

7.

8.

9.

10.

11.

12.

13.

14.

15.

16.

17.

18.

19.

20.

21.

22.

23.

24.

25.

26.

27.

28.

29.

30.

31.

32.

33.

34.

35.

36.

37.

38.

39.

40.

41.

42.

43.

44.

45.

46.

47.

48.

49.

50.

51.

52.

53.

54.

55.

56.

57.

58.

59.

60.

61.

62.

63.

64.

65.

66.

67.

68.

69.

70.

71.

72.

73.

74.

75.

76.

77.

78.

79.

80.

81.

82.

83.

84.

85.

86.

87.

88.

89.

90.

91.

92.

93.

94.

95.

96.

97.

98.

99.

100.

101.

102.

103.

104.

105.

106.

107.

108.

109.

110.

111.

112.

113.

114.

115.

116.

117.

118.

119.

120.

121.

122.

123.

124.

125.

126.

127.

128.

129.

130.

131.

132.

133.

134.

135.

136.

137.

138.

139.

140.

141.

142.

143.

144.

145.

146.

147.

148.

149.

150.

151.

152.

153.

154.

155.

156.

157.

158.

159.

160.

161.

162.

163.

164.

165.

166.

167.

168.

169.

170.

171.

172.

173.

174.

175.

176.

177.

178.

179.

180.

181.

182.

183.

184.

185.

186.

187.

188.

189.

190.

191.

192.

193.