NOTES:

1. PROCESS SWITCHPOINTS USED TO AUTO INITIATE THE BALL CHARGING SEQUENCE IF F19-BLC-401 IS IN LOCAL/REMOTE AUTO MODE AND AUTO START IS ENABLED.

BALL CHARGING MAGNET BIN CHUTE
2000-F19-PID-PR-10007
BALL MILL BALLS
MECH

FME-19-PI-408

BALL CHARGING MAGNET BIN CHUTE
2000-F19-PID-PR-10007
SAG MILL BALLS
MECH

19-615-IA-MSG-025

BALL CHARGING MAGNET BIN CHUTE
2000-F19-PID-PR-10007
SAG MILL BALLS

NOTE 1

LI 19755 H L
LIT 19755
LE 19755
LI 19756 H L
LIT 19756
LE 19756
LI 19757 H L
LIT 19757
LE 19757

19-619-IA-MSG-015
19-618-IA-MSG-015
25x15
15V301

19-BN-61A
19-BN-61B
19-BN-61C

SV 19660
SV 19661
SV 19662

ZA 19674E
ZS 19674E
ZS 19674F

ZA 19674C
ZS 19674C
ZS 19674D

19-FE-61
19-CH-82A 3
19-FE-62
19-CH-82B 3
19-FE-63
19-CH-82C 3

19-CV-62

SSL 19673
ZS 19674A
ZS 19674B
HS 19675A
HS 19675B
HS 19675C

19-CH-67 3

SAL 19673
ZA 19674A
HA 19675A
HA 19675C

UA 19550C
CONVEYOR START WARNING SIREN

19-616-IA-MSG-015
19-615-CA-MSG-025
25x50
FME-19-PI-419
19-617-IA-MSG-015

SV 19663
19-DG-61 3
SV 19664
19-DG-51 3

SSL 19676
ZS 19677A
ZS 19677B
19-CV-63
19-CH-62 3
HS 19678A
HS 19678B
19-CH-58 3

SAL 19676
ZA 19677A
HA 19678A

TO FIM SAG MILL 19-MS-61 FME-19-PI-419 2000-F19-PID-PR-10001

TO MT. CHARLOTTE SAG MILL 19-MS-51 FME-19-PI-404

HS
HS
I
SV
S
IA
ZSH
ZSH
ZSL
ZSL

TYPICAL BALL CHARGE ACTUATOR ARRANGEMENT

19-CH-82A	CONVEYOR CV62 FEED CHUTE No. 1
19-CH-82B	CONVEYOR CV62 FEED CHUTE No. 2
19-CH-82C	CONVEYOR CV62 FEED CHUTE No. 3
19-BN-61A	BALL CHARGING BIN No. 1
19-BN-61B	BALL CHARGING BIN No. 2
19-BN-61C	BALL CHARGING BIN No. 3
19-CV-62	BALL CHARGE CONVEYOR No. 1
19-FE-61	BALL FEEDER No. 1
19-FE-62	BALL FEEDER No. 2
19-FE-63	BALL FEEDER No. 3
19-CH-67	CONVEYOR CV62 HEAD CHUTE
19-CH-62	FIM SAG MILL BALL FEED CHUTE
19-CH-58	MT. CHARLOTTE SAG MILL BALL FEED CHUTE
19-CH-74	CONVEYOR CV63 HEAD CHUTE
19-CV-63	BALL CHARGE CONVEYOR No. 2
19-DG-51	MT CHARLOTTE SAG MILL DIVERTER GATE
19-DG-61	FIM SAG MILL DIVERTER GATE