HW4.7. RISC-V-Binary Translation (Randomized)

Feel free to check out the guide that we have prepared to help you in this problem.

For the following problems, you would need to refer to the <u>Reference Card</u> to help you with the conversion.

Translate the following instructions from RISC-V to hexadecimal. Note that we use integer values for branches and jumps, instead of labels (this is permitted by the ISA, but normally discouraged since it makes debugging incredibly hard).

Q1.1: auipc s6 11



Translate the following instructions from hexadecimal to RISC-V. Follow these conventions when writing your answer:

Do not include commas in your answer.


For immediates, submit a number in decimal. We have guaranteed that all immediates have absolute value 100 or less.

As with the above, use integer values for branches and jumps.

Use the register names (s0, a4, etc.) for all registers except register x0 (which should use x0).

Save only

Q2.1: 0x041B5703



Save & Grade 20 attempts left

Additional attempts available with new variants **②**

