ChatGPT Free offer ×

What is the typical procedure to setup cameras for Hik vision camera, like installing the camera, setting MVR or something and setting up admin password and encryption password? There are just my assumption, please suggest in great detail what components are used as I am complete nood, what components are used, procedure, in step by step, please explain for general procedure like that applies to any camera set up as well as for Hik Vision camera separately

You're broadly on the right track, but the terminology and flow matter. I'll structure this in two layers:

1. **Generic IP CCTV setup (applies to most systems)**
2. **Specific workflow for Hikvision systems**

---

1) Core Components (What you actually need)

Hardware

- **Cameras (IP cameras)** – capture video (bullet, dome, PTZ)
- **Recorder**
  - **NVR (Network Video Recorder)** → for IP cameras
  - **DVR (Digital Video Recorder)** → for analog cameras
- **Storage** – HDD installed inside NVR
- **Switch**
  - **PoE switch** (Power over Ethernet) → powers cameras + data via one cable
- **Router** – connects system to internet (for remote viewing)
- **Cables**
  - Ethernet (Cat5e/Cat6)
  - Power cables (if not PoE)
- **Monitor + Mouse** – for local setup

Software / Logical Components

- Camera firmware
- NVR firmware
- Mobile/desktop app (e.g., Hik-Connect)
- Network configuration (IP addressing)
- User credentials (admin password, encryption key)

---

2) General CCTV Setup Procedure (Vendor-agnostic)

Step 1: Physical Installation

1. Mount cameras at required locations
2. Run Ethernet cables from cameras to switch/NVR
3. Power cameras:
   - Via PoE → no separate power needed
   - Otherwise → use adapter

Step 2: Network Topology Setup

Two common designs:

Option A: NVR with built-in PoE (simplest)

```
Camera → NVR → Router → Internet
```

Option B: External PoE switch

```
Camera → PoE Switch → Router → NVR
```

Step 3: Power On & Initial Access

- Connect monitor + mouse to NVR
- Boot system
- First-time setup wizard appears

Step 4: Activate Devices

Modern systems require **activation** (security measure):

- Set **admin password**
- Sometimes set **unlock pattern or recovery email**
- Cameras may also need activation separately

Step 5: IP Address Configuration

- Each device must have a **unique IP**
- Two approaches:
  - DHCP (automatic)
  - Static IP (recommended for stability)

Example:

```
NVR: 192.168.1.100
Camera1: 192.168.1.101
Camera2: 192.168.1.102
```

Step 6: Add Cameras to Recorder

- NVR auto-detects cameras OR
- Manually add using:
  - IP address
  - Username/password of camera

Step 7: Storage Configuration

- Install HDD in NVR
- Format disk
- Set recording mode:
  - Continuous
  - Motion detection
  - Scheduled

Step 8: Remote Viewing Setup

Two methods:

Easy (Cloud / P2P)

- Scan QR code
- Login via app
- No port forwarding needed

Advanced (Port Forwarding)

- Configure router ports
- Access via public IP

Step 9: Security Configuration

- Strong admin password
- Enable encryption
- Disable unused services
- Firmware updates

---

3) Hikvision-Specific Setup (What changes)

Tools Used

- **SADP Tool**
- **Hik-Connect**

Step-by-Step for Hikvision

Step 1: Connect Everything

- Plug cameras into NVR PoE ports OR switch
- Connect NVR to router
- Power ON

Step 2: Device Activation (Critical Step)

Hikvision devices are **inactive by default**

Using monitor (local setup)

- First boot → “Activation” screen
- Set:
  - **Admin password**
  - Confirm password

Using SADP Tool (PC method)

- Detect devices on network
- Select device → “Activate”
- Set password

Step 3: Set Encryption / Verification Code

This is what you referred to as “encryption password”

- Used for **remote access (Hik-Connect)**
- Called:
  - Verification Code / Encryption Key

Example:

```
ABCDEF
```

Step 4: Assign IP Addresses

Using SADP Tool:

- Modify IP if needed
- Match your network subnet

Step 5: Add Cameras to NVR

If using Hikvision NVR:

- Usually **plug-and-play**
- Cameras auto-added

If manual:

- Go to Camera Management
- Add:
  - IP
  - Username: admin
  - Password: (camera password)

Step 6: Configure Recording

- Menu → Storage → HDD
- Initialize disk
- Set recording schedule

Step 7: Enable Remote Access

Using Hik-Connect:

1. Enable platform access in NVR
2. Scan QR code via app
3. Enter **verification code**

Step 8: Final Checks

- Live view working
- Playback working
- Remote access working
- Time/date correct

Common Mistakes (Avoid These)

- Using weak passwords → security risk
- IP conflicts → cameras not showing
- Not activating cameras → no video
- Wrong subnet → devices can’t communicate
- Forgetting encryption code → remote access fails

Quick Mental Model

Think of it like this:

- Cameras = input devices
- NVR = server + storage
- Router = internet gateway
- App = client interface

If You Want Practical Guidance

I can walk you through:

- Exact wiring diagram for your setup
- Recommended equipment list (budget vs professional)
- Troubleshooting when cameras don’t show

Just tell me:

- Number of cameras
- Indoor/outdoor
- Budget range

