



## APPLICATION NOTE

# Single-port I2C/SMBus/I3C operation for NVMe-MI on Binho Supernova

AN0014

## Document information

|                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Keywords</b> | AN0014, Supernova, I3C, I2C, SMBus, MCTP, clock stretching, legacy I2C, tTIMEOUT, NVMe-MI, ARP, Hot-Join, PIC18F16Q20, pyCosmicSDK                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Abstract</b> | Many SMBus and MCTP devices hold SCL low while they prepare a response. The Supernova's I3C engine cannot wait for that, so on its I3C port such a target used to lose bits. Adapter firmware 4.6.0 and pyCosmicSDK 1.6.0 add a mode in which legacy I2C transfers on the I3C port wait for the target, up to the SMBus 35 ms timeout. This note explains the mode, supplies a script that reads and writes a stretching target with it, and supplies the firmware of the reference target used to measure it: 1200 of 1200 reads correct at 100 kHz and 400 kHz, with the target stretching from 0 to 30 ms, and every stretched read correct up to the mode's ceiling of 746 kHz. The script also runs the SMBus to I3C Basic detection flow of the PCI-SIG out-of-band management specification as far as the adapter can. |

# 1 Introduction

An I2C target may hold SCL low after it acknowledges its address, to gain time before it answers. The controller must wait until SCL is released. The I2C specification calls this clock stretching, and SMBus allows it for up to 35 ms (tTIMEOUT). SMBus and MCTP devices use it routinely: a management controller that is fetching a value holds the clock until the value is ready.

The Supernova's I3C port can address legacy I2C targets on the same bus as I3C devices. Its I3C engine, however, keeps clocking while a target holds SCL low, so a stretching target misses bits and the transfer returns wrong data or no acknowledge. Adapter firmware 4.6.0 and pyCosmicSDK 1.6.0 add a mode that fixes this for legacy I2C transfers on the I3C port.

## 1.1 Scope

This document covers:

- what the clock-stretching mode changes, and what it refuses while it is on
- the SCL rates it runs at and how close they come to the request
- a script that reads and writes a stretching target through the mode
- a reference target that stretches for a configurable time, and its firmware
- measured results against that target
- the SMBus to I3C Basic detection flow used for NVMe-MI, and which of its steps the adapter performs

It does not cover SMBus framing beyond the PEC check of an ARP Get UDID (block read and write, quick command), MCTP or NVMe-MI messages, or the Supernova's separate I2C port.

## 1.2 Applicable devices

**Table 1.** Applicable devices

| Role             | Part                                 | Identifier                                                                                | Basis                                                     |
|------------------|--------------------------------------|-------------------------------------------------------------------------------------------|-----------------------------------------------------------|
| Controller       | Binho Supernova                      | hardware revision C, firmware 4.6.0 pre-release build <code>def51e1c</code> , I3C HV port | measured, this document                                   |
| Controller       | Binho Supernova                      | firmware 4.5.1 or earlier                                                                 | refuses the mode with <code>FW_UNSUPPORTED_COMMAND</code> |
| Controller       | Binho Pulsar                         | any                                                                                       | not applicable: the Pulsar has no I3C port                |
| Reference target | Microchip PIC18F16Q20 Curiosity Nano | firmware <code>stretch_target_pic18q20.c</code>                                           | measured, this document                                   |

**Note:** this revision was written against pre-release builds. The firmware reports its version as 4.5.1 with a build suffix because the version string had not yet been moved to 4.6.0. The mode and its behavior are those of the 4.6.0 release.

### 1.3

#### Related documents

**Table 2.** Related documents

| Document    | Title                                                                                         |
|-------------|-----------------------------------------------------------------------------------------------|
| UM10204     | I2C-bus specification and user manual, Rev. 7, NXP Semiconductors                             |
| SMBus 3.2   | System Management Bus Specification, version 3.2                                              |
| PCI-SIG ECN | PCI-SIG Engineering Change Notice: Chapter 12. Architectural Out-of-Band Management           |
| AN0015      | Setting the I2C SCL duty cycle and an exact bus frequency with the Binho Supernova and Pulsar |

## 2

### System overview

With the mode off, `legacy_i2c_read` and `legacy_i2c_write` on the I3C port are carried out by the I3C engine, which drives SCL on its own schedule. With the mode on, the adapter's firmware clocks those transfers in software and checks SCL after every phase it releases. When a target holds SCL low, the firmware waits.

Four facts shape how the mode is used:

- **It is a mode, not a per-transfer option.** `enable_i2c_clock_stretching(frequency_hz)` turns it on for every later legacy I2C transfer; `disable_i2c_clock_stretching()` turns it off. `initialize` and `configure` also turn it off.
- **It excludes I3C traffic.** While it is on, SDR, HDR and CCC calls, `init_bus` and `reset_bus` raise `I3cError` with status `FW_I3C_I2C_CLOCK_STRETCHING_ACTIVE`. Turn it off before talking to an I3C device.
- **It enforces the SMBus timeout.** A stretch longer than 35 ms ends the transfer with `FW_BUS_TIMEOUT`, and the bus is released.
- **The rate is never above the request.** The call returns the rate in effect. It is 10 kHz to 1 MHz; at 100 kHz the adapter runs at 97975 Hz, at 400 kHz at 391644 Hz. The software clock tops out at 746268 Hz, so 800 kHz and 1 MHz requests both run there.

## 3 Hardware setup

### 3.1 Required equipment

**Table 3.** Required equipment

| Item                                                                              |
|-----------------------------------------------------------------------------------|
| Binho Supernova, firmware 4.6.0 or later                                          |
| USB-C cable                                                                       |
| An I2C or SMBus target that stretches SCL, or the reference target of section 3.4 |
| Pull-up resistors on SCL and SDA, if the target board has none                    |

### 3.2 Connections

**Table 4.** Connections between the Supernova I3C HV port and the target

| Supernova I3C HV port | Target            | Required                                            |
|-----------------------|-------------------|-----------------------------------------------------|
| SCL                   | SCL               | required                                            |
| SDA                   | SDA               | required                                            |
| GND                   | GND               | required                                            |
| VTARG                 | target I/O supply | optional, if the target is powered from the adapter |

### 3.3 Bus considerations

The I3C port has no pull-up on SCL. An I2C bus needs one on both lines. On our bench it came from a Binho Pulsar's I2C port set to 1 kOhm and left idle; a pair of 1 kOhm to 2.2 kOhm resistors to the bus voltage does the same job. Without a pull-up on SCL the reported rate drops sharply, because the firmware waits for every rising edge.

**Caution:** the I3C HV port selects its voltage from `set_voltage` : 1200 mV to 3300 mV. Set it to the target's I/O voltage before connecting a target that is not 3.3 V tolerant.

**Caution:** only one controller on the bus. If a second adapter supplies the pull-up, do not start transfers from it.

### 3.4 The reference target

To measure the mode we needed a target whose stretch we could set.

`stretch_target_pic18q20.c`, in the assets archive, turns a PIC18F16Q20 Curiosity Nano into one. Its I2C peripheral holds SCL after every address match for a programmable time, which is how a busy SMBus device behaves.

**Table 5.** Reference target protocol, address 0x2A

| Transfer                        | Effect                                                                                 |
|---------------------------------|----------------------------------------------------------------------------------------|
| write 0xF0, low byte, high byte | stretch that many microseconds after every later address match; 0 turns stretching off |
| read                            | returns 0xA5 for every byte                                                            |
| any other write                 | accepted and discarded                                                                 |

SCL and SDA are on RB6 and RB5. Build it with MPLAB XC8 and program it with MPLAB X or the Curiosity Nano's drag-and-drop programmer.

## 4 Software setup

Install pyCosmicSDK 1.6.0 or later:

```
pip install "pycosmicsdk>=1.6.0"
```

The script `smbus_stretch.py` is in the assets archive. It needs nothing else.

## 5 The clock-stretching mode

### 5.1 Using it

The calls in isolation:

```
import pycosmicsdk as p

dev = p.Device.open(model=p.DeviceModel.SUPERNOVA)
i3c = dev.i3c()
i3c.set_voltage(voltage_mv=3300)
i3c.bring_up(
    push_pull_rate=p.I3cPushPullRate.PUSH_PULL_1_MHZ_DC_40,
    open_drain_rate=p.I3cOpenDrainRate.OPEN_DRAIN_100_KHZ,
    i2c_open_drain_rate=p.I2cOpenDrainRate.STANDARD_MODE,
)
print(i3c.enable_i2c_clock_stretching(100_000))
# I2cClockStretching(enabled=True, frequency_hz=97975)
data = i3c.legacy_i2c_read(0x2A, 16)
i3c.disable_i2c_clock_stretching()
```

A register read, the SMBus Read Byte or Read Word pattern, passes the register as `subaddress`: `i3c.legacy_i2c_read(0x0B, 2, subaddress=bytes([0x09]))`.

## 5.2 Status codes

**Table 6.** Status codes specific to the mode

| Status                                          | Raised by                                                     | Meaning                               |
|-------------------------------------------------|---------------------------------------------------------------|---------------------------------------|
| <code>FW_UNSUPPORTED_COMMAND</code>             | enable, disable                                               | firmware 4.5.1 or earlier             |
| <code>FW_INVALID_PARAMETER</code>               | enable                                                        | rate outside 10 kHz to 1 MHz          |
| <code>FW_INTERFACE_NOT_INITIALIZED</code>       | enable, disable                                               | the I3C controller was not brought up |
| <code>FW_I3C_I2C_CLOCK_STRETCHING_ACTIVE</code> | SDR, HDR, CCC, <code>init_bus</code> , <code>reset_bus</code> | the mode is on; turn it off first     |
| <code>FW_BUS_TIMEOUT</code>                     | legacy read or write                                          | the target held SCL longer than 35 ms |

## 5.3 The SMBus timeout

During firmware validation, with the reference target set to stretch 40 ms, 100 reads returned 50 `FW_BUS_TIMEOUT` and 50 `FW_I3C_NACK_ADDRESS`, the longest in 46 ms, and the adapter stayed responsive. The address NACKs come from the target, which misses the next address while it is still counting out its 40 ms.

## 6 Procedure

1. Connect the target and the pull-ups as in section 3.2. Power the target.
2. Read from the target. The first line shows the firmware and the rate in effect:

```
$ python smbus_stretch.py read 0x2A 16
FW-4.5.1-def51e1c I3C port 3300 mV stretching on, SCL 97975 Hz
read 0x2A: a5 a5 a5 a5 a5 a5 a5 a5 a5 a5 a5 a5 a5 a5 a5
```

3. Write to it:

```
$ python smbus_stretch.py write 0x2A 0x01 0x02 0x03
FW-4.5.1-def51e1c I3C port 3300 mV stretching on, SCL 97975 Hz
write 0x2A: 01 02 03
```

4. With the reference target, sweep the stretch. For each duration the script sets the target's stretch, reads 16 bytes 100 times, and checks every byte:

```
$ python smbus_stretch.py sweep
FW-4.5.1-def51e1c I3C port 3300 mV stretching on, SCL 97975 Hz
stretch reads ok median ms result
    0 us   100 100      6.19 all bytes correct
    50 us   100 100      6.79 all bytes correct
   500 us   100 100      7.13 all bytes correct
  2000 us   100 100      9.26 all bytes correct
 10000 us   100 100     17.89 all bytes correct
 30000 us   100 100     39.05 all bytes correct
```

5. Repeat at 400 kHz:

```
$ python smbus_stretch.py --kHz 400 sweep
FW-4.5.1-def51e1c I3C port 3300 mV stretching on, SCL 391644 Hz
stretch reads ok median ms result
    0 us   100 100      5.08 all bytes correct
    50 us   100 100      5.04 all bytes correct
   500 us   100 100      6.35 all bytes correct
  2000 us   100 100      8.46 all bytes correct
 10000 us   100 100     16.78 all bytes correct
 30000 us   100 100     37.92 all bytes correct
```

The median time per read grows with the stretch, and by about the stretch: the adapter waited each time. The script sets the target's stretch back to 0 before it exits.

## 7

### The SMBus to I3C Basic detection flow

NVMe-MI devices that move from SMBus to I3C Basic share one pair of pins, so the host has to find out which protocol each device speaks before it changes the bus. The flow the host follows is defined in the PCI-SIG Engineering Change Notice, Chapter 12, Architectural Out-of-Band Management. The `handoff` command of `smbus_stretch.py` runs it on the Supernova I3C port. Table 7 lists the steps and who performs each.

**Table 7.** Detection flow steps

| Step | Flow                                                                                             | Performed by                                                                                                                                                                                                                            |
|------|--------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1    | Broadcast DISEC with DISHJ to 7Eh at the SMBus voltage; ACK means an I3C Basic device is present | script. Only the 7Eh header is open-drain; the CCC byte and data are push-pull at the I3C rate. A NACK is reported as <code>FW_I3C_NACK_ADDRESS</code>                                                                                  |
| 2    | SMBus device discovery at static addresses and at 61h (ARP Get UDID)                             | script, with the clock-stretching mode on. The script checks the PEC                                                                                                                                                                    |
| 3    | An SMBus-only device was found: reset the SMBus interface and stay in SMBus mode                 | script: <code>hold_scl_low</code> holds SCL low for T2wrst ( <code>--t2wrst-us</code> ). A device with SMRST# can be reset from a GPIO instead                                                                                          |
| 4    | DISEC with DISHJ again, then SMBus pull-ups off and I3C Basic pull-ups on                        | script for DISEC. The adapter's SDA pull-up is set with <code>set_sda_pull_up ( --sda-pull-up )</code> for the SMBus phase and follows the I3C engine after it. SCL has no pull-up on the adapter: the external one is switched by hand |
| 5    | Wait Tsmb2i3c, move to the I3C Basic voltage, broadcast ENEC with ENHJ                           | script. <code>--t-smb2i3c-ms</code> and <code>--i3c-voltage-mv</code> come from the specification and the device                                                                                                                        |
| 6    | The device Hot-Joins                                                                             | firmware: it assigns the dynamic address itself and the script prints it                                                                                                                                                                |

The clock-stretching mode refuses every CCC (section 5.2), so the script turns it on for step 2 only and off again before step 4.

**Note:** only the SMBus-only branch has been run, 5 of 5 identical, on the bench of section 9.1: step 1 NACKed, step 2 found the reference target at 0x2A and no ARP device, and the SMBus reset held SCL low for 35000 to 35922 us when asked for 35000 us. Steps 3 to 6 need a device that ACKs 7Eh and Hot-Joins, and the ARP and PEC path needs an ARP-capable device; neither was on the bench. The PEC routine is checked against the CRC-8/SMBUS check value only.



```
$ python smbus_stretch.py --khz 400 handoff --address 0x2A 0x2B --sda-pull-up ON --
t2wrst-us 35000
FW-4.5.1-b11a067e I3C port 3300 mV (SMBus voltage)
1. DISEC(DISHJ) to 7Eh: NACK, SMBus only
2. SMBus discovery, stretching on, SCL 391644 Hz
   static 0x2A: ACK
   static 0x2B: FW_I3C_NACK_ADDRESS
   ARP 0x61 Get UDID: FW_I3C_NACK_ADDRESS (no ARP-capable device)
   SMBus mode stays.
   SMBus reset: SCL held low 35874 us (asked 35000 us)
```

## 8 Reference

**Table 8.** smbus\_stretch.py options

| Option                    | Default | Meaning                                             |
|---------------------------|---------|-----------------------------------------------------|
| <code>--serial</code>     | any     | Supernova serial number                             |
| <code>--voltage-mv</code> | 3300    | I3C port voltage, 1200 to 3300 for the HV connector |
| <code>--khz</code>        | 100     | SCL rate, 10 to 1000; runs at 746 kHz at most       |

**Table 9.** smbus\_stretch.py commands

| Command              | Arguments                                                                                                                                                                                                                      | Action                                                                                               |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|
| <code>read</code>    | address, length, optional <code>--register</code>                                                                                                                                                                              | read, optionally after writing one register byte                                                     |
| <code>write</code>   | address, bytes                                                                                                                                                                                                                 | write the bytes                                                                                      |
| <code>sweep</code>   | <code>--address</code> , <code>--count</code> , <code>--length</code>                                                                                                                                                          | reference target only: stretch 0, 50, 500, 2000, 10000 and 30000 us, <code>--count</code> reads each |
| <code>handoff</code> | <code>--address</code> , <code>--i3c-voltage-mv</code> , <code>--t-smb2i3c-ms</code> , <code>--hj-timeout-s</code> , <code>--no-smbus-only</code> , <code>--yes</code> , <code>--t2wrst-us</code> , <code>--sda-pull-up</code> | the detection flow of section 7                                                                      |

Every command enables the mode before its transfers and disables it before exiting, so the I3C port is usable for I3C traffic afterwards.

## 9 Measured results

### 9.1 Test configuration

**Table 10.** Test configuration

| Item          | Value                                                                                                                                                                                                                                                                                                                              |
|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Adapter       | Binho Supernova, hardware revision C. Firmware FW-4.5.1-def51e1c (4.6.0 pre-release) for section 6, FW-4.5.1-044a3b69 (fw-hostadapters#150 at 07528cc5 ) for the rates above 400 kHz, FW-4.5.1-8df61a39 for section 7, FW-4.5.1-b11a067e (#150 with the SMBus reset and SDA pull-up) for their measurements and the handoff output |
| Host software | pyCosmicSDK 1.6.0 pre-release, integration/1.6.0 at baacfdb, Linux                                                                                                                                                                                                                                                                 |
| Bus           | I3C HV port, 3.3 V, 1 kOhm pull-up on SCL and SDA from an idle Binho Pulsar                                                                                                                                                                                                                                                        |
| Target        | PIC18F16Q20 Curiosity Nano, stretch_target_pic18q20.c, address 0x2A                                                                                                                                                                                                                                                                |

### 9.2 Results

The sweeps of section 6 read 1200 times, 16 bytes each, across both rates and six stretch durations: 1200 correct, no errors.

Further results from the firmware validation of the same feature, on earlier builds:

- Soak with random 1 to 64 byte reads and writes, the stretch changing every 100 transfers among 0, 50 us, 500 us, 2 ms and 10 ms: 0 bad reads in about 3400 stretched transfers per run at 100 kHz and 400 kHz, including a run after a power cycle.
- Measured on the wire at a 1 kOhm pull-up: a 100 kHz request runs at 97.9 kHz and a 400 kHz request at 391.4 kHz, with tLOW and tHIGH at or above the UM10204 minimums.

Above 400 kHz, with the target stretching 50 us to 30 ms, 20 reads of 16 bytes per point:

**Table 11.** Rates above 400 kHz

| Request | Reported  | On the wire  | tLOW / tHIGH  | Stretched reads                                   |
|---------|-----------|--------------|---------------|---------------------------------------------------|
| 400 kHz | 391644 Hz | 394.5 kHz    | 1625 / 910 ns | 100 of 100                                        |
| 600 kHz | 581395 Hz | 561.8 kHz    | 965 / 820 ns  | 100 of 100                                        |
| 800 kHz | 746268 Hz | 754.7 kHz    | 815 / 515 ns  | 100 of 100, and 100 of 100 after each of 3 resets |
| 1 MHz   | 746268 Hz | not measured | not measured  | 100 of 100                                        |

On-the-wire values are medians over about 23000 SCL periods on an Acute logic analyzer. At 800 kHz both phases stay above the UM10204 Fast-mode Plus minimums of 500 ns and 260 ns. At 600 kHz the reported rate is 3.5 % above the wire.

With the reference target not stretching, reads above 400 kHz return 0xFF in the second byte, 0 of 100 at each rate, while every stretched read is correct. The adapter's SCL is the same in both cases; only the target's own clock stretching is off. We attribute it to the reference target's firmware not loading the second byte in time without stretching, not to the adapter.

SMBus reset ( `hold_scl_low` ), 5 holds per point, firmware `FW-4.5.1-b11a067e` , SCL low time on the Acute. Holds that span one of the analyzer's buffer boundaries read about 1.5 ms short and are left out:

**Table 12.** SCL hold for the SMBus reset

| Requested | Measured on the wire | Reported by the adapter | Reads after the hold               |
|-----------|----------------------|-------------------------|------------------------------------|
| 1 ms      | 999.7 to 1678 us     | 1000 to 1677 us         | 5 of 5                             |
| 10 ms     | 9987 to 11006 us     | 10000 to 10998 us       | 5 of 5                             |
| 35 ms     | 34996 to 35941 us    | 35000 to 35937 us       | 5 of 5 per mode, and after a reset |
| 100 ms    | 100013 to 100114 us  | 100000 us               | 5 of 5                             |

A hold can run up to about 1 ms long, and up to 0.13 % short against the analyzer's clock, which is the tolerance of the adapter's internal oscillator; ask for `T2wrst` with that margin. 0 us and more than 1 s are refused with `FW_INVALID_PARAMETER` , and firmware 4.5.1 answers `FW_UNSUPPORTED_COMMAND` .

The SDA pull-up, measured as the delay from SCL rising to SDA crossing 1.6 V at each STOP with the Pulsar's pull-up off: 7813 ns with `OFF` , 5975 ns with `ON` and 5965 ns with `AUTO` . Reads were 10 of 10 in all three settings, with and without the clock-stretching mode.

These are what we measured on one bench, not a specification.

**Note:** on the pre-release builds, the first `enable_i2c_clock_stretching` after an `init_bus` that failed (no I3C device answered) may report about half the rate at 100 kHz, or time out at 10 kHz. The rate on the wire is correct. This is being fixed for the release; the procedure above does not call `init_bus` .

## 10

## Troubleshooting

Table 13. Troubleshooting

| Symptom                                                                         | Probable cause and action                                                                             |
|---------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------|
| <code>FW_UNSUPPORTED_COMMAND</code> on enable                                   | Firmware 4.5.1 or earlier. Update the Supernova to 4.6.0 or later.                                    |
| Reported rate far below the request                                             | No pull-up on SCL. Add one (section 3.3).                                                             |
| <code>FW_I3C_I2C_CLOCK_STRETCHING_ACTIVE</code>                                 | An I3C call was made with the mode on. Call <code>disable_i2c_clock_stretching</code> first.          |
| <code>FW_BUS_TIMEOUT</code>                                                     | The target held SCL longer than 35 ms. Check the target; this is SMBus tTIMEOUT.                      |
| <code>FW_I3C_NACK_ADDRESS</code> right after reconfiguring the reference target | The target restarts its I2C peripheral to apply a new stretch. The script waits 10 ms for this.       |
| Wrong data from a stretching target with the mode off                           | Expected: the I3C engine does not wait. Turn the mode on.                                             |
| <code>FW_INVALID_PARAMETER</code> on enable above 400 kHz                       | Firmware before 4.6.0's 1 MHz limit. Update the Supernova.                                            |
| <code>handoff</code> step 1 NACK with an I3C Basic device on the bus            | The device is not in SMBus mode at the voltage set, or not powered. Check <code>--voltage-mv</code> . |

## 11

## Acronyms

**Table 14.** Acronyms

| Term             | Meaning                                                                  |
|------------------|--------------------------------------------------------------------------|
| I2C              | Inter-Integrated Circuit                                                 |
| I3C              | MIPI Improved Inter-Integrated Circuit                                   |
| SMBus            | System Management Bus                                                    |
| MCTP             | Management Component Transport Protocol                                  |
| SCL              | Serial clock line                                                        |
| SDA              | Serial data line                                                         |
| SDR              | Single data rate, the base I3C transfer mode                             |
| HDR              | High data rate I3C transfer modes                                        |
| CCC              | I3C common command code                                                  |
| tTIMEOUT         | SMBus clock-low timeout, 35 ms                                           |
| ARP              | SMBus Address Resolution Protocol                                        |
| PEC              | SMBus packet error code, a CRC-8                                         |
| UDID             | SMBus unique device identifier                                           |
| DISEC, ENEC      | I3C CCCs that disable and enable target events                           |
| Hot-Join         | I3C event in which a target joins the bus and receives a dynamic address |
| NVMe-MI          | NVM Express Management Interface                                         |
| T2wrst, Tsmb2i3c | timing parameters of the PCI-SIG detection flow                          |

## 12

## Note about the source code in the document

Example code shown in this document and supplied in the accompanying archive is provided for evaluation and reference. It is released under the MIT license, the text of which is included in the archive.

The archive `AN0014-assets.zip` contains `smbus_stretch.py`, `stretch_target_pic18q20.c` and `LICENSE`.

## 13

## Revision history

**Table 15.** Revision history

| Revision | Date              | Description                                                                                                                                          |
|----------|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0.1      | 25 September 2026 | Draft for internal review, measured on firmware 4.6.0 and pyCosmicSDK 1.6.0 pre-release builds.                                                      |
| 0.2      | 28 September 2026 | Retitled for NVMe-MI. Rates up to 1 MHz (746 kHz in effect). Section 7, the SMBus to I3C Basic detection flow, and the <code>handoff</code> command. |
| 0.3      | 28 September 2026 | <code>hold_scl_low</code> and <code>set_sda_pull_up</code> in the detection flow, with their measurements.                                           |

## Legal information

### Definitions

#### Draft

A document marked draft is under internal review and subject to formal approval. Binho Inc. makes no representation or warranty as to its accuracy or completeness and accepts no liability arising from its use.

### Disclaimers

#### Limited warranty and liability

Information in this document is believed to be accurate and reliable. Binho Inc. makes no representation or warranty, express or implied, as to its accuracy or completeness, accepts no liability for the consequences of its use, and takes no responsibility for content originating outside Binho Inc.

In no event shall Binho Inc. be liable for any indirect, incidental, punitive, special or consequential damages, including without limitation lost profits, lost savings, business interruption, or costs of removing or replacing any product, whether or not based on tort, warranty, breach of contract or any other legal theory.

Notwithstanding any damages a customer might incur, the aggregate and cumulative liability of Binho Inc. is limited in accordance with its terms and conditions of commercial sale.

#### Right to make changes

Binho Inc. reserves the right to change the information in this document, including specifications and product descriptions, at any time and without notice. This document supersedes all information supplied prior to its publication.

#### Suitability for use

Binho Inc. products are not designed, authorized or warranted for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure of a Binho Inc. product can reasonably be expected to result in personal injury, death, or severe property or environmental damage. Any such inclusion or use is at the customer's own risk and Binho Inc. accepts no liability for it.

#### Applications

Applications described here are illustrative only. Binho Inc. makes no warranty that they are suitable for the specified use without further testing or modification. Customers are responsible for the design and operation of their own applications and products, for appropriate design and operating safeguards, and for determining whether a Binho Inc. product is suitable and fit for their

purpose. Binho Inc. accepts no liability for assistance with applications or customer product design.

#### Third-party products and specifications

This document refers to products, boards, specifications and documentation supplied by third parties, which remain the responsibility of their respective owners.

Binho Inc. makes no warranty regarding them and their behavior may change without notice. Register maps, protocol details and device identifiers reproduced here were observed on the specific hardware and firmware versions stated in this document and must be confirmed against the vendor's own documentation for the reader's part.

#### Example code

Source code supplied with this document is provided as an example, for evaluation and reference. It is not qualified for production use, has not been developed under a functional safety or security process, and is licensed under the terms accompanying it in the distribution archive.

#### Terms and conditions of commercial sale

Binho Inc. products are sold subject to the general terms and conditions of commercial sale published by Binho Inc., unless otherwise agreed in a valid written individual agreement, in which case only the terms of that agreement apply.

#### Export control

This document and the items it describes may be subject to export control regulations. Export may require prior authorization from the competent authorities.

#### Security

All products may be subject to unidentified vulnerabilities or may support security standards with known limitations. The customer is responsible for the design and operation of its applications and products throughout their lifecycle to reduce the effect of such vulnerabilities, and for compliance with all legal, regulatory and security requirements concerning its products.

#### Trademarks

All referenced brands, product names, service names and trademarks are the property of their respective owners. **Binho** and the Binho logo are trademarks of Binho Inc. **PIC**, **MPLAB** and **Curiosity** are trademarks or registered trademarks of Microchip Technology Incorporated. **Acute** and **TravelBus** are trademarks or registered trademarks of Acute Technology Inc. **PCI-SIG** is a registered trademark of PCI-SIG. **NVMe** and **NVMe-MI** are trademarks of NVM Express, Inc.