

# Manage Threats and Opportunities (FIT4MTO)


Admins and Super User Features

# **Creating Workstreams**




#### Workstream Definition for MTO – Use with MTO Work Process

- Fit4 MTO Workstream this feature will be used to define the default asset hierarchy for each Asset/Site Production Team / Area / Unit (Level 6, 7 & 8 or "Unit" fields). Asset hierarchy is set up as initial site configuration and can be modified by System Administrator (Site will work with IT Support to update). Workstream has the following components.
  - 1 Details
  - 2 Hierarchy
  - 3 Pre-Defined Approvers



## Workstream Definition for MTO – Details Field Description



### • Workstream Details:

- Name:
  - Set to represent the Asset/Site Production Team it represents
- Owner:
  - User who initially created the Workstream
- Sponsor:
  - Production Unit Manager or OIM
- Lead:
  - Reliability Engineer assigned to the Production Team for support
- Finance Sponsor:
  - Used by the WAVE project for final approval. Will not be used in MTO but a name has to be entered when first creating and on the Details page. Name can be removed from the "Pre-Defined Approvers" view (covered later)
- Target:
  - Used to capture Site Production Team annual target for New Entries (KPI1)
- Ambition:
  - Used to capture Site Production Team annual target for Resolved/Realised Entries (KPI3)
- Description:
  - Short text field describing the Workstream

## **Workstream Definition for MTO – Hierarchy Field Description**




Workstream Hierarchy: As noted earlier, the initial set up of the Workstreams will be done by the IT team when migrating the L-MTO Site data to the Fit4 Tool. Of note with workstream is the hierarchy is not "required" at this time so in future when sites either request new or update – then they must recall to review the Hierarchy settings.

■ The overall asset hierarchy is set up to align with the Business (UP, IG or DS) agreed hierarchy. The following levels are defined within the Fit4 MTO tool. It has been agreed the following "Levels" will represent as noted even thought it may not completely align with the business. This is to ensure when extracting data from the Fit4 tool the "location" of key information such as Production Team name will be consistent across the businesses


#### Field Names

- Level 1 Business (DS, UP, IG) (Not included in L-MTO)
- Level 2 Class or Line of Business (DW, Manufacturing, etc) (L-MTO Class of Business)
- Level 3 Business Area (UP/IG) or Region (DSM) (L-MTO Region)
- Level 4 Asset / Site (L-MTO Site Name)
- Level 5 Manufacturing Type (Refining, Chemical, Upgrader); UP/IG not defined (Not included in L-MTO)
- Level 6 L-MTO Defined "Production Team" (does not currently exist in the business hierarchy)
- Level 7 L-MTO defined "Area" (does not currently exist in the business hierarchy)
- Level 8 L-MTO defined "Unit"
  - note the L-MTO unit name most likely differs from the business hierarchy unit names but this field will align to the L-MTO unit names


# Adding Workstreams in FIT4MTO (Super User/Admin Feature)




#### New Workstream




Note: if you belong to DS select "Downstream – Super User" for UP&IG select "Upstream – Super User" and click Next






# **Modifying the Approval Matrix**




# Adding/Modifying Hierarchy & Units in FIT4MTO



## Adding/Modifying Hierarchy & Units in FIT4MTO






Note: As a part of this testing please select only DS and UP as the two options

# For Downstream Manufacturing UAT Users





1)Search for the name of your site Example:
Deer Park (M). Because we have chemicals and
Manufacturing setup in FIT4 hence use (M) as
the suffix behind Site Name


Q Deer Park (M)


Import

Change Owner


\$ ₹

Printable View

















# For Upstream & IG UAT users












Name	~	Business
FNGL		UP
Fram	•	UP
Gannet		UP
Jackdaw		UP
Nelson		UP
NSP		UP










Name	Business	
Gannet Gas system	UP	
Gannet Oil system	UP	
Gannet Subsea system	UP	
Gannet Utilities	UP	
Gannet Water processing	UP	
Gannet Wells	UP	







# **Adding Users**



Note: The Support Team will address the Normal User Creation Requests however we do have a functionality where Site Admins can do that on their end aswell





1) Click on Users

RESTRICTED

28



All Users

Action Full Name ↑

Edit

Edit

Edit

a/p Manogaran. Aishwinee

Abadie, Randall

Abbas Abdi, Syed Zeerak

Abatan, Adetola aabat

Alias

USRAB1

Username

a.apmanogaran@shell.com.up.uat

randall.abadie@shell.com.up.uat

adetola.abatan@shell.com.uat

zeerak.abbas@shell.com.up.uat

#### On this page you can create, view, and manage users. In addition, download SalesforceA to view and edit user details, reset passwords, and perform other administrator. You can edit the users for whom the Action column is not blank. 1) Click on New User View: All Users ✓ Clone | Create New View

New User

Fit4 - DS - Retail - East

Fit4 - UP Deepwater (UPD) - DW Gulf of

Fit4 - UP Deepwater

(UPD) - DW Gulf of

Mexico

Last Login Role

2/18/2020

2/19/2020

4:39 PM

1:57 PM

Reset Password(s) Add Multiple Users

Active Profile

<u>Fit4 -</u> <u>Upstream</u>

✓ <u>iShale Admin</u>

<u>Fit4 -</u> <u>Upstream</u>

Manager Nickname

User15840946901794699723

User15814855983386448595

Randall Abadie

Zeerak.Abbas

Email

a.apmanogaran@shell.com.invalid

randall.abadie@shell.com.invalid

adetola.abatan@shell.com

zeerak.abbas@shell.com

<Pre><Previous Page | Next Page> A | B | C | D | E | F | G | H | I | J | K | L | M | N | O | P | Q | R | S | T | U | V | W | X | Y | Z | Other | All Phone Extension Federation Id Is Frozen Created By Kopal Goswami MYAAQR <u>Prasanna</u> USRAB1 <u>Vainatheya</u>

<u>Vijayalakshmi</u>

Harsha Rastogi


Kattamuri

Help for this Page 🕜


**RESTRICTED** 29


USAAB3

USZAB2




1) Fill in the attached User Information





#### Select the permission set and click save

## Permission Set Assignments Madhu Kutagulla



- Downstream Super User is Super User in Fit4 who would have Read/Edit access to all Manufacturing sites. This is the elevated level of permission to create Workstreams.
- Downstream Administrator will have access to their own site and region
- Generic User Super User is used where you want to give access to user to create T/O only across Class of Business
- Generic User Administrator is used where you want to give access to only to a region or site

