ENGTX 460 Standard Operation Procedure

Doc. No:
Date:Nov. 23. 2011
Revision:1.12

Page: 11 Grade:

0Rev	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.00		First release	GRMA	chongling	Aug.9.2010
1.01		Add new P/N(C1CPK5-A04)	GRMA	Chongling	Aug.17.2010
1.02		Add new P/N(C1CPL5-A04)	GRMA	Chongling	Aug.18.2010
1.03		Add new P/N(C1CPL0-A26)	GRMA	Chongling	Aug.30.2010
1.04		Add new P/N(C1CPKA-A01)	GRMA	Chongling	Sep.17.2010
1.05		Add new P/N(C1CPL5-A14)	GRMA	Chongling	Sep.27.2010
1.06		Add new P/N(C1CQ10-A01)	GRMA	Ariel_wang	Jan.11.2011
1.07		Add new PCBA(C1CQ10-A12)	GRMA	Ariel_wang	Jan.11.2011
1.08		Add new PCBA(C1CPKA-A24)	GRMA	Ariel_wang	Feb.15.2011
1.09		Add new PCBA(C1CPKA-A34)	GRMA	Ariel_wang	Apr.8.2011
1.10		Add new P/N(C1CPLK-A33)	GRMA	Ariel_wang	Apr.18.2011
1.11		Add new P/N(YV01F0-A01)	GRMA	Ariel_wang	Nov.8.2011
1.12		Add new P/N(YV01M0-A01)	GRMA	Ariel_wang	Nov.23.2011

Authorize by		Review by		Originator By	Chongling
-----------------	--	--------------	--	------------------	-----------

Form No: T2-009-01 Rev.01

ENGTX 460 Date:Nov. 23. 2011 Standard Operation Procedure Rev.: 1.12 Page: 1

Doc. No:
Date:Nov. 23. 2011

1.Objectives

Create test procedure.

2.Scope

Model: ENGTX 460

PN: C1CPL0(A01&A26) C1CPK5(A04) C1CPL5(A04&A14)

C1CPKA(A01&A24&A34) C1CQ10(A01&A12)C1CPLK(A33)YV01F0(A01)

YV01M0(A01)

3.Test Item

- 3.1 Diagnostic test in DOS
- 3.2 3DMark06(contain HDMI test)
- 3.3 Temperature test

4.Relevant Document

None.

5.Definition: 1. If the model name contains P, please test HDCP function.

Ex: EAH***/HTDP/512M/A

- 2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.
- 3. Please use Nvidia platform (P5Q) /P7H55-M/USB3 to test in DOS.

ENGTX 460 Date:Nov. 23. 2011 Standard Operation Procedure Rev.: 1.12 Page: 2

Doc. No:
Date:Nov. 23. 2011

6. Operation Procedures:

6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows test environment by yourself).

ENGTX 460 Standard Operation Procedure Rev.: 1.12 Page: 3

Doc. No:

Date: Nov. 23. 2011

6.2 Fixture connect

- 6.2.1 Install Intel P5/P7 CPU & CPU Fan.
- 6.2.2 Install DDR2 /DDR3 Memory to DIMM1~4.
- 6.2.3 Plug PS2 Mouse and PS/2 Keyboard into P5Q/P7H55-M/USB3 Motherboard.
- 6.2.4 Plug VGA Card ENGTX 460 into PCIEX16.
- 6.2.5 This card has 6 PIN of Power supply, please connect power con of VGA card & Power supply via bundled power cable. (6 PIN of Power supply to 6 PIN of VGA card)





6.2.6 Connect SATA HDD with SATA CON.



- 6.2.7 Plug 4PIN 12V (1200W) power cable into CON12V.
- 6.2.8 Plug ATX Power (1200W) on Power Connector.



ENGTX 460 Date:Nov. 23. 2011 Standard Operation Procedure Rev.: 1.12 Page: 4


Doc. No:
Date:Nov. 23. 2011

6.3 Diagnostic test in DOS

6.3.1 Please connect LCD monitor & card's DVI CON via a DVI cable.



- 6.3.2 Press Power Switch then turn on power button.
- 6.3.3 Press "Del" to enter CMOS setup menu while boot screen is displaying. EXIT -> Load Setup Defaults.



6.3.4 System will reboot, select DOS to run test program.

Path: VBAT\ENGTX460\BATCH\

Run the test program refer to the prompt.

6.3.5 Memory test

If you want to test memory, please run mats.exe.

Path: VBAT\ENGTX460\618KP1\

Path: VBAT\ENGTX460\2569KP1\

Path: VBAT\ENGTX460\25616\

Path: VBAT\ENGTX460\0256KP1\

6.3.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path: VBAT\ENGTX460\BIOS

Command:nvflash xxx.rom -4 -5 -6 -A -y

Notice:

If you can not flash bios because of the bios locked, please use nvflash.exe /r to unlock bios. And then, please use nvflash.exe /w to lock bios after updating latest bios.


ENGTX 460 Date:Nov. 23. 2011 Standard Operation Procedure Rev.: 1.12 Page: 5

Doc. No:
Date:Nov. 23. 2011

6.3.8 After finish DOS testing, please enter Windows environment to test 3DMark.


6.4 3DMark test(contain HDMI test)

- 6.4.1 Please install 3DMark program by yourself.
- 6.4.2 Please connect VGA card to LCD via HDMI cable.



6.4.3 Please install VGA card driver in Windows(You must use individual driver of this card).

- 6.4.4 Please run 3DMark06 base on this card (please test 1 cycle).
- 6.4.5 Press "Select" to enter Select test menu. You can choose "HDR1" for default setting.




ENGTX 460 Standard Operation Procedure Rev.: 1.12 Page: 6

Doc. No:

Date: Nov. 23. 2011

6.4.6 Press "Demo" to enter Demo menu. You can choose "Sounds" for default setting.



- 6.4.7 Please pay attention to check if there is flickering, discolor, crash and so on. If there's no problem, it can be judged OK!
- 6.4.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.



ENGTX 460 Standard Operation Procedure | Rev.: 1.12 Page: 7

Doc. No:

Date: Nov. 23. 2011

- 6. 4.9 If test OK, please test MINI HDMI port.
- 6. 4.10 Connect VGA card to LCD via HDMI –MINI HDMI Cable test HDMI function. (Please refer to step 6.4.4&6.4.5&6.4.6&6.4.7&6.4.8)




MINI HDMINI CON

6.5 Temperature test

- 6.5.1 Please copy Thermaltool(1.0.05) to Windows by yourself.
- 6.5.2 Please run ThermalTest.exe.



6.5.3 If test ok, show pass.




ENGTX 460 Standard Operation Procedure Rev.: 1.12 Page: 8

Doc. No:

Date: Nov. 23. 2011

6.5.4 If test fail, show fail.



6.5.5 If test OK, NTF test.

ENGTX 460 Standard Operation Procedure Rev.: 1.12 Page: 9

Doc. No:

Date:Nov. 23. 2011

7 Appendix

1 NO#	Equipment Description	ASUS Part#	Supplier	Quantity	INCHIAN S
1					Remarks
	SAMSUNG 2232MW			1	
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(1200W)			1	
5	INTEL Celeron E1200			1	E1100
6	Intel CPU Intel(R) Core(TM)2 CPU		local	1	E1100
7	Heat sink + FAN	22-240000160		1	
8	APACER 800MHz 1G			2	
9	DDR3 1333 2G	20-TT2605618	local	4	
10	SATA HDD			1	
11	SATA HDD Cable	14-000107070		1	
12	PCIEX16 VGA CARD			1	
13	D-SUB extend cable (Buying a local D-SUB cable by yourself)			1	
14	Dual link DVI cable (Buying a local DVI cable by yourself)			1	O
15	HDMI extend cable (Buying a local HDMI cable by yourself)			1	
16	TV extend cable (Buying a local TV cable by yourself)			1	
17	DVI-HDMI	04G460002400 /04G460002450		1	

ENGTX 460 Standard Operation Procedure Rev.: 1.12 Page: 10

Doc. No:

Date:Nov. 23. 2011

18	HDMI to MINI HDMI cable (Buying a local cable by yourself)			1	
19	LCD "Y" Cable	14-010230000		1	
20	P5Q	80-MIB4P0-G0A01		1	
21	P7H55-M/USB3 (YV01F0 and later)	80-MIBBKA-G0*	ASUS	1	