ASUSTeK	COMPUTER
IN	IC.

# Standard Operation Procedure Date: Aug. 1, 2 Revision: 1.04

Doc. No: Date: Aug. 1, 2011

Page: 11 Grade:

Rev. Modified Chapters		Issued Dept.	Issued by	Revised Date
1.00	First Release	GRMA	Ariel_wang	Jan.10,2011
1.01	Add new PCBA(C1CPZ0-A12)	GRMA	Ariel_wang	Jan.31,2011
1.02	Add new P/N(C1CPZ5-A11)	GRMA	Ariel_wang	Jul.4,2011
1.03	Add new PCBA(C1CPZ5-A01)	GRMA	Ariel_wang	Jul.5,2011
1.04	Add new PCBA	GRMA	Ariel_wang	Aug.1,2011
	(C1CPZ0-A22/YV00K0-A22)			

Authorize by Review by Originator By	Ariel_wang
--------------------------------------	------------

Form No: T2-009-01 Rev.01

ASUSTEK COMPUTER INC EAH6870 Date: Aug. 1, 2011
Standard Operation Procedure Rev.: 1.04 Page: 1

## 1.Objectives

Create test procedure.

## 2.Scope

Model: EAH6870

PN: C1CPZ0 (A01&A12&A22) C1CPZ5(A01&A11) YV00K0(A22)

#### 3.Test Item

- 3.1 Diagnostic test in 64-bit Linux system
- 3.2 3DMark06(contain HDMI test)
- 3.3 Temperature test
- 3.4 FAN test

#### **4.Relevant Document**

None.

**5.Definition**: 1. If the model name contains P, please test HDCP function.

Ex: EAH\*\*\*/HTDP/512M/A

- 2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.
- 3. System Memory: 1GB for a single GPU test station; please add an additional 512MB of system memory for each additional GPU used for the test configuration
- 4. EAH6870 Test Program in 64-bit Linux system test.

ASUSTeK	COMPUTER	INC

# EAH6870 Standard Operation Procedure

Doc. No:
Date: Aug. 1, 2011
Rev.: 1.04 Page: 2

# 6. Operation Procedures:

#### 6.1 Attention

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows test environment by yourself).

EAH6870 Standard Operation Procedure


Doc. No:
Date: Aug. 1, 2011
Rev.: 1.04 Page: 3

#### **6.2** Fixture connect

- 6.2.1 Install Intel P5/P7 CPU & CPU Fan.
- 6.2.2 Install DDR2 1GB Memory to DIMM1~4. (a minimum memory of 2GB for Linux test)
- 6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.
- 6.2.4 Plug VGA Card EAH6870 into PCIEX16 1.
- 6.2.5 If this card has 6 PIN or 8 PIN of Power supply, please connect power con of VGA card & Power supply via bundled power cable.
  - (6 PIN of Power supply to 6 PIN of VGA card)
  - (8 PIN of Power supply to 8 PIN of VGA card)
- 6.2.6 Connect SATA HDD & SATA con via SATA cable



- 6.2.7 Plug 4PIN 12V power(a minimum power of 1200W) cable into CON12V.
- 6.2.8 Plug ATX Power on Power(a minimum power of 1200W) Connector.



## EAH6870 Standard Operation Procedure

Doc. No:

Date: Aug. 1, 2011 Rev.: 1.04 Page: 4

#### 6.3 Certain test.

### 6.3.1 Diagnostic test in 64-bit LINUX system

6.3.1.1 Please connect LCD monitor & card's DVI CON via a DVI cable.



- 6.3.1.2 Press Power Switch then turn on power button.
- 6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.

EXIT -> Load Setup Defaults. Advanced Power Exit Options Exit system setup Exit & Save Changes Exit & Discard Changes after saving the changes. Discard Changes F10 key can be used for this operation. Load Setup Defaults Select Screen Select Item Enter Go to Sub-screen General Help Save and Exit (C)Copyright 1985-2092, American Megatrends

6.3.1.4 Run test program in 64-bit linux system.

Path:eah6870\c1cpz0a0.sh or c1cpz5a0.sh

Path:eah68701\c1cpz0a1.sh or c1cpz5a1.sh

 $Path: eah 68702 \\ \verb|c1cpz0a2.sh| or yv00k0a2.sh|$ 

Please enter into the file of eah6870 or eah68701 or eah68702,enter the following command: cd ./eah6870 cd ./eah68701 cd ./eah68702

Then,please run ./c1cpz0a0.sh ./c1cpz0a1.sh ./c1cpz5a1.sh ./c1cpz5a0.sh ./c1cpz0a2.sh ./yv00k0a2.sh

6.3.1.5 Memory test

If you want to test memory, please run ./tserver -test=memfa

Path:eah6870\

Path:eah68701\

Path:eah68702\

6.3.1.6 BIOS Version

If you want to look at the version of bios, please run ./atiflash.sh or ./atiflash -ai 0.

Path:eah6870\

Path:eah68701\

Path:eah68702\

6.3.1.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

## EAH6870 Standard Operation Procedure

Doc. No:

Date: Aug. 1, 2011 Rev.: 1.04 Page: 5

Path:eah6870\ Path:eah68701\ Path:eah68702\

Command:./atiflash -p -f 0 xxx.rom

Notice:

If you can not flash bios because of the bios locked, please use ./atiflash –unlockrom 0 to unlock bios. And then, please use ./atiflash –lockrom 0 to lock bios after updating latest bios.

6.3.1.8 FAN Test

If you want to test FAN, please run ./aft64102.

Path: Path:eah68702\AFT64100

Notice:

./aft64102 apply the following Part Number

C1CPZ0-A22/YV00K0-A22

6.3.1.9 After finishing 64-bit Linux test, please enter Windows environment to test 3DMark.

## 6.3.2 3DMark test(contain HDMI function test)

- 6.3.2.1 Please install 3DMark program by yourself.
- 6.3.2.2 Please connect VGA card to LCD via Display port cable.




- 6.3.2.3 Please install VGA card driver in Windows(You must use individual driver of this card).
- 6.3.2.4 Please run 3DMark06 base on this card (please test 1 cycle).
- 6.3.2.5 Press "Select" to enter Select test menu. You can choose "HDR1" for default setting.


# EAH6870 Standard Operation Procedure

Doc. No:

Date: Aug. 1, 2011 Rev.: 1.04 Page: 6




6.3.2.6 Press "Demo" to enter Demo menu. You can choose "Sounds" for default setting.



- 6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on. If there's no problem, it can be judged OK!
- 6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.

EAH6870 Standard Operation Procedure Doc. No:

Date: Aug. 1, 2011 Rev.: 1.04 Page: 7



# **6.4** Temperature test

- 6.4.1 Please copy Thermaltool(1.0.05) to Windows by yourself.
- 6.4.2 Please run ThermalTest.exe.




6.4.3 If test ok, show pass.


# EAH6870 Standard Operation Procedure

Doc. No:

Date: Aug. 1, 2011 Rev.: 1.04 Page: 8



6.4.4 If test fail, show fail.



6.4.5 If test OK, please NTF test.

# EAH6870 Standard Operation Procedure

Doc. No:

Date: Aug. 1, 2011 Rev.: 1.04 Page: 9

# 7.Appendix

					,
NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	Dell 30 inches (3008WFP) (Buying a local LCD by yourself)			1	Participant of the state of the
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(a minimum power of 500W)			1	
5	INTEL Celeron E1200			1	E11200
6	Heat sink + FAN	22-240000160		1	
7	Intel CPU Intel(R) Core(TM)2 CPU		local	1	E11200
8	DDR2(667/800) 1G	04G0016169A9NE /22-T00642404		4	
9	DDR3 1333 2G	20-TT2605618	local	4	
10	TEST HDD			1	
11	SATA HDD Cable	14-000107070	ASUS	1	
12	PCIEX16 VGA CARD			1	
13	Dual link DVI cable (Buying a local DVI cable by yourself)			1	
14	HDMI extend cable (Buying a local HDMI cable by yourself)	00 1500-10		1	O
14 16	P5E MB P7H55-M/USB3 MB	80- MBB7X0-* 80- MIBBKA-*		1 1	
17	Display port cable (Buying a local Display port cable by yourself)	ou- MIDDINA-"		1	11113.300 R 1114