ASUSTeK	COMPUTER
IN	IC.

# EAH5550 Date: Jun. 7, 2 Standard Operation Procedure Revision: 1.10

Doc. No:
Date: Jun. 7, 2011

Page: 11 Grade:

Rev.	Modified	Modification Description	Issued	Issued by	Revised Date
ICCV.	Chapters	Wodification Description	Dept.	Issued by	Revised Date
1.00		First Release	GTC	Ariel_wang	Jun.4,2010
1.01		Add new pcba (C1CPG0-A11)	GTC	Chongling	Oct.11.2010
1.02		Add new pcba (C1CPA0-A11)	GTC	Chongling	Oct.13.2010
1.03		Add new pcba (C1CPG5-A01)	GTC	Chongling	Oct.19.2010
1.04		Add new pcba (C1CPG0-A21)	GTC	Chongling	Oct.22.2010
1.05		Add new pcba (C1CPGA-A01)	GTC	Chongling	Nov.15.2010
1.06		Add new pcba (C1CPG0-A32)	GTC	Chongling	Nov.17.2010
1.07		Add new pcba (C1CPGA-A11)	GTC	Chongling	Nov.24.2010
1.08		Add new pcba (C1CPG5-A13)	GTC	Chongling	Nov.24.2010
1.09		Add new PCBA(C1CPGA-A22)	GRMA	Ariel_wang	Mar.30,2011
1.10		Add new PCBA(C1CPGA-A32)	GRMA	Ariel_wang	Jun.7,2011

Authorize	Review	Originator	Ariel
by	by	By	

Form No: T2-009-01 Rev.01

ASUSTEK COMPUTER INC EAH5550 Date: Jun. 7, 2011 Rev.: 1.10 Page: 1

# 1.Objectives

Create test procedure.

## 2.Scope

Model: EAH5550

PN: C1CPG0(A01&A11&A21&A32)C1CPA0(A11) C1CPG5(A01&A13)

C1CPGA(A01&A11&A22&A32)

## 3.Test Item

- 3.1 Diagnostic test in 32-bit Linux
- 3.2 3DMark03(contain HDMI test)
- 3.3 Temperature test

## **4.Relevant Document**

None.

**5.Definition**: 1. If the model name contains P, please test HDCP function.

Ex: EAH\*\*\*/HTDP/512M/A

- 2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.
- 3. System Memory: 1GB for a single GPU test station; please add an additional 512MB of system memory for each additional GPU used for the test configuration

ASUSTEK COMPUTER INC EAH5550 Date: Jun. 7, 2011 Rev.: 1.10 Page: 2

## **6. Operation Procedures:**

## **6.1 Attention**

- 6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.
- 6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.
- 6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.
- 6.1.4 Some test items should be tested under Windows environment. (Please install windows test environment by yourself).

EAH5550 Standard Operation Procedure Doc. No:

Date: Jun. 7, 2011 Rev.: 1.10 Page: 3

#### **6.2** Fixture connect

- 6.2.1 Install Intel P5 CPU & CPU Fan.
- 6.2.2 Install DDR2 1GB Memory to DIMM1~4. (a minimum memory of 2GB for Linux test)
- 6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.
- 6.2.4 Plug VGA Card EAH5550 into PCIEX16 1.



C1CPG0

#### 6.2.5 Connect SATA HDD & SATA con via SATA cable



- 6.2.6 Plug 4PIN 12V power(a minimum power of 600W) cable into CON12V.
- 6.2.7 Plug ATX Power on Power(a minimum power of 600W) Connector.



EAH5550 Standard Operation Procedure

Doc. No:
Date: Jun. 7, 2011
Rev.: 1.10 Page: 4


#### 6.3 Certain test.

## 6.3.1 Diagnostic test in LINUX

6.3.1.1 Please connect LCD monitor & card's DVI CON via a DVI cable.



Please connect LCD monitor & card's D-SUB CON via a D-SUB cable.



- 6.3.1.2 Press Power Switch then turn on power button.
- 6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying. EXIT -> Load Setup Defaults.



6.3.1.4 Run test program in linux.

Path:eah5550\clcpg0a0.sh or clcpg0a1.sh or clcpg5a0.sh or clcpg0a2.sh or clcpgaa0.sh

Path:eah55501\c1cpa0a1.sh

Path:eah55502\clcpg0a3.sh or clcpgaa1.sh or clcpg5a1.sh

Path:eah55503\c1cpgaa2.sh or c1cpgaa3.sh

Please enter into the file of eah5550 or eah55501 or eah55502 or eah55503, enter the following command :cd ./eah5550 or cd ./eah55501 or cd ./eah55502 or ./eah55503
Then,please run ./c1cpg0a0.sh or c1cpg0a1.sh or c1cpg0a1.sh or c1cpg5a0.sh or

# EAH5550 Standard Operation Procedure

Doc. No:

Date: Jun. 7, 2011 Rev.: 1.10 Page: 5

clcpg0a2.sh or clcpgaa0.sh or clcpg0a3.sh or clcpgaa1.sh or clcpgaa1.sh or clcpgaa2.sh or clcpgaa3.sh

#### 6.3.1.5 Memory test

If you want to test memory, please run ./tserver-exec -test=memfa1.1

Path:eah5550\ or eah55501\ or eah55502\

If you want to test memory, please run ./tserver -test=memfa

Path:eah55503

#### 6.3.1.6 BIOS Version

If you want to see the version of bios, please run ./atiflash -ai 0.

Path:eah5550\ or eah55501\ or eah55502\ or eah55503\

#### 6.3.1.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path:eah5550\ or eah55501\ or eah55502\ or eah55503

Command:./atiflash -p -f 0 xxx.rom

Notice:

If you can not flash bios because of the bios locked, please use ./atiflash –unlockrom 0 to unlock bios. And then, please use ./atiflash –lockrom 0 to lock bios after updating latest bios.

6.3.1.8 After finish Linux testing, please enter Windows environment to test 3DMark.

EAH5550 Standard Operation Procedure Doc. No:

Date: Jun. 7, 2011 Rev.: 1.10 Page: 6


### 6.3.2 3DMark test(contain HDMI test)

- 6.3.2.1 Please install 3DMark program by yourself.
- 6.3.2.2 Please connect VGA card to LCD via HDMI cable.



**HDMI CON** 

- 6.3.2.3 Please install VGA card driver in Windows(You must use individual driver of this card).
- 6.3.2.4 Please run 3DMark03 base on this card (please test 1 cycle).
- 6.3.2.5 Press "Select" to enter Select test menu. You can choose "GT1" for default setting.




# EAH5550 Standard Operation Procedure

Doc. No:

Date: Jun. 7, 2011 Rev.: 1.10 Page: 7

6.3.2.6 Press "Demo" to enter Demo menu. You can choose "Sounds" for default setting.



- 6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on. If there's no problem, it can be judged OK!
- 6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test fail.



EAH5550 Standard Operation Procedure


Doc. No:
Date: Jun. 7, 2011
Rev.: 1.10 Page: 8

## **6.4 Temperature test**

- 6.4.1 Please copy Thermaltool(1.0.05) to Windows by yourself.
- 6.4.2 Please run ThermalTest.exe.



6.4.3 If test ok, show pass.




6.4.4 If test fail, show fail.

# EAH5550 Standard Operation Procedure

Doc. No:

Date: Jun. 7, 2011 Rev.: 1.10 Page: 9



6.4.5 If test OK, please NTF test.

EAH5550 Standard Operation Procedure Doc. No:

Date: Jun. 7, 2011 Rev.: 1.10 Page: 10

# 7.Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	Dell 30 inches (3008WFP) (Buying a local LCD by yourself)			1	Page of the second of the seco
2	USB MOUSE			1	
3	PS/2 KEYBOARD			1	
4	ATX POWER SUPPLY(a minimum power of 1200W)			1	The Assertion of the Control of the
5	INTEL Celeron E1200			1	E1100
6	Heat sink + FAN	22-240000160		1	
7	DDR2(667/800) 1G	04G0016169A9NE /22-T00642404		4	
8	TEST HDD			1	
9	SATA HDD Cable	14-000107070	ASUS	1	
10	PCIEX16 VGA CARD			1	
11	Dual link DVI cable (Buying a local DVI cable by yourself)			1	
12	HDMI extend cable (Buying a local HDMI cable by yourself)			1	
13	Display port cable (Buying a local HDMI cable by yourself)	00 MDD5W0 #		1	THE SAME OF STREET
14	P5E MB	80- MBB7X0-*		1	