Rev.	Modified Chapters	Modification Description	Issued Dept.	Issued by	Revised Date
1.00		First Release	GRMA	Ariel_wang	May.2,2012

Authorize by		**Review by**		**Originator By**	**Ariel**

1.Objectives

Create test procedure.

2.Scope

Model: HD6750

PN: YV0123(A01)

3.Test Item

3.1 Diagnostic test in 64-bit Linux

3.2 3DMark06(contain HDMI test)

3.3 Temperature test

3.4 Fan test

4.Relevant Document

None.

5.Definition :

1. If the model name contains P, please test HDCP function. Ex: HD***/HTDP/512M/A

2. If you test HDMI already, it's unnecessary to test HDCP. The HDMI contains HDCP function.

3. System Memory: 1GB for a single GPU test station; please add an additional 512MB of system memory for each additional GPU used for the test configuration

4. HD6750 Test Program in 64-bit Linux system.

6. Operation Procedures:

6.1 Attention

6.1.1 To avoid damaging devices or M/B, please turn off A/C power then unplug VGA card.

6.1.2 While unplugging the card, do it in upright direction to avoid damaging slot & golden finger.

6.1.3 If any problem happens, please inform test supervisor. Base on ATX power specification, +5V standby voltage is existed while AC power is connecting. For safety reason, please turn off main power during break time or idling test.

6.1.4 Some test items should be tested under Windows environment. (Please install windows 7 test environment by yourself).

6.2 Fixture connect

6.2.1 Install Intel P7 CPU & CPU Fan.

6.2.2 Install DDR2 1GB Memory to DIMM1~4. **(a minimum memory of 2GB for Linux test)**

6.2.3 Plug USB Mouse and PS/2 Keyboard into MB.

6.2.4 Plug VGA Card HD6750 into PCIEX16_1.

 6.2.5 If this card has 6 PIN or 8 PIN of Power supply, please connect power con of VGA card & Power supply via bundled power cable.

   (6 PIN of Power supply to 6 PIN of VGA card)

    (8 PIN of Power supply to 8 PIN of VGA card)

6.2.6 Connect SATA HDD & SATA con via SATA cable

SATA

6.2.7 Plug 4PIN 12V power**(a minimum power of 1200W)** cable into CON12V.

6.2.8 Plug ATX Power on Power**(a minimum power of 1200W)** Connector.

6.3 Certain test.

### 6.3.1 Diagnostic test in 64-bit LINUX system

6.3.1.1 Please connect LCD monitor & card's DVI CON/D-SUB CON via a DVI /D-SUB cable.

D-SUB cable

Dual link DVI cable

6.3.1.2 Press Power Switch then turn on power button.

6.3.1.3 Press "Del" to enter CMOS setup menu while boot screen is displaying.

EXIT -> Load Setup Defaults.

6.3.1.4 Run test program in 64-bit linux system.

Path:hd6750\yv0123a0.sh

Please enter into the file of hd6750 enter the following command: cd ./hd6750

Then, please run ./yv0123a0.sh

6.3.1.5 Memory test

If you want to test memory, please run ./tserver -test=memfa

Path:hd6750\

6.3.1.6 BIOS Version

If you want to see the version of bios, please run ./atiflash –ai 0.

Path:hd6750\

6.3.1.7 BIOS flash

Please use the following command to flash bios and notice the size of character.

Path:hd6750\

Command:./atiflash -p -f 0 xxx.rom

Notice:

If you can not flash bios because of the bios locked, please use ./atiflash –unlockrom 0 to unlock bios. And then, please use ./atiflash –lockrom 0 to lock bios after updating latest bios.

6.3.1.8 FAN Test

If you want to test FAN, please run ./aft64102.

Path: Path:hd6750\AFT64100

Notice:

./aft64102 apply the following Part Number

YV0123-A01

6.3.1.9 After finishing 64-bit Linux testing, please enter Windows environment to test 3DMark.

6.3.2 3DMark test(contain HDMI test)

6.3.2.1 Please install 3DMark program by yourself.

6.3.2.2 Please connect VGA card to LCD via HDMI cable.

HDMI cable

HDMI Port

6.3.2.3 Please install VGA card driver in Windows(You must use individual driver of this card).

6.3.2.4 Please run 3DMark06 base on this card (please test 1 cycle).

6.3.2.5 Press "Select" to enter Select test menu. You can choose "HDR1" for default setting.

6.3.2.6 Press "Demo" to enter Demo menu. You can choose "Sounds" for default setting.

6.3.2.7 Please pay attention to check if there is flickering, discolor, crash and so on.
      If there's no problem, it can be judged OK!
6.3.2.8 Please listen to voice carefully to check whether it outputs sounds. If not, HDMI test
      fail.

6. 3.2.9 If test OK, please test temperature test.

6.4 Temperature test

6.4.1 Please copy Thermaltool(1.0.05) to Windows by yourself.

6.4.2 Please run ThermalTest.exe.

6.4.3 If test ok, show pass.

6.4.4 If test fail, show fail.

6.4.5 If test OK, please NTF test.

7.Appendix

NO#	Equipment Description	ASUS Part#	Supplier	Quantity	Remarks
1	**Dell 30 inches (3008WFP)** **(Buying a local LCD by yourself)**			**1**	
2	**USB MOUSE**			**1**	
3	**PS/2 KEYBOARD**			**1**	
4	**ATX POWER SUPPLY(a minimum power of 500W)**			**1**	
5	**Intel CPU** **Intel(R) Core(TM)2 CPU**		**local**	**1**	
6	**Heat sink + FAN**	**22-240000160**		**1**	
7	**DDR3 1333 2G**	**20-TT2605618**	**local**	**4**	
8	**TEST HDD**			**1**	
9	**SATA HDD Cable**	**14-000107070**	**ASUS**	**1**	
10	**PCIEX16 VGA CARD**			**1**	
11	**Dual link DVI cable** **(Buying a local DVI cable by yourself)**			**1**	
12	**HDMI extend cable** **(Buying a local HDMI cable by yourself)**			**1**	
13	**P7H55-M/USB3 MB**	**80- MIBBKA-***		**1**	
14	**Display port cable** **(Buying a local Display port cable by yourself)**			**1**	