
7-1. Components on the Rear Case




7-2. Pre-requisite




7-3. Disassembly

heating condition



- SOC 68%↓: 70 °C ±5/15±5 minute
- SOC 68% \uparrow : Disassemble before and after discharge
- * Please confirm the heating condition released lastly, and follow it.



1) Remove SIM Tray on side. 2) Disassemble Rear Cover.



Caution
 Be care of scratch.

3

Remove screws 13ea.



Caution
Be care of scratch.

Caution
 Be care of scratch.

1) Disassemble Rear TOP_ANT.2) Disassemble Rear BTM_ANT.



Caution
 Be care of Rear amage.

- 4
- 1) Remove PBA screws 2 points.
- 2) Disassemble LCD Connector



5 Detach other components.





X Caution

- 1) Be care of scratch.
- 2) Be care of Rear and connector damage.
- 3) Be careful not to damage the PBA.

- Caution
- 1) Be care of scratch.
- 2) Be careful not to damage the PBA.

7-4. Assembly

- 1) Assemble Main Camera.
- 2) Attache tape on connecotr of Main camera.



2 Assemble RCV, MOT, SPK.



Caution

Be care of PBA damages.


- 3
- 1) Assemble PBA on Front ass'y 2) Assemble LCD connector.
- 3) Assemble PBA screws 2 points
- * Torque Value : 1.2 \pm 0.1kgfcm



***** Caution

Be care of Battery and LCD damages.

- 1) Assemble Rear TOP_ANT.
- 2) Assemble Rear BTM_ANT.





- 1) Be care of FPCB damage and tilt.
- 2) Be care of PBA damages.

Caution

Be care of press REAR damage.

