7. Level 2 Repair

7-1. Pre-requisite



7-2. Parts which must be changed after repair



7-3. Disassembly

1



Temperature: 70~80 ° C

2



1) After heating for 10 minutes the decice at 70~80℃, take out the device from Mobile dryer.

 Detach the Bracket CU tape care fully from the OCTA Cu sheet using Glass absorber and holder.
Be careful not to separate LCD from TSP.

3



4



1) Disassemble loosen 12 Point of Bracket

1) Disassemble Bracket and REAR

5 6 SAMSUNG 1) Loosen a Screw in PBA Ass'y 1) Detach the Bracket and REAR 7 8 SAMSUNG SAMSUNG 1) Detach Connector and Coaxial Cable 1) Detach the PBA from bottom REAR 2) Be careful not to damage from PBA


9

10





- 1) Detach Main and Sub Camera on PBA
- 1) Detach the Receiver, Speaker, Coaxial Cable and Battery



12



- 1) Detach upper Sub PBA and Power key
- 2) Be careful not to Damage

- 1) Detach lower Sub PBA from Bracket
- 2) Be careful not to Damage

7-4. Assembly

1



2



1) Assemble lower Sub PBA on Bracket

 Assemble the Upper/Lower SUB PBA and Coaxial Cable Then RCV, Speaker, Power Key

3



4



- 1) Attach Battery on Bracket
- 2) Press Battery using Battery Pressing JIG.
- 1) Attach Main and Sub Camera on PBA

5



6



- 1) Assemble PBA on Bracket
- 2) Assemble lower Sub PBA and Main PBA
- 1) Assemble Connector on the PBA Assy
- 2) Assemble Coaxial Cable

7



8



1) Tighten a screw

 $1.2 \pm 0.1 \text{ Kgf/cm}^2$

1) Assemble PBA ass'y and REAR

5





1) Tighten screw the 12 point 1.2 ± 0.1 Kgf/am²

- 1) Assemble LCD Connector
- 2) Attach LCD and REAR ass'y

7



1) Press OCTA Window using Window pressing JIG.