

SM-A920F RF Block Diagram REV00


2018.07.26 H/W R&D Group1 Seungwan Yang

[지원밴드] • 2G: GSM850 / GSM900 / DCS1800 / PCS1900 3G: WB1, 2, 4, 5, 8 MAIN H 4G: FDD B1, 2, 3, 4, 5, 7, 8, 12, 13, 17, 20, 26, 28, 66 TDD B34, 38, 39, 40, 41 TD-SCDMA: 34, 39 CDMA: BC0 **HBPA** SKY77786-11 PRX_TR_IN_B38_40_41 MXD8642 TRX_B38_41 0 TRX_B40 TX_TR_OUT_B7_38_40_41_CH0 TRX_B7 PRX_TR_IN_B7 **B7** TX_PA_OUT_B13 0 TX_PA_OUT_B28 RFIC **MMMB** SDR660 SKY77656-11 TX_PA_OUT_B5_ TX_PA_OUT_B8 TX_TR_OUT_B5_8_12_13_17_20 _26_28_BC0____ TX_PA_OUT_12_17 MAIN_LM TX PA OUT 20 TX_PA_OUT_B34_3 TX PA OUT B1 TX_PA_OUT_B3_4 TX_PA_OUT_B66 TX_PA_OUT_B2 Diple xer Coupler VRF_PAM_VCC1 VPH_PW TX_PA_OUT_GSMLE TX TR OUT GSMLB TX_TR_OUT_GSMHB TX_PA_OUT_GSMHB **FEMID** D5328 PRX TR IN B1 4 PRX TR IN B1 4 66 MB B1 PRX_TR_IN_B1_4_HB PRX_TR_IN_B4_66 RF3 RF2 PRX_TR_IN_B2_PCS DRX B5 ASDIV ASDIV_B5_TX PRX_B3_G1800 PRX_TR_IN_G1800_B3 PRX_TR_IN_EGSM_B8 PRX_TR_IN_B20 PRX_TR_IN_B5_26_G850_BC0 PRX_TR_IN_B12_17 PRX_TR_IN_B13 TRX_B13 AUX_LB2 TX_PA_OUT_B13 PRX_TR_IN_B66 TRX_B66 TX_PA_OUT_B66 SUB L PRX_TR_IN_B28 TRX B28 TX_PA_OUT_B28 AUX_MB1 AUX_LB1 AUX_MB3 PRX_TR_IN_B34_39 B34/39 AUX_MB4 DRX_TR_IN_B5_AS B5 0 0 SFML7E0H001 **DRX LFEM** SUB MH 06 DRX ANT LB DRX_TR_IN_B5_8_13_17_20_26_28_BC0 0 GPS_ANT_TEST 0 DRX_TR_IN_B1_4_HB SADRM1G DRX ANT MB DRX_TR_IN_B2_3_34_39_66 DPX252690D T-5325A1K LNA1/2 DRX_TR_IN_B7_38_40_41 B2,B4/66: SFHG60BA002 B34/39: SFWG00DB002 B38/41: SFDG93AQ902 B40: SAFFB2G35AA0F3K B28: SFH780AQ102 외부필터

AUX

AUX

8-3. Flow chart of Troubleshooting.





Oscilloscope


Digital Multimeter





Power Supply

+ driver, ESD Safe Tweezer







8960 & Spectrum Analyzer

Soldering iron


8-4-1. Power On/ ligando




8-4-2. Initial/ inicialização




8-4-3. No Service/ sem sinal de rede



8-4-4. SIM Part/ chip




8-4-5. T-Flash Part/ cartao de memoria




8-4-6. Cable Charging Part (Normal/Fast)

8₂4-6. Parte de carregamento do cabo (normal/rápido) Insira TA/USB YES Início da sequência de carregamento VBUS_IF_5P0(C6036) = 5V ou 9V NO Replace SUB PBA YES NO Verifica a Substitua U6002 CHG_IN_5P0(C6035)=5V ou 9V YES NO A bateria está carregando? Substitua U5002 YES fim


8-4-7. OTG




8-4-8-1. Magnetic Sensor/ Sensor magnético




8-4-8-2. 6Axis Sensor




8-4-8-3. Proximity + RGB Light sensor/ Sensor de proximidade + luz RGB




8-4-8-4. Fingerprint Sensor/ Sensor de impressão digital




8-4-9-1. Microphone Part - Main MIC/Peça do microfone - MIC principal




8-4-9-2. Microphone Part - Sub(2nd) MIC/ Peça do Microfone - Sub(2º) MIC




8-4-10. Speaker Part/Parte do alto-falante




Parte Receptora




8-4-12. BT/WIFI




8-4-13. GPS




8-4-15. Display/ tela




8-4-16. 24M CAMERA(FRONT CAMERA)/CÂMERA 24M (CÂMERA FRONTAL)




8-4-17-1. QUAD CAMERA(REAR CAMERA, 24M, WIDE) CÂMERA QUAD (CÂMERA TRASEIRA, 24M, LARGA)




8-4-17-2. QUAD CAMERA(REAR CAMERA, 5M, DEPTH)CÂMERA QUAD (CÂMERA TRASEIRA, 5M, PROFUNDIDADE)




8-4-17-3. QUAD CAMERA(REAR CAMERA, 8M, ULTRA WIDE)/ CÂMERA QUADRADA (CÂMERA TRASEIRA, 8M, ULTRA LARGA)




8-4-17-4. QUAD CAMERA(REAR CAMERA, 10M, TELE)CÂMERA QUAD (CÂMERA TRASEIRA, 10M, TELE)



8-4-18. TSP/ toush



8-4-19. Motor



8-5. Service Schematics

- NC Point(Top View)

