



Generator Operation Safety Guidelines

Purpose:

Ensure that the generator operation and maintenance follow the related guidelines.

Maintenance Manual:

1. Clean air filter element within every 50H of use of the generator;
2. Replace the generator engine oil for new generator after using for 20H;
3. Replace regularly oil of generator after using for 50H. If the oil fails to be replaced regularly, it is prone to causing damage to the generator;
4. When filling fuel, it is strictly forbidden to remove fuel filter screen out of the filler of the fuel tank;
5. The damping pad of the wheel must be mounted before operation.
6. After using for 100H, inspect and clean up the carbon deposit of spark plug to ensure the spark plug gap (0.7-0.8mm); replace the spark plug after using more than 200H;
7. If often working in high-temperature environment, replace the engine oil every 10H.
8. If working in dusty areas, clean the air filter every 10H.
9. If the generator has not been used for long time (more than 30



days), turn off the fuel switch and drain off gasoline in the carburetor.

Operation Manual:

1. It is strictly forbidden to fill gasoline into the fuel tank when the generator is started;
2. It is strictly forbidden to omit the installation of wheel damping pad;
3. It is strictly forbidden to work under a tree with electricity in rainy days, and expose the generator in the rain to use;
4. It is strictly forbidden to connect the generator to the mains supply or other generator. Please use it alone;
5. It is strictly forbidden to smoke nearby fuel. In addition, keep away from other open flame, spark, etc;
6. When using the generator, make sure that there is no combustible material nearby the exhaust port of generator muffler;
7. Inspect the oil circuit (fuel tank and engine oil) when starting the generator next day;
8. When starting up the generator, pressing the one-button start switch shall not exceed (3S); and it is forbidden to press and hold the button for long time;
9. Please separate the generator from combustible material for 1M



and more;

10. The generator is not filled with engine oil when leaving the factory, please fill 1.1L of engine oil before using the new generator;

11. If the generator is unable to be started by electric starting, start the generator by pulling the start handle;

12. Warning indicator description:

- 1) Solid yellow – Main board is abnormal and the power is limited.
- 2) Blinks yellow once continuously – The power module is abnormal and the power is limited
- 3) Blinks red once continuously - The fan has stalled or the power module has experienced a critical error or is unavailable.
- 4) Blinks red four times continuously – Engine oil needs to be changed
- 5) Solid red - Main board is abnormal and unavailable