

【EN】 1P Recommended Maintenance Cycle					
Module		Maintenance Period			Recommended Replacement Time (Important)
	Picture	Recommended Maintenance Time	Check Item	Solution	
Motor		1. Perform the first check after the new drone has flown 100 flights. 2. After the first check, check the motor every 100 hours. 3. If the motor prompts that the motor cannot rotate smoothly or that the motor/ESC temperature is abnormal, perform an inspection.		Check the product during the repair.	Replace after 1000 hours of use.
Propeller		1. Perform the first check after the new drone has flown 100 flights. 2. After the first check, check the motor every 100 hours. 3. If the motor prompts that the motor cannot rotate smoothly or that the motor/ESC temperature is abnormal, perform an inspection.		Check the product during the repair.	Replace after 1000 hours of use.
Motor Base		Pre-work daily inspection		Check the product during the repair.	Replace after 1000 hours of use.
Propeller Adapter		100h		Check the product during the repair.	Replace after 1000 hours of use.
Aircraft Arm Screw		Pre-work daily inspection		Check the product during the repair.	Replace after 1000 hours of use.
Aircraft Fixing Screw		100h		Check the product during the repair.	Replace after 1000 hours of use.
Landing Gear Fixing Screw Bolt		100h		Check the product during the repair.	Replace after 1000 hours of use.
Radar Fixing Bracket		100h		Check the product during the repair.	
Delivery Pump		100h		Check the product during the repair.	300h Or Replace the hardware after 24 months of use.
Delivery Pump		When it is found that the delivery pump's flow rate is abnormal, check the product.		When it is found that the delivery pump's flow rate is abnormal, check the product.	Replace
Nozzle		When it is found that the delivery pump is seeping water, check the product.		When it is found that the delivery pump is seeping water, check the product.	
Hose Connector		Pre-work daily inspection		Check the product during the repair.	
Spray Tank One-way Valve Sealing Ring		Pre-work daily inspection		Check the product during the repair.	
Pipeline		Pre-work daily inspection		Check the product during the repair.	
Filter		Pre-work daily inspection		Check the product during the repair.	
Spraying System		Pre- and post-work daily inspection		Check the product during the repair.	

ESC		6 months	1. Clean the ESC and check whether it has any corrosion. 2. Mount the ESC to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Flight Controller		6 months	Clean the flight controller, mount it to the drone, and check the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Radar		6 months	1. Clean the radar and check whether it has any corrosion. 2. Mount the radar to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Central Board		6 months	1. Clean the central board and check whether it has any corrosion. 2. Mount the central board to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Power Distribution Board		6 months	1. Clean the power distribution board and check whether it has any corrosion or is scorched. 2. Mount the power distribution board to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
OcuSync Module		6 months	1. Clean the OcuSync module and check whether it has any corrosion. 2. Mount the OcuSync module to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
FPV Module		6 months	1. Clean the FPV module and check whether it has any corrosion. 2. Mount the FPV module to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
GNSS Module		6 months	1. Clean the GNSS module and check whether it has any corrosion. 2. Mount the GNSS module to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Liquid Level Meter		3 months	1. Clean the liquid level meter and check whether it has any corrosion. 2. Mount the liquid level meter to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Operation Resume Module (MG-1P RTK)		6 months	1. Clean the operation resume module and check whether it has any corrosion. 2. Mount the operation resume module to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Aircraft Cable		100h	1. Clean the cable and check whether it has any corrosion. 2. Attach the cable to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.		
LED		6 months	1. Clean the LED and check whether it has any corrosion. 2. Mount the LED to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Image Transmission Antenna		6 months	1. Clean the image transmission antenna and check whether it has any corrosion. 2. Attach the image transmission antenna to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	
Y-type Composite Cable		6 months	1. Clean the Y-type composite cable and check whether it has any corrosion. 2. Attach the Y-type composite cable to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	
Compass Module		6 months	1. Clean the compass module and check whether it has any corrosion. 2. Mount the compass module to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
RTK Board		6 months	1. Clean the RTK board and check whether it has any corrosion. 2. Mount the RTK board to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	Check the product during the repair.	Replace the hardware after 24 months of use.
Remote Controller		3 months	1. Clean the remote controller and check whether it has any corrosion. 2. Mount the remote controller to the drone, power on the drone, and check whether the drone can be powered on normally and function properly.	The maintenance cycle can be adjusted based on the actual operation.	Replace the hardware after 24 months of use.
Battery		3 months or 200 charge cycles	1. Check whether the battery is swollen. 2. Charge and discharge the battery at least once every three months to maintain the battery as active.	The maintenance cycle can be adjusted based on the actual operation.	300 charge cycles
Charger		3 months or 200 charge cycles	Check whether the charger is damaged or working abnormally.	The maintenance cycle can be adjusted based on the actual operation.	

