

1. 故障代码列表 Error Codes list :

代码 Error Code	故障名称 Error Name	故障灯连闪次数 Error light continuously flashes times
P0261	喷嘴故障 Injector error	1
P0230	油泵故障 Fuel Pump error	4
P0350	点火线圈故障 Ignition coil error	8
P0650	故障指示灯故障 Error indicator fault	故障灯故障只能用 OBD 读取故障代 码 error indicator fault can only use OBD to read the error code
P0123	油门位置传感器对电短路 Throttle position sensor electrically short-circuit	7
P0122	油门位置传感器对地短路 Throttle position sensor short circuit to ground	
P0120	油门位置传感器故障 Throttle position sensor error	
P0118	缸温传感器对电短路 Cylinder cover temperature sensor electrically short-circuit	5
P0117	缸温传感器对地短路 Cylinder temperature sensor short circuit to ground	
P0108	进气压力传感器对电短路 Intake pressure sensor electrically short-circuit	2
P0107	进气压力传感器对地短路 Intake pressure sensor short circuit to ground	
P0106	进气压力传感器故障 Intake pressure sensor error	
P0113	进气温度传感器对电短路 Intake temperature sensor electrically short-circuit	9
P0112	进气温度传感器对地短路 Intake temperature sensor short circuit to ground	
P0132	氧传感器对电短路 Oxygen sensor error electrically short-circuit	3

P0131	氧传感器对地短路 Oxygen sensor error short circuit to ground	
P0130	氧传感器故障 Oxygen sensor error	
P0562	电瓶电压 $\leq 12V$ Low battery voltage	上电常亮 When started up the generator, error indicator is always on.
P0561	启动后充电电压 $\leq 12V$ Low charging voltage after startup	启动后常亮 When started up the generator, error indicator is always on.
P0563	电瓶电压 $\geq 16V$ high battery voltage	上电常亮 When started up the generator, error indicator is always on.