

HowTo: Encode MIFARE Cards

#### Requirements:

Working CT station, connected to the network and the server

MIFARE Card Reader/Writer (We are currently using an Ask Logo RDR608-I Type RD-DE-09084-10)

CT Software (version V14.92.0.0 Dated 9/21/2020 or greater)


### Steps:

#### Encoding the card

Begin the process by having the CT application running and being logged into a shift.


Close the Transactions menu (if present).

Click on **Encoder** > **Encode** > **Mifare encode**.




Click in the **First ticket number to encode** field and enter the ticket number. (In this case, it's **99994.** It will match what is printed on the card.)






Enter 1 for the Version, 1 for Quantity to be encoded and tick the encoding/recoding on a blank title check box.

Next, click on **Writing** (or press the Enter key).




# This will display the following prompt:



## Place the card on the MIFARE Reader/Writer.




At this point, the system will display the **last title encoded**. It should match the title number that you entered in a previous step.




# To verify the card status:

### Click on the **Reading** button.



The system will display the following:



Tap or touch the card to the MIFARE reader/writer.



The ticket number that you previously encoded to the card will be displayed in the **First ticket number to encode** field, highlighted in blue.

