0			NOT_EXEC	This is the code to use when creating a PR15 program. The firmware knows that if it sees a command with this code it has to execute it.
1	C	**C**ommand done	COMMAND_DONE	The command has been successfully executed with no errors.
8	F	can't **F**ind command	COMMAND_UNKNOWN	The command code is unknown.
9	E	**E**rror	COMMAND_ERROR	The command is known but there is an error with it. For instance, an invalid slot number.