AUDI A4 B9 LANE ASSIST ENABLE

https://vagupdate.ru/coding.php?section=1&subsection=8

Lane Assist Activation

Link
Requirement: A windshield camera must be installed

When prompted for a code, enter 20103
Block A5 (Lane Assist Camera) → Coding:
- ALDW_lane_assist: installed

Enable new functions in the menu
Block 5F (Multimedia) → Adaptation:
Car_Function_List_BAP_Gen2:
- LDW_HCA_0x19: Activate
- LDW_HCA_0x19_msg_bus: Terminal 15

Car_Function_Adaptations_Gen2:
- menu_display_Lane_Departure_Warning: Activate
- menu_display_Lane_Departure_Warning_over_threshold_high: Activate
- HCA – Notifies the steering control unit of the presence of Lane Assist

Block 44 (Power Steering) → Coding:
Lane Assist, linked to power steering
- Byte 03 – Bit 1 (heading_control_assist): Activate

Block 09 (On-board network) → Adaptation:
- Heading Control config: heading_control
- Enable display of Lane Assist on the instrument cluster

Block 17 (Instrument cluster/ActiveInfoDisplay) → Coding:
- Lane_assist -> yes

Block A5 (Lane Assist camera) → Adaptation:
Lane_departure_warning_on_state:
- Selection_over_menu_default_on -> apply

Personalisation_for_lane_departure_warning:
- TT_activated_not_activated: last_setting

Confidential C