Signal Name	FPGA Pin Number	Description
		·
KEY0	PIN U7	Push-button[0]
KEY1	PIN W9	Push-button[1]
KEY2	PIN M7	Push-button[2]
KEY3	PIN M6	Push-button[3]
KETO	1 III_III0	1 don battonioj
SW0	PIN_U13	Clide Cwitch[0]
SW1	PIN_U13	Slide Switch[0] Slide Switch[1]
SW2	PIN_V13	Slide Switch[2]
SW3	PIN_T12	Slide Switch[3]
SW4	PIN AA15	Slide Switch[4]
SW5	PIN_AA15	Slide Switch[5]
SW6	PIN AA14	Slide Switch[6]
SW7	PIN_AA14	Slide Switch[7]
SW8	PIN_AA13	Slide Switch[8]
SW9	PIN_AB13	Slide Switch[9]
3449	FIN_AD12	Sinde Switch[9]
. ====		1.=5.40
LEDR0	PIN_AA2	LED [0]
LEDR1	PIN_AA1	LED [1]
LEDR2	PIN_W2	LED [2]
LEDR3	PIN_Y3	LED [3]
LEDR4	PIN_N2	LED [4]
LEDR5	PIN_N1	LED [5]
LEDR6 LEDR7	PIN_U2 PIN U1	LED [6]
LEDRI	PIN_U1	LED [7] LED [8]
LEDR9	PIN_L2	LED [9]
LEDRA	PIN_L1	FED [9]
11=3/44		
HEX00	PIN_U21	Seven Segment Digit 0[0]
HEX01	PIN_V21	Seven Segment Digit 0[1]
HEX02	PIN_W22	Seven Segment Digit 0[2]
HEX03	PIN_W21	Seven Segment Digit 0[3]
HEX04	PIN_Y22 PIN_Y21	Seven Segment Digit 0[4]
HEX05	PIN_Y21	Seven Segment Digit 0[5]
HEX06	PIN_AA22	Seven Segment Digit 0[6]
HEX10 HEX11	PIN_AA20	Seven Segment Digit 1[0] Seven Segment Digit 1[1]
HEX12	PIN_AB20	Seven Segment Digit 1[1] Seven Segment Digit 1[2]
HEX13	PIN_AA19	Seven Segment Digit 1[2] Seven Segment Digit 1[3]
HEX14	PIN_AA16	Seven Segment Digit 1[3] Seven Segment Digit 1[4]
HEX15	PIN_AB10	Seven Segment Digit 1[4] Seven Segment Digit 1[5]
HEX16	PIN_AA17	Seven Segment Digit 1[6]
HEX20	PIN_V19	Seven Segment Digit 1[0]
HEX21	PIN_119	Seven Segment Digit 2[1]
HEX22	PIN_AB17	Seven Segment Digit 2[1]
HEX23	PIN_AATO	Seven Segment Digit 2[2]
HEX24	PIN_114	Seven Segment Digit 2[3]
いレハムマ	1 114_V 14	Deven Deginent Digit 4[4]

HEX25	PIN AB22	Seven Segment Digit 2[5]
HEX26	PIN AB21	Seven Segment Digit 2[6]
HEX30	PIN Y16	Seven Segment Digit 3[0]
HEX31	PIN W16	Seven Segment Digit 3[1]
HEX32	PIN Y17	Seven Segment Digit 3[2]
HEX33	PIN V16	Seven Segment Digit 3[3]
HEX34	PIN U17	Seven Segment Digit 3[4]
HEX35	PIN V18	Seven Segment Digit 3[5]
HEX36	PIN V19	Seven Segment Digit 3[6]
HEX40	PIN U20	Seven Segment Digit 4[0]
HEX41	PIN Y20	Seven Segment Digit 4[1]
HEX42	PIN V20	Seven Segment Digit 4[2]
HEX43	PIN U16	Seven Segment Digit 4[3]
HEX44	PIN U15	Seven Segment Digit 4[4]
HEX45	PIN Y15	Seven Segment Digit 4[5]
HEX46	PIN P9	Seven Segment Digit 4[6]
HEX50	PIN N9	Seven Segment Digit 5[0]
HEX51	PIN M8	Seven Segment Digit 5[1]
HEX52	PIN T14	Seven Segment Digit 5[2]
HEX53	PIN P14	Seven Segment Digit 5[3]
HEX54	PIN C1	Seven Segment Digit 5[4]
HEX55	PIN C2	Seven Segment Digit 5[5]
HEX56	PIN W19	Seven Segment Digit 5[6]
CLOCK 50	PIN M9	50 MHz clock input(Bank 3B)
CLOCK2 50	PIN H13	50 MHz clock input(Bank 7A)
CLOCK3 50	PIN E10	50 MHz clock input(Bank 8A)
CLOCK4 50	PIN V15	50 MHz clock input(Bank 4A)
		,
GPIO_0_D0	PIN_N16	GPIO Connection 0[0]
GPIO_0_D1	PIN_B16	GPIO Connection 0[1]
GPIO 0 D2	PIN_M16	GPIO Connection 0[2]
GPIO_0_D3	PIN_C16	GPIO Connection 0[3]
GPIO_0_D4	PIN_D17	GPIO Connection 0[4]
GPIO_0_D5	PIN_K20	GPIO Connection 0[5]
GPIO_0_D6	PIN_K21	GPIO Connection 0[6]
GPIO_0_D7	PIN_K22	GPIO Connection 0[7]
GPIO_0_D8	PIN_M20	GPIO Connection 0[8]
GPIO_0_D9	PIN_M21	GPIO Connection 0[9]
GPIO_0_D10	PIN_N21	GPIO Connection 0[10]
GPIO_0_D11	PIN_R22	GPIO Connection 0[11]
GPIO_0_D12	PIN_R21	GPIO Connection 0[12]
GPIO_0_D13	PIN_T22	GPIO Connection 0[13]
GPIO_0_D14	PIN_N20	GPIO Connection 0[14]
GPIO_0_D15	PIN_N19	GPIO Connection 0[15]
GPIO_0_D16	PIN_M22	GPIO Connection 0[16]
GPIO_0_D17	PIN_P19	GPIO Connection 0[17]
GPIO_0_D18	PIN_L22	GPIO Connection 0[18]
GPIO_0_D19	PIN_P17	GPIO Connection 0[19]
GPIO_0_D20	PIN_P16	GPIO Connection 0[20]
GPIO_0_D21	PIN_M18	GPIO Connection 0[21]
GPIO_0_D22	PIN_L18	GPIO Connection 0[22]
GPIO_0_D23	PIN_L17	GPIO Connection 0[23]

GPIO_0_D25	PIN_K17	GPIO Connection 0[25]
GPIO_0_D26	PIN_K19	GPIO Connection 0[26]
GPIO_0_D27	PIN_P18	GPIO Connection 0[27]
GPIO_0_D28	PIN_R15	GPIO Connection 0[28]
GPIO_0_D29	PIN_R17	GPIO Connection 0[29]
GPIO_0_D30	PIN_R16	GPIO Connection 0[30]
GPIO_0_D31	PIN_T20	GPIO Connection 0[31]
GPIO_0_D32	PIN_T19	GPIO Connection 0[32]
GPIO_0_D33	PIN_T18	GPIO Connection 0[33]
GPIO_0_D34	PIN_T17	GPIO Connection 0[34]
GPIO_0_D35	PIN_T15	GPIO Connection 0[35]
GPIO_1_D0	PIN_H16	GPIO Connection 1[0]
GPIO_1_D1	PIN_A12	GPIO Connection 1[1]
GPIO_1_D2	PIN_H15	GPIO Connection 1[2]
GPIO_1_D3	PIN_B12	GPIO Connection 1[3]
GPIO_1_D4	PIN_A13	GPIO Connection 1[4]
GPIO_1_D5	PIN_B13	GPIO Connection 1[5]
GPIO_1_D6	PIN_C13	GPIO Connection 1[6]
GPIO_1_D7	PIN_D13	GPIO Connection 1[7]
GPIO_1_D8	PIN_G18	GPIO Connection 1[8]
GPIO_1_D9	PIN_G17	GPIO Connection 1[9]
GPIO_1_D10	PIN_H18	GPIO Connection 1[10]
GPIO_1_D11	PIN_J18	GPIO Connection 1[11]
GPIO_1_D12	PIN_J19	GPIO Connection 1[12]
GPIO_1_D13	PIN_G11	GPIO Connection 1[13]
GPIO_1_D14	PIN_H10	GPIO Connection 1[14]
GPIO_1_D15	PIN_J11	GPIO Connection 1[15]
GPIO_1_D16	PIN_H14	GPIO Connection 1[16]
GPIO_1_D17	PIN_A15	GPIO Connection 1[17]
GPIO_1_D18	PIN_J13	GPIO Connection 1[18]
GPIO_1_D19	PIN_L8	GPIO Connection 1[19]
GPIO_1_D20	PIN_A14	GPIO Connection 1[20]
GPIO_1_D21	PIN_B15	GPIO Connection 1[21]
GPIO_1_D22	PIN_C15	GPIO Connection 1[22]
GPIO_1_D23	PIN_E14	GPIO Connection 1[23]
GPIO_1_D24	PIN_E15	GPIO Connection 1[24]
GPIO_1_D25	PIN_E16	GPIO Connection 1[25]
GPIO_1_D26	PIN_F14	GPIO Connection 1[26]
GPIO_1_D27	PIN_F15	GPIO Connection 1[27]
GPIO_1_D28	PIN_F13	GPIO Connection 1[28]
GPIO_1_D29	PIN_F12	GPIO Connection 1[29]
GPIO_1_D30	PIN_G16	GPIO Connection 1[30]
GPIO_1_D31	PIN_G15	GPIO Connection 1[31]
GPIO_1_D32	PIN_G13	GPIO Connection 1[32]
GPIO_1_D33	PIN_G12	GPIO Connection 1[33]
GPIO_1_D34	PIN_J17	GPIO Connection 1[34]
GPIO_1_D35	PIN_K16	GPIO Connection 1[35]
VGA R0	PIN A9	VGA Red[0]
VGA_R0 VGA_R1	PIN_A9 PIN B10	VGA Red[0] VGA Red[11
VGA_R0 VGA_R1 VGA_R2	PIN_A9 PIN_B10 PIN_C9	VGA Red[0] VGA Red[1] VGA Red[2]

VGA G0	PIN L7	VGA Green[0]
VGA G1	PIN K7	VGA Green[1]
VGA G2	PIN J7	VGA Green[2]
VGA G3	PIN J8	VGA Green[3]
VGA B0	PIN B6	VGA Green[6]
VGA B1	PIN B7	VGA Blue[1]
VGA B2	PIN A8	VGA Blue[1] VGA Blue[2]
VGA_B2	PIN_A0	VGA Blue[2]
VGA_BS	PIN_A7	VGA Bide[5] VGA H_SYNC
VGA_HS	PIN_G8	VGA H_STNC
VGA_VS	PIN_G0	VGA V_STNC
PS2 CLK	PIN D3	PS/2 Clock
PS2_OLK	PIN G2	PS/2 Data
PS2_CLK2	PIN_G2	PS/2 Clock (reserved for second PS/2
P32_CLR2	PIN_E2	device)
PS2_DAT2	PIN_G1	PS/2 Data (reserved for second PS/2
		device)
0D 011/	DIN HAA	Out of Olivers
SD_CLK	PIN_H11	Serial Clock
SD_CMD	PIN_B11	Command, Response
SD_DATA0	PIN_K9	Serial Data 0
SD_DATA1	PIN_D12	Serial Data 1
SD_DATA2	PIN_E12	Serial Data 2
SD_DATA3	PIN_C11	Serial Data 3
DRAM_ADDR0	PIN_W8	SDRAM Address[0]
DRAM_ADDR1	PIN_T8	SDRAM Address[1]
DRAM_ADDR2	PIN_U11	SDRAM Address[2]
DRAM_ADDR3	PIN_Y10	SDRAM Address[3]
DRAM_ADDR4	PIN_N6	SDRAM Address[4]
DRAM_ADDR5	PIN_AB10	SDRAM Address[5]
DRAM ADDR6	PIN P12	SDRAM Address[6]
DRAM ADDR7	PIN P7	SDRAM Address[7]
DRAM ADDR8	PIN P8	SDRAM Address[8]
DRAM ADDR9	PIN R5	SDRAM Address[9]
DRAM ADDR10	PIN U8	SDRAM Address[10]
DRAM_ADDR11	PIN_P6	SDRAM Address[11]
DRAM ADDR12	PIN R7	SDRAM Address[12]
DRAM DQ0	PIN Y9	SDRAM Data[0]
DRAM DQ1	PIN T10	SDRAM Data[1]
DRAM DQ2	PIN R9	SDRAM Data[2]
DRAM DQ3	PIN Y11	SDRAM Data[2]
DRAM DQ4	PIN R10	SDRAM Data[5]
DRAM DQ5	PIN R11	SDRAM Data[5]
DRAM DQ6	PIN R12	SDRAM Data[6]
DRAM DQ7	PIN_K12	SDRAM Data[0]
DRAM DQ8	PIN_AA12	SDRAM Data[7]
DRAM DQ9	PIN_AB8	SDRAM Data[9]
DRAM DQ10	PIN_AA8	SDRAM Data[9] SDRAM Data[10]
DRAM_DQ10	PIN_AA7	SDRAM Data[10]
DRAM_DQ11	PIN_AA7	
		SDRAM Data[12]
DRAM_DQ13	PIN_V9	SDRAM Data[13]
DRAM_DQ14	PIN_U10	SDRAM Data[14]

DRAM_DQ15	PIN_T9	SDRAM Data[15]
DRAM_BA0	PIN_T7	SDRAM Bank Address[0]
DRAM_BA1	PIN_AB7	SDRAM Bank Address[1]
DRAM_LDQM	PIN_U12	SDRAM byte Data Mask[0]
DRAM_UDQM	PIN_N8	SDRAM byte Data Mask[1]
DRAM_RAS_N	PIN_AB6	SDRAM Row Address Strobe
DRAM_CAS_N	PIN_V6	SDRAM Column Address Strobe
DRAM_CKE	PIN_R6	SDRAM Clock Enable
DRAM_CLK	PIN_AB11	SDRAM Clock
DRAM_WE_N	PIN_AB5	SDRAM Write Enable
DRAM_CS_N	PIN_U6	SDRAM Chip Select