Hazard ID	Situational Analysis						Hazard Identification						Hazardous Event Classification						Determination of ASIL and Safety Goals		
	Operational Mode	Operational Scenario	Environmental Details	Situation Details	Other Details (optional)	Item Usage (function)	Situation Description	Function	Deviation	Deviation Details	Hazardous Event (resulting effect)	Event Details	Hazardous Event Description	Exposure (of situation)	Rationale (for exposure)	Severity (of potential harm)	Rationale (for severity)	Controllability (of hazardous event)	Rationale (for controllability)	ASIL Determination	Safety Goal
HA-001	OM03 - Normal Driving	OS04 - Highway	EN06 - Rain (slippery road)	SD02 - High speed		IU01 - Correctly used	correctly used system.	Lane Departure Warning (LDW) function shall apply ar oscillating steering torque to provide the driver with haptic feedbank	DV04 - Actor effect is too much	The Lane Departure Warning function applies an oscillating torgue with very high torque (above limit.)	EV00 - Collision with other vehicle.	intented. The driver loose control		E3 - Medium probability	Driving on a highway with rain could happen between 1% and 10% of the time operating the vehicle.	S3 - Life-threatening or fatal injuries	Collisions at high spee could cause fatal injuries.	d C3 - Difficult to control or uncontrollable	It is difficult to stay caim and react properly when the steering well is moving too much.	С	The oscillating steering torque from the Lane Departure Warning function shall be limited.
HA-002	OM03 - Normal Driving	OS03 - Country Road	EN01 - Normal conditions	SD02 - High speed		IU02 - Incorrectly used	normal conditions with high speed and incorrectly used systam.	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in em lane	DV03 - Function is always activated	Lane Keeping function is always activated	EV00 - Collision with other vehicle.		The driver do not use the function properly.	E2 - Low probability	The conviation beween driving at a country road and misusing system should not happen oftem. Less than 1% of the time operating the vehicle.	S3 - Life-threatening or fatal injuries	Collisions at high spee could cause fatal injuries.	d C3 - Difficult to control or uncontrollable	When the driver loose focus on driving, it is dflicult to re-focus in the case of imminent collition.	В	The Lane Keeping Assistance function shall be time limited, and additional steering torque shall end after a given time interval so the driver carnot misuse the system for autonomous driving.
HA-003			EN06 - Rain (slippery road)				(slippery road) with high speed and correctly used system.			The Lane Departure Warning function continues to be activated even though the camera subsystem stops sending request for LDW activity.	EV00 - Collision with other vehicle.		to be active even in the absence of requests from the camera subsystem	E3 - Medium probability	10% of the time operating the vehicle.	S3 - Life-threatening or fatal injuries	Collisions at high spee could cause fatal injuries.	or uncontrollable	When the driver loose control of the vechicle is very difficult to realize the situation and act accordently.	С	The Lane Departure Warning function shall be deactivated when the camera sensor stop working.
HA-004	OM03 - Normal Driving	OS04 - Highway	EN06 - Rain (slippery road)	SD02 - High speed		IU01 - Correctly used	(slippery road) with high speed and correctly used system.	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in em lane	DV02 - Function unexpectedly activated	The Lane Keeping Assistance function continues to be activated even though the camera subsystem stops sending remuest for LKA activity	EV00 - Collision with other vehicle.		The LKA function continues to be active even in the absence of requests from the camera subsystem			S3 - Life-threatening or fatal injuries	Collisions at high spee could cause fatal injuries.	d C3 - Difficult to control or uncontrollable	When the driver loose control of the vechicle is very difficult to realize the situation and act accordently.	c	The Lane Keeping Assistance function shall be deactivated when the camera sensor stop working.