

How to enable driver to support 802.11d

2013/01/21

Introduction

country IE) in AP's beacon to specify what channel plan the AP applied now, and STA can follow the country IE to decide its channel plan.

In Realtek wireless LAN (WLAN) driver, it can support 802.11d function when setting is configured correctly. If 802.11d support is enabled, driver would retrieve channel plan from first scanned AP which its beacon contains country IE, then driver will keep the channel plan and follow it to do site survey.

That is if WLAN channel of WLAN driver would change the scan type of channel from passive to active. And next time when WLAN need to do site survey, it will send probe request in that channel. This can help WLAN to scan more available APs in that legal channel and connect to hidden-SSID APs in passive scan channels.


Summary the functions Realtek WLAN would be active when enable **802.11d support**:

1. **Change channel scan type to active if some AP is sending beacon in that channel**
2. **Following the channel plan of AP's IE.**

Configure steps

If need to enable Realtek WLAN

1. Add define "CONFIG_80211D" to file "include/autoconf.h", for example:



ps.
package

the driver you get is compound driver

not include/autoconf.h . For example,
the autoconf.h of RTL8723A SDIO interface IC should be



Once you finish this step, the function 1, automatic change scan type of channel to be
until step 2 is done.

2. **Set driver parameter “rtw_80211d” to 1**, default is 0.

one is

your favor.

2.1



2.2 Bring value from outside when load driver

In Linux OS, the value of driver parameters could be set when load driver. So you can
also set th

For example:

```
# insmod wlan.ko rtw_80211d=1
```

example:

```
# insmod wlan.ko rtw_80211d=0
```

ps. You need to be super user o

After these two steps, the driver now supports both function 1&2 of 802.11d.