



KTM 990 DUKE 2024 Manual

[Manuals](#) / [Brands](#) / [KTM Manuals](#) / [Motorcycle](#) / [990 DUKE 2024](#) / [Installation manual](#) / PDF

Contents

1. MEANS OF REPRESENTATION

- 1.1. Symbols used
- 1.2. Formats used

2. SETUP

- 2.1. Transport mode
- 2.2. Diagnostics connector
- 2.3. Unpacking and setting up the product

3. WORK

- 3.1. Adjusting the handlebar position
- 3.2. Removing the passenger seat
- 3.3. Mounting the passenger seat
- 3.4. Charging the 12V battery
- 3.5. Disconnecting the negative cable of the 12V battery
- 3.6. Connecting the negative cable of the 12V battery
- 3.7. Setting the time and date
- 3.8. Refueling
- 3.9. Opening fuel tank filler cap
- 3.10. Closing the fuel tank filler cap

3.11. [Checking the headlight setting](#)

3.12. [Adjusting the headlight range](#)

4. [CHASSIS TIGHTENING TORQUES](#)

5. [SUBSTANCES](#)

6. [Documents / Resources](#)

6.1. [References](#)

6.2. [In Other Languages](#)

6.3. [Other ManualsLib Projects](#)



MEANS OF REPRESENTATION

Symbols used

The meaning of specific symbols is described below.

✓	Indicates an expected reaction (e.g. of a work step or a function).
✗	Indicates an unexpected reaction (e.g. of a work step or a function).
i	Indicates information with more details or tips.
»	Indicates the result of a testing step.
V	Indicates a voltage measurement.
A	Indicates a current measurement.
Ω	Indicates a resistance measurement.

Formats used

The typographical formats used in this document are explained below.

Proprietary name	Indicates a proprietary name.
<u>Underlined terms</u>	Refer to technical details of the vehicle or indicate technical terms, which are explained in the glossary.

SETUP

This document is valid for the following models:

990 DUKE EU (F9803XC, F9803XD)

990 DUKE US (F9875XC, F9875XD)

990 DUKE CN (F9887XC, F9887XD)

Transport mode


This vehicle was blocked for transport in the software.

To operate the vehicle, the vehicle electronics must be enabled. This process is conducted during initial setup.

Enabling ensures that the initial setup is documented in electronic proof of service.

Enabling can be performed either temporarily, e.g. for a test ride, or permanently for

vehicle handover.




Info

Make sure that the vehicle is permanently enabled before handing it over to the customer.

Diagnostics connector

Diagnostics connector ❶ is located under the passenger seat.



Unpacking and setting up the product

Preliminary work

- Remove the box.

Main work

- Remove the adhesive tape in the upper area of the motorcycle.
- Roll down the film at the sides.

Guideline

To avoid damaging the vehicle while setting it up, do not remove the protective film on each component until installing the component, and leave it on the vehicle until work has been completed.



- Remove the separate enclosure and unpack it. Check that the scope of supply is complete using the enclosed packing list.

Info

The procedure for missing components is described in the Customer Service Manual.

- Check the vehicle for transport damage.

Info

The procedure in the event of transport damage is described in the Customer Service Manual.

WARNING

Danger of accidents

A repaired handlebar poses a safety risk.


If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

- Change the handlebar if the handlebar is damaged or bent.
- Unpack handlebar and position.

Info

Make sure the cables and wiring are positioned correctly.

The markings **1** on the handlebar should be at the height of the gap between the handlebar supports and the handlebar clamps.



- Position the handlebar clamps. Mount and tighten the screws evenly.


Guideline		
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)




Info

Keep the installed gap widths equal when tightening.


- Check the handlebar position.
 - » If the handlebar position is not adjusted as required by the customer:
 - Adjust the handlebar position. (see "Adjusting the handlebar position")
- Mount and tighten the rear mirror on both sides.



- Position the splash protector.
- Mount and tighten screws ②.



Guideline		
Remaining screws, chassis	EJOT PT K40x12	1 Nm (0.7 lbf ft)



- Position the cross tube guard on the underside of the engine.
- Mount and tighten screws ③ .

Guideline		
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

- Carefully loosen and remove the rear tension belt.



Info

An assistant prevents the motorcycle from falling over.

- Carefully loosen and remove the tension belts around the fork legs.
✓ The vehicle is released at the front.
- Together with an assistant, take the vehicle off the pallet.
- Remove the passenger seat. (see "Removing the passenger seat")
- Remove the spare key and **KEYCODECARD** keep in a safe place for the handover.



BURN HAZARD



Risk of injury

Battery acid and battery gases cause serious chemical burns.

- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.

- Fill the 12 V battery.



Info

Read the notes in the 12 V battery accessory pack.

- Charge the 12-V battery. (see "Charging the 12-V battery")

Guideline

The 12-V battery must be fully charged before it is handed over to the customer.



Info

The first charging process may take longer with a new 12-V battery.

- Take the tool set out of the separate enclosure and store it for the handover.
- Mount the passenger seat. (see "Mounting the passenger seat")
- Unpack and mount the **KTM PowerParts** included in the delivery (optional).



Info

Read the accompanying **KTM PowerParts** fitting instructions.

- Attach the stickers included in the scope of supply (optional).
- Set time and date. (see "Setting the time and date")
- Check the headlight setting. (see "Checking the headlight setting")
- Refuel. (see "Refueling")
- Position all controls in their exact positions on the handlebar. Tighten all screws.
- Remove the remaining film, padding, the corrugated cardboard, and the other packaging material.
- Prepare the vehicle according to the specifications of the presales inspection for handover to the customer.



Info

Transport mode must be deactivated to be able to start the motorcycle.

WORK

Adjusting the handlebar position


WARNING

Danger of accidents

A repaired handlebar poses a safety risk.

If the handlebar is bent or straightened, the material becomes fatigued. The handlebar may break as a result.

- Change the handlebar if the handlebar is damaged or bent.



- Remove screws ❶ . Take off the handlebar clamps ❷ . Position the handlebar so that screws ❸ are accessible.

Info

Cover the components to protect them against damage. Do not kink the cables and lines.

- Remove screws ❸ . Take off handlebar supports ❹ .
- Move the handlebar supports into the desired position A or B . Mount and tighten screws ❸ .

Guideline		
Mount the left and right handlebar supports in the same position.		
Screw, handlebar support	M10	45 Nm (33.2 lbf ft) Loctite 243

- Position the handlebar. **Info** Make sure the cables and wiring are positioned correctly.
- Position the handlebar clamp. Mount screws ❶ and tighten evenly.

Guideline		
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)


Removing the passenger seat

i Info

The passenger seat cover is also included for the special model.

If it is not required to carry a passenger, the passenger seat cover can be used instead of the passenger seat.

The passenger seat cover can be removed in the same way as the passenger seat.



- Insert the ignition key in seat lock **1** and turn it clockwise.
- Raise the front of the passenger seat cover, push it toward the fuel tank, and remove it upward.
- Remove the ignition key from the seat lock.

Mounting the passenger seat

i Info

The passenger seat cover is also included for the special model.

If it is not required to carry a passenger, the passenger seat cover can be used instead of the passenger seat.

The passenger seat cover can be fitted in the same way as the passenger seat.



- Hook holding lugs **1** of the passenger seat onto the storage compartment, lower the

front and push backward.

- Press the passenger seat downward until it clicks into place.



Danger of accidents

The seat can come loose from the anchoring if it is not mounted correctly.

- After assembly, check whether the seat is correctly locked and cannot be pulled up.
- Finally, check that the passenger seat is correctly mounted.

Charging the 12V battery



Risk of injury

Battery acid and battery gases cause serious chemical burns.

- Keep 12 V batteries out of the reach of children.
- Wear suitable protective clothing and safety glasses.
- Avoid contact with battery acid and battery gases.
- Keep sparks or open flames away from the 12 V battery.
- Only charge 12 V batteries in well-ventilated rooms.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse eyes with water for at least 15 minutes and consult a doctor immediately if battery acid and battery gases get into the eyes.

Note

Environmental hazard

12 V batteries contain environmentally hazardous materials.

- Do not dispose of 12 V batteries as household waste.
- Dispose of 12 V batteries at a collection point for used batteries.

Note

Environmental hazard

Hazardous substances cause environmental damage.

- Dispose of oils, grease, filters, fuel, cleaning agents, brake fluid, etc., correctly and in compliance with the applicable regulations.

Info

Even when there is no load on the 12-V battery, it discharges steadily each day. The charging level and the method of charging are very important for the service life of the 12-V battery.

Rapid recharging with a high charging current shortens the service life of the battery. If the charging current, charging voltage, or charging time is exceeded, electrolyte escapes through the safety valves. This reduces the capacity of the 12-V battery. If the 12-V battery is discharged by repeated starting, charge the 12-V battery immediately.

If the 12-V battery is left in a discharged state for an extended period, it will become deeply discharged and sulfating occurs, thus destroying the battery.


The 12-V battery is maintenance-free. The acid level does not have to be checked.

Preparatory work

- Remove the passenger seat. (see "Removing the passenger seat")
- Disconnect the negative cable of the 12-V battery. (see "Disconnecting the negative cable of the 12-V battery")

Main work

- Connect a battery charger to the 12-V battery. Adjust the battery charger.



EU battery charger **XCharge-professional** (00029095050)

Alternative 1

US battery charger **XCharge-professional** (00029095051)

Alternative 2

UK battery charger **XCharge-professional** (00029095052)

Info

Follow the instructions of the charger and the manual.

- Disconnect the battery charger after charging the 12-V battery.

Guideline	
The charging current, charging voltage, and charging time must not be exceeded.	
Recharge the 12-V battery regularly when the motorcycle is not being used	6 months

Finishing work

- Connect the negative cable of the 12-V battery. (see "Connecting the negative cable of the 12-V battery")
- Mount the passenger seat. (see "Mounting the passenger seat")
- Set the time and date.


Disconnecting the negative cable of the 12V battery

Preparatory work

- Remove the passenger seat. (see "Removing the passenger seat")

Main work


- Disconnect negative cable ❶ of the 12-V battery.



Connecting the negative cable of the 12V battery

Main work

- Connect negative cable ❶ . Tighten the screw.



Guideline		
Screw, battery terminal	M6x12	4.5 Nm (3.32 lbf ft)

Finishing work


- Mount the passenger seat. (see "Mounting the passenger seat")
- Set the time and date.

Setting the time and date

Condition


The motorcycle is stationary.

- Press the **SET** button when the menu is closed.
- Press **UP** or **DOWN** button until **Settings** appears. Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until **Clock & Date** is highlighted. Press the **SET** button to open the submenu.



Setting the clock

- Press the **UP** or **DOWN** button until **Set Clock** is marked.



- Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current hour is set. Press the **SET** button to select the hour.
- Press the **UP** or **DOWN** button until the current minute is set. Press the **SET** button to select the minute.

- Press the **BACK** button to exit the menu.

Setting the date

- Press the **UP** or **DOWN** button until **Set Date** is marked.



- Press the **SET** button to open the menu.
- Press the **UP** or **DOWN** button until the current day is set. Press the **SET** button to select the day.
- Press the **UP** or **DOWN** button until the current month is set. Press the **SET** button to select the month.
- Press the **UP** or **DOWN** button until the current year is set. Press the **SET** button to select the year.
- Press the **BACK** button to exit the menu.

Refueling



BURN HAZARD

Fire hazard

Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



WARNING

Danger of poisoning

Fuel is harmful to health.

- Avoid skin, eye and clothing contact with fuel.

- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.

Note

Material damage

Inadequate fuel quality causes the fuel filter to quickly become clogged.

In some countries and regions, the available fuel quality and cleanliness may not be sufficient. This will result in problems with the fuel system.


- Refuel only with clean fuel that meets the specified standards.

Note

Environmental hazard

Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.



- Switch off the engine.
- Open fuel tank filler cap. (see "Opening fuel tank filler cap")
- Fill the fuel tank with fuel up to the lower edge **A** of the filler neck.

Fuel tank capacity, approx.	14.8 l (3.91 US gal)	Super unleaded (ROZ 95)
-----------------------------	----------------------	-------------------------

- Close the fuel tank filler cap. (see "Closing the fuel tank filler cap")

Opening fuel tank filler cap



BURN HAZARD



Fire hazard

Fuel is highly flammable.

The fuel in the fuel tank expands when warm and can escape if overfilled.

- Do not fuel the vehicle in the vicinity of open flames or lit cigarettes.
- Switch off the engine for refueling.
- Make sure that no fuel is spilled; particularly not on hot parts of the vehicle.
- If any fuel is spilled, wipe it off immediately.
- Observe the specifications for refueling.



WARNING



Danger of poisoning

Fuel is harmful to health.


- Avoid skin, eye and clothing contact with fuel.
- Immediately consult a doctor if you swallow fuel.
- Do not inhale fuel vapors.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Rinse the eyes thoroughly with water, and consult a doctor in case of fuel contact with the eyes.
- Change your clothing if fuel spills on them.
- Keep fuels correctly in a suitable canister, and out of the reach of children.

Note

Environmental hazard

Improper handling of fuel is a danger to the environment.

- Do not allow fuel to enter the groundwater, the soil, or the sewage system.
- Lift cover  of the fuel tank filler cap and insert the ignition key into the lock.



Note

Danger of damage

The ignition key may break if overloaded. Damaged ignition keys must be replaced.

- Push down on the fuel tank filler cap to take pressure off the ignition key.
- Turn the ignition key 90° clockwise.
- Lift the fuel tank filler cap.

Closing the fuel tank filler cap



- Fold down the fuel tank filler cap.
- Turn the ignition key 90° clockwise.
- Push down the fuel tank filler cap and turn the ignition key counterclockwise until the lock closes.




Fire hazard

Fuel is highly flammable and a health hazard.

- Check that the fuel tank filler cap is locked correctly after closing.
- Change your clothing if fuel spills on them.
- Rinse the affected area immediately with plenty of water in the event of contact with the skin.
- Remove the ignition key and close the cover.

Checking the headlight setting



- Position the vehicle upright on a horizontal surface in front of a light wall and make a marking at the height of the center of the low beam headlight.
- Make another mark at a distance **B** under the first marking.

Guideline	
Distance B	5 cm (2 in)

- Position the vehicle perpendicular to the wall at a distance **A** from the wall and switch on the low beam.

Guideline	
Distance A	5 m (16 ft)

- The rider now mounts the motorcycle with luggage and passenger if applicable.
- Check the headlight setting.
The light-dark boundary must be exactly on the lower marking when the motorcycle is ready to be operated with the rider mounted along with any luggage and a passenger if applicable.
 - » If the boundary between light and dark does not meet specifications:
 - Adjust the headlight range. (see "Adjusting the headlight range")


Adjusting the headlight range

Preparatory work

- Check the headlight setting. (see "Checking the headlight setting")

Main work

- Turn adjusting screw **1** to adjust the headlight range.



i Info

Turn clockwise to increase the headlight range; turn counterclockwise to reduce the headlight range.


If you have a payload, you may have to correct the headlight range.

Screw ❶ also secures the headlight. Ensure the screw is always screwed in far enough.

- Set the headlight to marking **B** .

Guideline:

The light-dark boundary must lie exactly on lower marking **B** when the motorcycle is ready to operate with the rider mounted along with any luggage and a passenger, if applicable.



CHASSIS TIGHTENING TORQUES

Radiator hose hose clamp	-	2.2 Nm (1.62 lbf ft)
Remaining screws, chassis	EJOT PT® K40x12	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K45x12	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K50x12	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K50x14	1 Nm (0.7 lbf ft)
Remaining screws, chassis	EJOTPT® K50x16	2 Nm (1.5 lbf ft)
Remaining screws, chassis	EJOTPT® K50x18	2 Nm (1.5 lbf ft)
Screw, headlight	EJOT PT® K50x14	4 Nm (3 lbf ft)
Throttle valve body hose clamp	-	2.8 Nm (2.07 lbf ft)
Brake fluid reservoir cover, front	M4	1 Nm (0.7 lbf ft)
Remaining nuts, chassis	M4	3 Nm (2.2 lbf ft)
Remaining screws, chassis	M4	3 Nm (2.2 lbf ft)
Screw, fixed grip, left	M4	3 Nm (2.2 lbf ft)
Remaining nuts, chassis	M5	5 Nm (3.7 lbf ft)
Remaining screws, chassis	M5	5 Nm (3.7 lbf ft)
Screw, air filter box	M5	3 Nm (2.2 lbf ft)
Screw, battery holding bracket	M5	3 Nm (2.2 lbf ft)
Screw, brake fluid reservoir for rear brake	M5	5 Nm (3.7 lbf ft)
Screw, combination instrument	M5	4.5 Nm (3.32 lbf ft)
Screw, combination switch, left	M5	3.5 Nm (2.58 lbf ft)
Screw, combination switch, right	M5	4.5 Nm (3.32 lbf ft)
Screw, combination switch, right	M5	3 Nm (2.2 lbf ft)
Screw, engine sprocket cover	M5	5 Nm (3.7 lbf ft) Loctite®243™
Screw, front rider's seat	M5x12	3 Nm (2.2 lbf ft)
Screw, fuel level sensor	M5	3 Nm (2.2 lbf ft)
Screw, fuel tank cover	M5	3 Nm (2.2 lbf ft)
Screw, heat guard	M5	5 Nm (3.7 lbf ft)
Screw, lower rear panel	M5	3 Nm (2.2 lbf ft)
Screw, mask support	M5	3.5 Nm (2.58 lbf ft)
Screw, support roller	M5	4 Nm (3 lbf ft) Loctite®243™
Screw, throttle grip	M5	3.5 Nm (2.58 lbf ft)
Screw, trim	M5	3 Nm (2.2 lbf ft)
Brake cylinder screw on the rear brake system	M6	10 Nm (7.4 lbf ft) Loctite®243™
Nut, cable on starter motor	M6	5 Nm (3.7 lbf ft)
Nut, hand brake lever	M6	5.5 Nm (4.06 lbf ft)
Nut, push rod, foot brake lever	M6	10 Nm (7.4 lbf ft)
Nut, shift rod	M6	6 Nm (4.4 lbf ft)
Nut, shift rod	M6LH	6 Nm (4.4 lbf ft)
Remaining nuts, chassis	M6	10 Nm (7.4 lbf ft)
Remaining screws, chassis	M6	10 Nm (7.4 lbf ft)

Screw, activated carbon filter holder	M6	6 Nm (4.4 lbf ft)
Screw, angle sensor	M6	5 Nm (3.7 lbf ft)
Screw, battery terminal	M6x12	4.5 Nm (3.32 lbf ft)
Screw, battery terminal	M6x20	4.5 Nm (3.32 lbf ft)
Screw, clutch assembly	M6	8 Nm (5.9 lbf ft)
Screw, foot brake lever stub	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, front brake assembly	M6	8 Nm (5.9 lbf ft)
Screw, fuel tank rollers	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, fuel tank spoiler	M6	3 Nm (2.2 lbf ft)
Screw, ground wire on frame	M6	6 Nm (4.4 lbf ft)
Screw, ground wire to starter motor	M6	6 Nm (4.4 lbf ft)
Screw, ignition lock (tamper-proof screw)	M6	Tighten until the head tears off. Loctite®243™
Screw, license plate bracket	M6	6 Nm (4.4 lbf ft)
Screw, license plate holder	M6	6 Nm (4.4 lbf ft)
Screw, lower mask support	M6	6 Nm (4.4 lbf ft)
Screw, magnetic holder on side stand	M6	2 Nm (1.5 lbf ft) Loctite®243™
Screw, push rod ball joint on the rear brake cylinder	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, seat lock	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift lever stub	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift rod	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, shift shaft deflector on shift shaft	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, side stand sensor	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, subframe brace	M6	10 Nm (7.4 lbf ft) Loctite®243™
Screw, wheel speed sensor	M6	6 Nm (4.4 lbf ft)
Nut, manifold on cylinder head	M8	Tighten the nuts evenly. Do not bend the metal. 13 Nm (9.6 lbf ft)
Nut, rear sprocket screw	M8	35 Nm (25.8 lbf ft) Loctite®2701™
Pin, brake linings	M8	8 Nm (5.9 lbf ft)
Pin, rear brake caliper	M8	22 Nm (16.2 lbf ft)
Remaining nuts, chassis	M8	25 Nm (18.4 lbf ft)
Remaining screws, chassis	M8	25 Nm (18.4 lbf ft)
Screw, bottom triple clamp	M8	12 Nm (8.9 lbf ft)
Screw, cross member	M8x20	25 Nm (18.4 lbf ft) Loctite®243™

Screw, engine fixing arm linkage bracket	M8	25 Nm (18.4 lbf ft) Loctite®243™
Screw, foot brake lever	M8	25 Nm (18.4 lbf ft) Loctite®2701™
Screw, footrest bracket, rear	M8x30	25 Nm (18.4 lbf ft) Loctite®243™
Screw, fork stub	M8	15 Nm (11.1 lbf ft)
Screw, front brake disc	M8	28 Nm (20.7 lbf ft) Loctite®2701™
Screw, grab handle	M8x20	25 Nm (18.4 lbf ft) Loctite®243™
Screw, handlebar clamp	M8	20 Nm (14.8 lbf ft)
Screw, main silencer clamp	M8	15 Nm (11.1 lbf ft)
Screw, main silencer fastening	M8	15 Nm (11.1 lbf ft)
Screw, manifold clamp	M8	15 Nm (11.1 lbf ft)
Screw, presilencer on frame	M8	15 Nm (11.1 lbf ft) Loctite®243™
Screw, rear brake disc	M8	28 Nm (20.7 lbf ft) Loctite®2701™
Screw, shift lever	M8	25 Nm (18.4 lbf ft) Loctite®2701™
Screw, steering damper on frame	M8	8 Nm (5.9 lbf ft) Loctite®243™
Screw, steering damper on triple clamp	M8	8 Nm (5.9 lbf ft) Loctite®243™
Screw, steering stem	M8	20 Nm (14.8 lbf ft) Loctite®243™
Screw, top triple clamp	M8	15 Nm (11.1 lbf ft)
Engine carrying screw	M10	45 Nm (33.2 lbf ft) Loctite®243™
Remaining nuts, chassis	M10	45 Nm (33.2 lbf ft)
Remaining screws, chassis	M10	45 Nm (33.2 lbf ft)
Screw, front footrest bracket	M10x24	45 Nm (33.2 lbf ft) Loctite®243™
Screw, front footrest bracket	M10x80	45 Nm (33.2 lbf ft) Loctite®243™
Screw, handlebar support	M10	45 Nm (33.2 lbf ft) Loctite®243™
Screw, main silencer holder	M10x24	30 Nm (22.1 lbf ft) Loctite®243™
Screw, side stand	M10	35 Nm (25.8 lbf ft) Loctite®243™
Screw, subframe	M10	50 Nm (36.9 lbf ft) Loctite®243™
Banjo bolt, brake line	M10x1	25 Nm (18.4 lbf ft)
Screw, front brake caliper	M10x1.25	45 Nm (33.2 lbf ft) Loctite®243™
Screw, bottom shock absorber	M12	80 Nm (59 lbf ft) Loctite®2701™

Screw, swingarm pivot	M12	100 Nm (73.8 lbf ft)
Screw, top shock absorber	M12	80 Nm (59 lbf ft) Loctite®2701™
Lambda sensor	M18x1.5	50 Nm (36.9 lbf ft)
Bushing, shock absorber support	M20LHx1.5	10 Nm (7.4 lbf ft) Thread and fitting greased
Screw, steering head	M20x1.5	18 Nm (13.3 lbf ft)
Screw, adjusting ring	M24x1.5	10 Nm (7.4 lbf ft)
Nut, rear wheel spindle	M25x1.5	90 Nm (66.4 lbf ft) Thread and contact area of wheel spindle greased
Screw, wheel spindle, front	M25x1.5	45 Nm (33.2 lbf ft)

SUBSTANCES

Super unleaded (ROZ 95)

Standard/classification

- DIN EN 228 (ROZ 95)

Guideline

- Only use super unleaded fuel that matches or is equivalent to the specified standard.
- Fuel with an ethanol content of up to 10% (E10 fuel) is safe to use.



Info

Do **not** use fuel containing methanol (e.g., M15, M85, M100) or more than 10% ethanol (e.g., E15, E25, E85, E100).

KTM Sportmotorcycle GmbH

5230 Mattighofen/Austria

[KTM.COM](https://www.ktm.com)

Documents / Resources

References

 [KTM - READY TO RACE | Netherlands](#)

Available languages

 [Deutsch](#)  [Français](#)  [Español](#)  [Mexicano](#)  [Dutch](#)  [Italiano](#)  [Dansk](#)  [Norsk](#)

 [Polski](#)  [Suomi](#)  [Português](#) [Español \(Latinoamérica\)](#)  [Русский](#)  [Български](#)

 [Čeština](#)  [ελληνικά](#) [English \(UK\)](#)  [Eesti](#)  [Hrvatski](#)  [Magyar](#)

 [Bahasa indonesia](#)  [Қазақша](#)  [Lietuvių](#) [Português \(Brasil\)](#)  [Română](#)

[Română \(Moldova\)](#)  [Slovenčina](#)  [Slovenščina](#)  [Shqip](#) [Kiswahili](#)  [Türkçe](#)

 [O'zbekcha](#)

Other ManualsLib Projects

 www.manualslib.com

 www.manualslib.de

 www.manualslib.es

 www.manualslib.fr

 www.manualslib.nl

 www.manualslib.mx

 www.manualslib.tech 30+ languages