

Helios Robotics Safety Guidelines

Read this guide before operating any Helios Robotics product. Keep a clear zone around moving robots and never disable a safety scanner while a unit is energized. Lockout procedures must be followed during maintenance. Only trained operators may modify fleet traffic rules. Emergency stop buttons are located on the chassis and in the Fleet Manager console; test them at the start of every shift. Report any near-miss incident through the safety portal within one business day.